TM-327
3rd printing

ATARI®
GAMES

Hard Drivin'™

Operator's Manual



For technical assistance:

If reading through this manual does not lead to solving your game maintenance or repair problem, call TELE-HELP® at one of these Atari Games Customer Service offices:

UNITED STATES

Atari Games Corporation
California Customer Service Office
737 Sycamore Drive
Milpitas, CA 95036-1110
Fax (408) 434-3945
Telex 5101007850
✆ **(408) 434-3950**
(Monday–Friday, 7:30 a.m.–4:00 p.m. Pacific time)

EUROPE

Atari Games Ireland Limited
European Customer Service Office
Tipperary Town, Ireland
Fax 062-51702
Telex 70665
✆ **062-52155**
(Monday–Friday, 9:00 a.m.–5:30 p.m. GMT)

ATARI®
GAMES

Hard Drivin'™

OPERATOR'S MANUAL

with Illustrated Parts Lists



Table of Contents

1 Set Up

How to Use This Manual 1-1
Operating the Simulator 1-2
Inspecting the Simulator 1-2
Installing the Attraction Sign Assembly 1-2
Adjusting the Glides 1-3
Control and Switch Locations 1-3
Setting the Coin and Game Options 1-4
Simulator Systems 1-4
Maximizing Earnings 1-4
Simulator Driving 1-4

2 Self-Test and Diagnostics

Automated Self Test 2-2
Program ROM and RAM Test 2-2
Microprocessor and Board Tests 2-3

Test Menu Screens 2-3

Operator Screens 2-4
Coin Options 2-4
Game Options 2-5
Custom Game Options 2-8
Statistics 2-9
Histogram 2-10
Error Count 2-10
Games Played by Day and Hour 2-10

Set Controls Screens 2-10

Control Inputs Screen 2-11

Monitor Test Patterns 2-12

Set Clock Screen 2-12

Disable Broken Controls Screen 2-13

Special Functions Screen 2-13
Main Board GSP Tests 2-14
Main Board MSP Tests 2-15
Main Board Controls 2-15
Steering Wheel Submenu 2-16
Shifter Test Screen 2-17
Main Board ROM Checksums 2-17
Main Board ZRAM Test 2-18
ADSP Board Tests 2-18
Sound Board 2-18

LEDs on the Main PCB 2-20

DIP Switches 2-20

3 Maintenance

Maintaining and Inspecting 3-2
Maintaining Your Simulator 3-2

Dashboard 3-2
Removing the Dashboard 3-2
Installing the Dashboard 3-3

Steering Assembly 3-4
Greasing the Steering Assembly 3-5
Replacing the Steering Assembly Potentiometer 3-5
Replacing the Steering Wheel Motor 3-9
Replacing the Steering Wheel Stop 3-11

Key Switch Assembly 3-11
Oiling the Key Switch Assembly 3-11
Replacing the Spring in the Key Switch Assembly 3-11
Tightening the Screw in the Key Switch Assembly Actuator 3-12
Replacing the Switch on the Key Switch Assembly 3-12

Clutch Pedal 3-13
Maintaining the Clutch and Brake Pedals 3-15
Replacing the Clutch Potentiometer 3-15
Replacing the Clutch Springs 3-15

Brake Pedal 3-17
Repairing the Brake 3-17
Testing the Switch, Switch Acuator Distance, and Pedal Movement 3-17
Testing the Stain Gauge and the Strain Gauge Bonding 3-18
Replacing the Brake Switch 3-19
Replacing the Brake Strain Gauge and Pedal Assembly 3-19

Gas Pedal Assembly 3-20
Lubricating the Gas Pedal 3-20
Rewinding the Gas Pedal Pulley Cable 3-20
Replacing the Gas Pedal Cable Spring 3-21
Replacing the Gas Pedal Potentiometer 3-21
Replacing a Broken Compression or Extension Spring on the Gas Pedal 3-21

Shifter Assembly 3-24
Installing a New Shifter Boot 3-24
Removing the Reverse Latch Pin 3-24
Replacing a Shifter Potentiometer 3-24
Replacing the Shifter Magnet or Plate 3-27

Seat Assembly 3-27
Replacing the Seat Rod End Bearings 3-28
Replacing Bearings on the Seat Pivot 3-29
Replacing Main Seat Bearings 3-31
Replacing the Gears on the Seat Assembly 3-32
Replacing the Small Gear 3-34
Replacing the Large Gear 3-34
Replacing the Magnet on the Seat Assembly 3-34
Replacing the Seat Potentiometer 3-35

Video Display 3-36
Removing the Video Display 3-36
Replacing the Video Display 3-36

Motor Amplifier Assembly 3-38
Removing the Motor Amplifier Assembly 3-38

Speakers 3-38
Removing a Speaker 3-38

Static-Sensitive Devices 3-38
Replacing Static-Sensitive Devices 3-38

Cleaning the Coin Mechanism 3-39

Cleaning the Interior Components 3-39

4 Illustrated Parts Lists

See the List of Illustrations that follows.

Statistics Sheet

List of Illustrations

Figure 1-1 Attraction Sign Installation 1-3

Figure 2-1 Program ROM and RAM Test 2-3
Figure 2-2 Microprocessor and Board Tests 2-3
Figure 2-3 Instructions for Test Menu Screen 2-4
Figure 2-3 Test Menu Screen 2-4
Figure 2-5 Coin Options Screen 2-5
Figure 2-6 Game Options Screen 2-5
Figure 2-7 Custom Game Options Screen 2-8
Figure 2-8 Statistics Screen 2-9
Figure 2-9 Histogram Screen 2-10
Figure 2-10 Games Played by Day and Hour Screen 2-10
Figure 2-11 First Set Controls Screen 2-11
Figure 2-12 Control Inputs Screen 2-11
Figure 2-13 Set Clock Screen 2-12
Figure 2-14 Disable Broken Controls Screen 2-13
Figure 2-15 Special Functions Screen 2-13
Figure 2-16 GSP Tests Screen 2-14
Figure 2-17 MSP Tests Screen 2-15
Figure 2-18 Main Board Controls Screen 2-15
Figure 2-19 Pots: 8-Bit Screen 2-16
Figure 2-20 Pots: 12-Bit Screen 2-16
Figure 2-21 Steering Wheel Submenu Screen 2-16



Figure 2-22 Send Force Screen 2-17
Figure 2-23 Shifter Screen 2-17
Figure 2-24 ROM Checksums Screen 2-17
Figure 2-25 ADSP Board Tests Screen 2-18
Figure 2-26 ADSP ROM Checksums Tests Screen 2-18
Figure 2-27 Sound Board Tests Screen 2-19
Figure 2-28 Sound Board Sound Wave ROM Checksums Screen 2-20
Figure 2-29 DIP Switch and LED Locations on the Main PCB 2-21

Figure 3-1 Removing and Installing the Dashboard 3-4
Figure 3-2 Steering Wheel Has No Feedback and You Have Tried the *Set Controls* Screens 3-6
Figure 3-3 Steering Wheel is Turned All the Way to One Side and You Have Tried the *Set Controls* Screens 3-7
Figure 3-4 Steering Wheel is Jerky and You Have Tried the *Set Controls* Screens 3-8
Figure 3-5 Maintaining the Steering Wheel 3-10
Figure 3-6 Maintaining the Key Switch Assembly 3-12
Figure 3-7 Clutch, Seat, or Gas Pedal is Not Working or Working Erratically and You Have Tried the *Set Controls* Screens 3-14
Figure 3-8 Maintaining the Clutch and Brake Assembly 3-16
Figure 3-9 Brake is Not Working or Working Erratically and You Have Tried the *Set Controls* Screens 3-18
Figure 3-10 Rewinding the Gas Pedal Pulley Cable 3-20
Figure 3-11 Maintaining the Gas Pedal 3-22
Figure 3-12 Shifter is Not Working or Working Erratically and You Have Already Tried the *Set Controls* Screens 3-25
Figure 3-13 Maintaining the Shifter 3-26
Figure 3-14 Seat is Not Locked When it Should Be and You Have Already Tried the *Set Controls* Screens 3-29
Figure 3-15 Seat is Locked When it Should Not Be and You Have Already Tried the *Set Controls* Screens 3-30
Figure 3-16 Maintaining the Seat Assembly 3-33
Figure 3-17 Removing the Video Display 3-37

Figure 4-1 Cabinet-Mounted Assemblies 4-2
Figure 4-2 Seat Assembly 4-8
Figure 4-3 Dashboard Assembly 4-10
Figure 4-4 Key Switch Assembly 4-12
Figure 4-5 Steering Assembly 4-14
Figure 4-6 Shifter Assembly 4-16
Figure 4-7 Clutch and Brake Pedal Assembly 4-18
Figure 4-8 Gas Pedal Assembly 4-20
Figure 4-9 Coin Acceptors, Inc. Coin Door Assembly 4-22
Figure 4-10 Power Supply Assembly 4-26
Figure 4-11 Hard Drivin' Main PCB Assembly 4-30
Figure 4-12 APU PCB Assembly 4-36
Figure 4-13 Shifter PCB Assembly 4-38
Figure 4-14 Brake PCB Assembly 4-40

List of Tables

Table 1-1 Simulator Specifications 1-2

Table 2-1 Using the Self-Test Screens and Diagnostics 2-2
Table 2-2 Coin Option Settings 2-4
Table 2-3 Game Option Settings 2-5
Table 2-4 All Screens Appearing in the Self-Test 2-6
Table 2-5 Custom Game Option Settings 2-8
Table 2-6 When to Use the Special Function Items 2-14
Table 2-7 Program ROM Locations 2-18
Table 2-8 ADSP Scope Loop Diagnostic Tests 2-19
Table 2-9 LED Status 2-20
Table 2-10 Using the DIP Switches 2-22

Table 3-1 Maintenance and Inspection Items 3-2
Table 3-2 Troubleshooting All Controls 3-3
Table 3-3 Voltage Inputs and Test Points on the Simulator PCBs 3-3
Table 3-4 Troubleshooting the Steering Assembly 3-5
Table 3-5 Troubleshooting the Key Switch 3-11
Table 3-6 Troubleshooting the Clutch Pedal 3-13
Table 3-7 Troubleshooting the Brake Pedal 3-17
Table 3-8 Troubleshooting the Gas Pedal Assembly 3-21



Table 3-9 Troubleshooting the Shifter Assembly 3-24
Table 3-10 Troubleshooting the Seat Assembly 3-28
Table 3-11 Troubleshooting the Video Display 3-36
Table 3-12 Troubleshooting the Speakers 3-38

Safety Summary

The following safety precautions apply to all game operators and service personnel. Specific warnings and cautions will be found in this manual whenever they apply.

WARNING

Properly Ground the Game. Players may receive an electrical shock if this game is not properly grounded! To avoid electrical shock, do not plug in the game until it has been inspected and properly grounded. This game should only be plugged into a grounded three-wire outlet. If you have only a two-wire outlet, we recommend you hire a licensed electrician to install a three-wire grounded outlet. If the control panel is not properly grounded, players may receive an electrical shock! After servicing any part on the control panel, check that the grounding wire is firmly secured to the inside of the control panel. After you have checked this, lock up the game.

AC Power Connection. Before you plug in the game, be sure that the game's power supply can accept the AC line voltage in your location. The line voltage requirements are listed in the first chapter of this manual.

Disconnect Power During Repairs. To avoid electrical shock, disconnect the game from the AC power before removing or repairing any part of the game. If you remove or repair the video display, be very careful to avoid electrical shock. High voltages continue to exist even after power is disconnected in the display circuitry and the cathode-ray tube (CRT). Do not touch the internal parts of the display with your hands or with metal objects! Always discharge the high voltage from the CRT before servicing it. Do this after you disconnect it from the power source. First, attach one end of a large, well-insulated, 18-gauge jumper wire to ground. Then momentarily touch the free end of the grounded jumper wire to the CRT anode by sliding the wire under the anode cap. Wait two minutes and do this again.

Use Only Atari Parts. To maintain the safety of your Atari game, use only Atari parts when you repair it. Using non-Atari parts or modifying the game circuitry may be dangerous, and could injure you and your players.

Handle the CRT With Care. If you drop the CRT and it breaks, it may implode! Shattered glass from the implosion can fly six feet or more.

Use the Proper Fuses. To avoid electrical shock, use replacement fuses which are specified in the parts list for this game. Replacement fuses must match those replaced in fuse type, voltage rating, and current rating. In addition, the fuse cover must be in place during game operation.

CAUTION

Properly Attach All Connectors. Make sure that the connectors on each printed circuit board (PCB) are properly plugged in. The connectors are keyed to fit only one way. If they do not slip on easily, do not force them. If you reverse a connector, it may damage your game and void your warranty.

Ensure the Proper AC Line Frequency. Video games manufactured for operation on 60 Hz line power (used in the United States) must not be operated in countries with 50 Hz line power (used in Europe). If a 60 Hz machine operates on 50 Hz line power, the fluorescent line ballast transformer will overheat and cause a potential fire hazard. Check the product identification label on your machine for the line frequency required.

ABOUT NOTES, CAUTIONS, AND WARNINGS

In Atari publications, notes, cautions and warnings have the following meaning:

NOTE — A highlighted piece of information.

CAUTION — Equipment and/or parts can be damaged or destroyed if instructions are not followed. You will void the warranty on Atari printed-circuit boards, parts thereon, and video displays if equipment or parts are damaged or destroyed due to failure of following instructions.

WARNING — Players and/or technicians can be killed or injured if instructions are not followed.

Chapter 1

Set-Up

How to Use This Manual

This manual is written for operators and service personnel. It provides information for setting up, driving, testing, and maintaining your Hard Drivin'™ simulator.

The manual is divided into the following chapters:

- Chapter 1 contains set-up and simulator driving information.
- Chapter 2 contains self-test procedures and additional diagnostic tests. The self-test is important in the Hard Drivin' simulator. You can troubleshoot the PC boards, main circuits, and controls using the more than 60 screens in the self-test. You should regularly test the boards and controls with the self-test to keep your simulator in peak condition and at top earnings.
- Chapter 3 contains the preventive maintenance schedule for the simulator and the repair procedures, flowcharts, and troubleshooting tables for each control. If you have problems with your simulator, use this chapter to troubleshoot and to repair it. Be sure to perform the preventive maintenance tasks to keep your simulator in good condition.
- Chapter 4 contains the illustrated parts lists.



Operating the Simulator

To operate your simulator for maximum income, make sure your players know that the simulator is designed to be driven like a real car. You should regularly do the automated self-test and check the controls with the *Control Inputs* screen in the self-test. By using the self-test regularly, you can find and fix problems immediately. This lets you keep your simulator in top condition.

NOTE

If you are installing a new PC board or a control in your simulator, go through the Set Controls *screen in the self-test. This is explained in Chapter 2.*

If you turn on your simulator and you see a screen that says Initialize Pot Inputs *instead of the attraction screens, then reset the controls by following the instructions on the screens that appear.*

Inspecting the Simulator

WARNING

To avoid electrical shock, do not plug in the cabinet until it has been properly inspected and set up for the line voltage in your area.

This cabinet should be connected to a grounded three-wire outlet only. If you have only two-wire outlets, we recommend that you hire a licensed electrician to install grounded outlets. Players can receive an electrical shock if the cabinet is not properly grounded.

Inspect your Hard Drivin' simulator carefully to ensure that the simulator is complete and was delivered to you in good condition.

Inspect the cabinet and seat as follows:

1. Examine the exterior of the cabinet for dents, chips, or broken parts.
2. Open the lower service door and the small top service panel. (Leave this top panel open so you can install the attraction sign.) Unlock and open the coin doors. Inspect the interior of the cabinet as follows:
   a. Check that all plug-in connectors on the cabinet harnesses are firmly plugged in. Do not force connectors together. The connectors are keyed so they fit only in the proper orientation. A reversed connector can damage a printed-circuit board (PCB). This will void your warranty.

Table 1-1 Simulator Specifications

Characteristic	Specification
Power Consumption	635 W maximum
Line Fuse Rating	7 Amps
Line Voltage	102 to 132 VAC
Temperature	5° to 38° C (37° to 100° F)
Humidity	Not to exceed 95% relative
Width	31 1/2 in. (81 cm.)
Depth (seat pushed in)	62 1/2 in. (160 cm.)
Height	77 in. (197 cm.)
Weight	750 lbs. (341 kg.)

   b. Ensure that all plug-in integrated circuits on each PCB are firmly plugged into their sockets.
   c. Inspect the power cord for any cuts or dents in the insulation.
   d. Inspect the power supply. Make sure that the correct fuses are installed. Check that the harness is plugged in correctly and that the fuse block cover is mounted in place. Check that the green ground wires are connected.
   e. Inspect other sub-assemblies, such as the video display, controls, printed-circuit boards (PCBs), and speakers. Make sure that they are mounted securely and that the ground wires are connected.

Installing the Attraction Sign Assembly

The attraction sign assembly is shipped uninstalled with the simulator. Mount the sign on the back of the cabinet as shown in Figure 1-1.

The hardware for assembling the sign and for mounting it is shipped in the cash box. This hardware consists of ten 1/4-20 button-head screws 2 inches long with black washers.

1. Lay the attraction sign face down on a clean surface where it will not be scratched.
2. Lay the H-shaped attraction frame on top of the sign. Put the short ends of the H on top of the sign. The harness connection in the leg should face the sign. Attach the harness from the sign to the harness in the leg. Push the extra wires inside the leg of the attraction frame.
3. Install six screws and washers through the attraction frame and into the attraction sign. Tighten the screws.


Attraction Sign
Sub-Assembly
Attraction Frame
Button-Head
Screw
Washer

Chapter 2

Self-Test and Diagnostics

The *Hard Drivin'* simulator is a complex machine. To keep it at peak efficiency and maximum earnings, you should regularly check the controls, RAMs, ROMs, PCBs, and microprocessor systems. You can check all of these when you switch on the self-test. Also in the self-test you can check the video display, the statistics, and set the internal clock.

If you cannot use the self-test because the screen is dark, you can use a DIP switch on the main PCB to find the source of the problem. If you are having electronic problems, you can check the state of various signals with the LEDs on the main PCB.

You should regularly check the following screens and information. We recommend you check these when you first set up the simulator, each time you collect money, or when the simulator is not working correctly.

- Use the automated self-test, which begins automatically when you turn on the self-test to test the program RAMs and ROMs, the video RAMs, color RAMs, the MSP microprocessor system, the ADSP PCB, and the sound PCB. The test takes about 5 minutes to run.
- Check the *Control Inputs* screen, which you choose from the *Test Menu* screen. This shows the voltage input to the main PCB from the steering wheel, brake pedal, gas pedal, clutch pedal, seat, and shifter. With this information you can easily check how the controls are working.

NOTE

If the control inputs are wrong, your earnings may drop, since the realistic driving feel is lost.

- Check the *Statistics, Histogram,* and *Games Played by Day and Hour* screens which show the statistical information about how and when your simulator is played.

Table 2-1 shows you what tests and screens to use at different times and for different problems.



Automated Self-Test

When you enter the self-test, the simulator automatically tests the program ROM and RAM, the video RAM, the color RAM, the MSP microprocessor system, the ADSP PC board, and the sound PC board. This test takes about five minutes (unless you bypass the test as described in the next paragraph).

NOTE

If you do not see anything on the video display screen, you may have a video display problem or a simulator system problem. See DIP Switches *at the end of this chapter to diagnose the problem.*

If you do not want to wait for the systems and PCBs to be tested, then skip these tests by turning the key switch while in the program ROM and RAM screen, Figure 2-1. If you want to go to the attract mode, just turn off the self-test switch.

Program ROM and RAM Test

When you enter self-test, the simulator tests the program ROM and RAM. The screen in Figure 2-1 shows the results of a program ROM and RAM test.

The top of the screen shows the ROM test result. The numbers on the left and the letters on the top of the screen show the locations of the ROMs on the main PCB. If a white box appears, then the ROM there is good. If an empty box appears (as shown at 200U and

Table 2-1 Using the Self-Test Screens and Diagnostics

Problem or Type	Explanation
Automated Self-Test	When you switch on the self-test, the automated self-test is performed. This tests the program RAM and ROM and the PCBs. You can skip the self-test by turning and holding the key as soon as you enter the self-test. If you cannot run the self-test at all, use the DIP switches to diagnose the problem. These are explained at the end of this chapter.
Test Menu	Appears after the automated self-test. Select tests and information on this screen.
Regular Maintenance	Regularly do the following: 1. Do the automated self-test. 2. Check the *Operator Screens.* 3. Go to the *Control Inputs* screen to test the controls.
Game Set-Up	When you first set up your game, do the following: 1. Do the automated self-test. 2. Make sure the options on the *Operator Screens* are set correctly for your location, or set to the defaults. 3. Go to the *Control Inputs* screen to test the controls. 4. Set the clock, if necessary, using the *Set Time* screen.
Control Problem	1. Do the *Set Controls* screens. 2. If that does not correct the problem, go to the *Control Inputs* screen and see if the input from the control changes as you use the control. 3. Go to Chapter 3 and check the troubleshooting table and maintenance information for that control. 4. If the shifter, brake, clutch, or seat potentiometer is broken and you cannot fix it immediately, but still want to operate the game, turn off the control circuit in the *Disable Broken Controls* screen.
Video Display Problem	1. Try the *Monitor Test Patterns* screens. 2. If you cannot go into the self-test or the screen is dark, use the DIP switch diagnostics.
Electronics Problems	1. Do the automated self-test. 2. Choose the *Special Functions* screen that applies to your problems: the GSP, MSP, program ROM, ADSP PC board, or sound PC board test.
Game Clock	Use the *Set Time* screen to set the internal game clock. This time is used in the statistics screen that shows games played by day and time and in the schedule for clearing the high score table.
Cannot Enter the Self-Test	Use the DIP switches and the LEDs to diagnose the problem. These are explained at the end of the chapter.

210U), then the ROM there is bad. If nothing appears, then nothing was tested there.

The RAMs are tested after the ROMs. If the RAMs have no errors, then you see the message *Program RAM OK*. If the test finds an error, then you see *Bad Program RAM At* with the bad RAM location listed.

This screen disappears after a few seconds and the self-test continues. However, the screen with the results of the complete self-test, shown in Figure 2-2, will show the message *Bad Program ROM* (or *Bad Program RAM*) if it found an error in the program ROMs or RAMs.



Figure 2-1 Program ROM and RAM Test Screen

Microprocessor and Board Tests

After checking the program RAM and ROM, the automated self-test checks the simulator's microprocessor and PC boards. It tests the video RAM and color RAM in the GSP microprocessor system, the DRAM in the MSP microprocessor system, the ADSP board, and the sound board. The test takes four to five minutes. You see the screen in Figure 2-2 when the test finishes.

If the system or board is good, *OK* follows the test name. If it is bad, the word *Bad* precedes the name of the board or system (except for the ADSP board test, which gives more information). If you have a bad system or board, then choose *Special Functions* from the test menu, choose the appropriate system or board tests from the special functions menu, and read the description of the tests in this chapter.

A brief description of each microprocessor and board test performed in the self-test is below.

PROGRAM ROM: Described above.

PROGRAM RAM: Described above.

GSP VRAM: Uses the Simple GSP VRAM Test. (Described in the section *Main Board GSP Tests.*)

GSP COLOR RAM: Uses the GSP Color RAM Test. (Described in the section *Main Board GSP Tests.*)

MSP DRAM: Uses the MSP Verify Test. (Described in the section *Main Board MSP Tests.*)

ADSP Board: Tests the ADSP board memory and the ADSP-2100. Most of the error messages are self-explanatory. (*Does Not Respond* generally indicates a missing board.)

Sound Board: Tests the program ROM and RAM on the sound PC board. If any are bad, the message *Bad Sound Board* appears on the screen.

Sound Wave ROMS: Tests the ROMs that have the sound waveform data. If any are bad, the message *Bad Sound Wave ROMs* appears on the screen.



Figure 2-2 Microprocessor and Board Tests Screen

Test Menu Screens

After the microprocessor and board test is finished, or you bypass it, turn the key to see the test menu screens. Turn the key once to see the screen with the instructions for moving and choosing in the test menu, shown in Figure 2-3. Turn the key again to see the test menu.

To move down the menu, press the left coin switch. To move up the menu, press the right coin switch. You can choose the test menu item with the white letters by turning the key.

The test menu, shown in Figure 2-4, is the most important screen in the self-test. Use this screen to choose the other screens and tests in the self-test. If you choose any item on this test menu, a new screen on that subject appears. Table 2-4 shows all the screens that appear in the self-test.



Figure 2-3 Instructions for Test Menu Screen



Figure 2-4 Test Menu Screen

Operator Screens

Choose the operator screens in the test menu by turning the key while the words *Operator Screens* are in white. (For information about moving in and choosing from the menu, see the section above.)

If you are in the operator screens and want to go to the attract mode, first turn the key to go through the remaining operator screens. When you return to the test menu, turn off the self-test switch.

These are the screens in the operator screens submenu:

- Coin Options
- Game Options
- Game Statistics
- Histogram of Game Times
- Error Count
- Games Played by Day and Hour

Coin Options

The coin options are the first operator screen (see Figure 2-5). To move and choose in this screen, do the following:

- To move up or down the list, press the right or left coin switch.
- To change a setting, press the abort button and either coin switch.
- To return to the setting originally on the screen, press the abort button and turn the key.
- To exit the screen, turn the key.

You can change an option when it is enclosed in the blue box. The default setting of each option is green. The other settings are blue when you select that option. (The other settings are white when the option is *not* selected.) The possible settings are shown in Table 2-2.

The coin options are explained below.

- *Coin Mode* is the number of coins required for one credit.
- *Right Mech Multiplier* is the number of coins each coin counts as in the right coin mechanism.
- *Left Mech Multiplier* is the number of coins each coin counts as in the left coin mechanism.
- *Bonus Adder* lets you choose bonus coins, no bonus, or free play.

Table 2-2 Coin Option Settings

Option	Available Settings
Coin Mode	1 coin/1 credit 2 coins/1 credit 3 coins/1 credit ♦ 4 coins/1 credit
Right Mech Multiplier	1 coin counts as 1 coin ♦ 1 coin counts as 4 coins 1 coin counts as 5 coins 1 coin counts as 6 coins
Left Mech Multiplier	1 coin counts as 1 coin ♦ 1 coin counts as 2 coins
Bonus Adder	No bonus adder ♦ 2 coins give 1 extra coin 4 coins give 1 extra coin 4 coins give 2 extra coins 5 coins give 1 extra coin 3 coins give 1 extra coin Free Play

♦ *Manufacturer's recommended settings*



Figure 2-5 Coin Options Screen

Game Options

Use this screen to set the game difficulty and various other operator options explained below. The screen is shown in Figure 2-6, and a table of the options is shown in Table 2-3.

To move and choose in this screen, do the following:

- To move up or down the list, press the right or left coin switch.
- To change a setting, press the abort button and either coin switch.
- To return to the setting that was originally on the screen, press the abort button and turn the key.
- To exit the screen, turn the key.

You can change an option when it is inside the blue box. The default setting of each option is green. The other settings are blue when the option is selected. (The other settings are white when the option is *not* selected.)

- *Game Difficulty* sets the game difficulty for the drivers. The settings are shown in Table 2-3. The *custom* setting lets you choose the actual amount of time the players receive. We suggest you use the preset factory setting (easy, medium, hard, and very hard), not the custom setting.
- *Champ Lap Qualification* sets the difficulty of qualifying for the championship lap.
- *Steering During Attract Mode* allows you turn the movement of the steering wheel on or off while the simulator is in the attract mode.
- *Steering Wheel Force* is the amount of force exerted by the steering assembly motor on the steering wheel.
- *High Score Name Censor* controls a program to censor names entered on the high score table. The program deletes letters in possibly objectionable words in the high score table.
- *Clear High Score Table* clears the high score table at the time chosen. You can choose not to clear the table, clear it now, clear every week, or clear every two weeks. If you choose clear every week or clear every two weeks, the table is cleared when the simulator is turned on after Wednesday midnight every week or every second week. Be sure your simulator clock is set correctly so the table clears at the right time.
- *Signs and Gauges* allows you to choose whether the signs and gauges are displayed in kilometers or miles.



Figure 2-6 Game Options Screen

Table 2-3 Game Option Settings

Option	Available Settings	
Game Difficulty	Easy	Medium ♦
	Hard	Very Hard
	Custom	
Champ Lap Qualification	Easy	Medium ♦
	Hard	Very Hard
Steering During Attract Mode	On ♦	Off
Steering Wheel Force	Very Light	Light
	Medium	Stiff ♦
High Score Name Censor	Easygoing ♦	Strict
Clear High Score Table	Don't Clear	Clear Now
	Clear Every Week	
	Clear Every 2 Weeks ♦	
Signs and Gauges	Miles per Hour ♦	
	Kilometers per Hour	
Reverse Gear	Disabled ♦	Enabled

♦ *Manufacturer's recommended settings*

Table 2-4 All Screens Appearing in the Self-Test

Screen	Use
Automated Self Test	
Program RAM and ROM	Tests the program RAM and ROM.
Automated Self-Test Results	Shows results of the program RAM and ROM, VRAM, color RAM, MSP DRAM, ADSP PCB, and sound PCB tests.
Test Menu Screens	
Instructions for Test Menu	Information about using the test menu.
Test Menu	List of available tests and information you can choose.
Operator Screens	
Coin Options	Sets the coin options.
Game Options	Sets the game options, controls the high score table and steering in the attract mode.
Custom Game Options	Use preset game options first.
Statistics	Shows game statistics.
Histograms	Shows game histograms, and number of games by length of play.
Error Count	Shows the error count from the PC boards. Used by the factory for debugging.
Games Played by Day and Hour	The simulator clock must be set correctly to get maximum use from this screen.
Set Controls	Use if you are having any control problems or replace or repair a control or a PCB.
Initialize Pot Inputs	Initializes all the simulator potentiometers.
Initialize Steering Limits	Sets the steering limits.
Initialize Shifter Limits	Sets the shifter limits.
Initialize Seat Limits	Sets the seat movement limits.
Initialize Force Brake	Sets the limit on the force on the brake.
Control Inputs	Check this screen *regularly* to make sure your controls are operating correctly.
Monitor Test Patterns	Use these screens to check the performance of your video display.
Color Bars	Shows the video display colors.
Monitor Brightness	Shows the brightness adjustment.
Grey Scale	Shows the grey scale of the video display.
B/W Dots	Shows convergence and focus of the video display.
B/W Grid	Shows convergence and focus of the video display.
Diagonal Lines	Shows linearity of the video display.
Full Screen Grey	Shows the color purity of the video display.
Full Screen White	Shows the color purity of the video display.
Full Screen Red	Shows the color purity of the video display.
Full Screen Green	Shows the color purity of the video display.
Full Screen Blue	Shows the color purity of the video display.
Monitor High Voltage Test	Checks the regulation of the high voltage to the video display.
Scrolling Test	Checks the scrolling mechanism of the GSP microprocessor.
Set Clock	Set the time so that you can get maximum use from the *Games Played By Day and Hour* screen and so that the high score table reset occurs at the right time.
Disable Broken Controls	If you cannot repair a broken shifter, brake, clutch or seat potentiometer immediately, you can disable that control's circuit so you can continue to operate the game. *Repair the broken control as soon as possible. Use this screen only as a temporary measure.*
Special Functions	Use this screen for tests of the controls, PCBs, and microprocessors.
Main Board GSP Tests	Use this screen if you have a VRAM failure in the automated self-test.
VRAM Simple Test	Checks for bad VRAMs in the GSP microprocessor system.
VRAM Verify Test	Tests all the VRAM GSP memory.
VRAM Complete Test	Completely tests all VRAM.

Table 2-4 All Screens Appearing in the Self-Test, Continued

Screen	Use
Color RAM	Tests the color RAM.
VRAM Shift Register Test	Checks the VRAM shift register.
Main Board MSP Tests	Use this screen if the MSP system fails the automated self-test.
MSP Verify Test	The MSP microprocessor tests the DRAMs.
MSP Complete Test	The 68010 tests the DRAMs.
Main Board Controls	Shows much the same information as the *Control Inputs* screen, but has additional tests for the steering wheel, shifter, and line voltage calibration.
Pots: 8 Bit	Shows the gas pedal, clutch pedal, seat movement, shifter movement, steering wheel movement, line voltage and the shifter force input to the main PCB.
Pots: 12 Bit	Shows the steering wheel movement and the brake force input to the main PCB.
Steering Wheel	Use if the steering wheel does not work. See the steering wheel flow charts in Chapter 3 for information about their use.
Send Force	Use this test as directed in the flowchart in Chapter 3.
Sine Wave	Sends a sine wave force to the motor amplifier PCB.
Square Wave	Sends a square wave force to the motor amplifier PCB.
Triangle Wave	Use this test as directed in the flowchart in Chapter 3.
Closed Loop Test	Sends a force to the motor amplifier PCB simulating a simple spring.
Line Voltage Calibration	Calibrates the line voltage display in the self-test.
Opto Test	For factory use only.
Life Test	For factory use only.
Shifter	Use this screen if the shifter does not work right.
Main Board ROM Checksums	Use this test if the program ROMs fail the automated self-test.
Main Board ZRAM Tests	Check the ZRAMs. Use this if all the controls are operating erratically or the statistics are not kept correctly.
ADSP Board Tests	Use this test if the ADSP board fails the automated self-test.
ADSP RAM	Tests the RAM on the ADSP PCB.
2100 Test	Tests the response of the 2100 integrated circuit on the ADSP PCB.
ADSP IRQs	Tests if the ADSP system can generate interrupts.
ROM Checksums	Tests the graphic ROM on the ADSP PCB.
Scope Loops	Shows hardware diagnostic tests for the ADSP board.
Seq Input Memory Reads	Reads the sequential input memory.
Seq Input Mem ADR Writes	Writes to the sequential input memory.
Seq Output Writes, Buf 1	Writes to the Sequential Output Memory 1.
Seq Output ADR Writes, Buf 1	Writes the address to the Sequential Output Memory 1.
Seq Output Writes, Buf 2	Writes the address to the Sequential Output Memory 2.
Seq Output ADR Writes, Buf 2	Writes the address to the Sequential Output Memory 1.
Toggle MPAGE	The MPAGE at 7L, Pin 5, alternates between 0 and 1.
Toggle XPAGE	The XPAGE at 6K, Pin 5, alternates between 0 and 1.
Sound Board Tests	Use these tests if the sound board fails the automated self-test.
Sound Board Self-Test	Tests the sound program RAM and ROM, COMRAM and the 320 RAM.
Play Sounds	Choose and hear game sounds.
Sound Board ROM Checksums	Tests the sound PCB ROMs.
Sound Board Program RAMs	Tests the sound PCB program RAMs.
Sound Board Program ROMs	Tests the sound PCB program ROMs.
COMRAM	Tests the sound PCB communication ROM.
320 RAM	Tests the sound PCB 32010 program RAM.

- *Reverse Gear* allows reverse gear to be enabled. The simulator is shipped with reverse disabled because it is not required when driving. However you can add reverse, if you wish, by doing the following steps:

  1. Change the setting to *enabled.*
  2. Loosen the self-locking screw in the shifter knob and take off the knob. See Figure 3-12, *Maintaining the Shifter.*
  3. Remove the four tamperproof screws that hold the boot cover plate on the shifter case. Lift off the boot and the cover plate.
  4. Remove the shifter gate.
  5. Turn it over. Remove the socket-head screw and washer on the end of the latch nearest the spring.
  6. Leave the latch on the shifter to provide resistance against shifting into reverse accidentally.

Custom Game Options

This screen is shown in Figure 2-7. Choose *Custom* under *Game Difficulty* to see this screen. In the *Custom* setting, you can choose the actual amount of time each driver is given. You can select different times for each individual lap in this option.

The actual times for easy, medium, hard, and very hard game difficulty settings are also shown in the custom settings. For example, if you have chosen the medium setting in *Game Difficulty,* then the custom screen appears as shown in Figure 2-7.

NOTE

Always use the preset Game Difficulty *settings before you use the settings of the* Custom *game options.*

To move and choose in this screen, do the following:



Figure 2-7 Custom Game Options Screen

Table 2-5 Custom Game Option Settings

Option	Available Settings (in Seconds)
Initial Time	72 76 78 Very Hard 80 82 84 Hard 86 88 90 Medium 92 94 96 Easy 98 100 102
First Extended Time	37 38 39 Very Hard 40 41 42 Hard 43 44 45 Medium 46 47 48 Easy 49 50 51 52
Second Extended Time	37 38 39 Very Hard 40 41 42 Hard 43 44 45 Medium 46 47 48 Easy 49 50 51 52
Extended Time After Second	37 38 39 Very Hard 40 41 42 Hard 43 44 45 Medium 46 47 48 Easy 49 50 51 52

- To move up or down the list, press the right or left coin switch.
- To change a setting, press the abort button and either coin switch.
- To return to the setting that was originally on the screen, press the abort button and turn the key.
- To exit the screen, turn the key.

You can change an option when it is inside the blue box. The default setting of each option is green. The other settings are blue when the option is selected. (The other settings are white when the option is *not* selected.) All of the possible settings are shown in Table 2-5.

The custom game options are explained below.

- *Initial Time* is the amount of time always given for one driving session.
- *First Extended Time* is the amount of time given if the driver crosses the finish line before the initial time is up.
- *Second Extended Time* is the amount of time given if the driver crosses the finish line before the time is up on his second lap.
- *Extended Time After Second* is the amount of time given when the driver crosses the finish line before the time is up after the first two laps.

Statistics

The statistics screen is shown in Figure 2-8. The statistics are collected from the last time the statistics screen was cleared. Write this information on the statistics sheet in the back of this manual to help you maximize your profit.

To move to the next screen, just turn the key. To clear the statistics, press and hold the abort button and turn the key at the same time.

The statistics the simulator collects are explained below.

- *Left Coins* shows the number of coins counted in the left coin mechanism.
- *Right Coins* shows the number of coins counted in the right coin mechanism.
- *Aux Coins* shows the number of times the auxiliary coin switch (inside the coin door) is pressed.
- *Idle Mins* shows the number of minutes the simulator has been idle.
- *Active Mins* shows the number of minutes the simulator has been played.
- *Xtnded Plays* shows the total number of times drivers received at least one additional lap.
- *1-X Games* shows the number of times drivers crossed the finish line one time and did not complete a second lap.
- *2-X Games* shows the number of times drivers crossed the finish line two times and did not complete a third lap.
- *N-X Games* shows the number of times drivers crossed the finish line three times and continued to drive.
- *Auto Games* shows the number of times drivers chose the automatic transmission instead of the shifter.
- *Error Count* shows the number of errors counted in the erasable memory. If you have more than 75 errors, you should have your simulator serviced by a qualified service technician.
- *Total Games* shows the number of unique games played, regardless of how many additional laps each driver received.
- *Laps by Track* is numbers of laps, completed or not, on each track. The first number is the common track at the beginning, before the driver chooses the stunt track or the speed track. The second number is the speed track and the third number is the stunt track. See the example after *No X Games by Track* for more information.



Figure 2-8 Statistics Screen

- *Xtnded Plays by Track* is the number of additional laps given to drivers if they complete a track before the time allotted. (These laps, when added together, are the same as the number of laps in *Xtnded Plays*.)

  These additional laps do not need to be completed to be counted. The first number is the common track at the beginning, before the driver chooses the stunt track or the speed track. The second number is the speed track and the third number is the stunt track. Use this to find out which track drivers are choosing and driving well on. See the example after *No X Games by Track* for more information.

- *No X Games by Track* is the number of times the drivers did not get extended games on either track. If these numbers are very high (in proportion to the *Laps by Track* statistic), then the *Game Difficulty* setting may be too hard. The first number is the common track at the beginning, before the driver chooses the stunt track or the speed track. The second number is the speed track and the third number is the stunt track.

The following examples show how the *Laps by Track*, *Xtnded Plays by Track*, and *No X Games by Track* statistics are counted.

If a driver chooses the speed track and completed it before the time allotted, started driving the second lap on the speed track, but ran out of time, and did not put in any more coins, you would see the following statistics:

Laps By Track	0	2	0
Xtnded Plays by Track	0	1	0
No X Games by Track	0	0	0

If a second driver chooses the stunt track and did not complete the track before time was up, his statistics are added to the first driver's as follows:

Laps By Track	0	2	1
Xtnded Plays by Track	0	1	0
No X Games by Track	0	0	1

- *Champ Laps* is the number of times drivers qualified to race a championship lap.
- *Wins* is the number of times drivers won championship laps.
- *Inst Rpls* is the total number of instant replays. If this number is very high, the drivers should probably be reminded they will be most successful if they drive the Hard Drivin' simulator like a real car.
- *Rpl Abort* is the number of times the drivers pressed the abort button to cut the instant replay short.
- *Rpl Secs* is the total number of seconds the simulator is in the replay mode.
- *Total Credits* is calculated by multiplying the coins by the credit setting you chose in *Coin Mode*.
- *Avg Time/Credit* is the average amount of time, in seconds, that each credit gave.

Histogram

The histogram screen shows the length of driving time in seconds and the how many times the simulator was driven. The screen is shown in Figure 2-9. Write these numbers on the statistics sheet in the back of this manual to help you maximize your profit.

To move to the next screen, turn the key. To clear the histograms, press and hold the abort button and turn the key at the same time.



Figure 2-9 Histogram Screen

Error Count

This screen shows the error count on the PC boards. If you call Atari Game Customer Service, the numbers on this screen may help Customer Service personnel troubleshoot your problem.

Games Played By Day and Hour

This screen, illustrated in Figure 2-10, shows the number of games played every hour in each day. The information on this screen relies on the simulator clock being set correctly. (The clock time is shown on the bottom of the test menu screen. If the time is incorrect, follow the instructions in the *Set Clock* section of this chapter to set the clock.)

Write the simulator driving information on the statistics sheet in the back of this manual to help you maximize your profit.

To clear the screen, press and hold the abort button and turn the key at the same time.



Figure 2-10 Games Played by Day and Hour Screen

Set Controls Screens

If you have problems with a control in the simulator, use the *Set Controls* screens before doing any troubleshooting or repairs. These screens allow you to set the beginning and ending points of the control input to the main PCB. Often, resetting these points will solve the problem you have. If resetting does not solve the problem, then check the *Control Inputs* screen, described below.

If you repair a control, then when you put the control back in the simulator, go through the *Set Control* screens. If you install a new board or a new control, you must go through the *Set Control* screens too.

The first screen of the *Set Controls* screens is shown in Figure 2-11.



Figure 2-11 First Set Controls Screen

NOTE

If you take a control out of the simulator for repair or maintenance, you must go through all the Set Controls *screens after you replace it. If you do not, the simulator will not operate correctly.*

After you choose *Set Controls*, simply do what the screens say. You must reset all the controls after you start the screens. The first screen initializes all potentiometers in the simulator. (The steering wheel, shifter, seat, gas, and brake have potentiometers.) The next screens initialize the limits for the steering wheel, shifter, seat, and brake. The numbers on each screen are for factory use.

NOTE

When you initialize the brake, the instructions say to "step firmly" on the brake. Do not stomp on the brake or gently press it. Either way sets the brake limits incorrectly and drivers will be frustrated when they use the brake.

Control Inputs Screen

Check this screen as part of your regular maintenance to be sure your controls are operating correctly.

The *Control Inputs* screen is shown in Figure 2-12. This screen shows the voltage inputs from the control potentiometers to the A/D converter circuits on the main PC board. As you use a control, the line length on the screen changes, showing the change in the voltage input from the potentiometer. If the line length does not change, you have a problem.

If you have a problem, first go through the *Set Controls* screens to see if that solves the problem. Check the results on the *Control Inputs* screen. If using the *Set Controls* screens does not solve the problem, check Chapter 3 for troubleshooting and repair information.

The first control on the screen is the *Steering Wheel*. This line shows the movement of the steering wheel. As you turn the steering wheel counterclockwise, the line should disappear.

The second line is *Brake Force* which measures the force with which the brake is pushed. As you push harder and harder on the brake, its line should disappear.

In both of these lines, 0 Volts appears as no line or a short line on the screen, and 5 Volts appears as almost eight full lines on the screens.

Below these two lines are the gas pedal, clutch pedal, seat movement, shifter (front to back), shifter (left to right), steering wheel, line voltage, and shifter force. (The steering wheel movement is checked with two lines.) As you use the controls, the lines should become longer and shorter. If the line does not move, then see Chapter 3 for more information. (The line voltage varies at 60 Hz. You cannot test the line voltage.)

For these controls, 0 Volts input appears as no line or a short line on the screen and 5 Volts appears as a line halfway across the screen.

At the bottom of the screen, you can check the left and right coin mechanism, the auxiliary coin switch



Figure 2-12 Control Inputs Screen

behind the coin door, and the seat magnet. Use the seat magnet test to determine whether the seat is locking as it should and if the magnet is good.

If the seat has not been working correctly, but does lock in this test, the switch probably should be repaired or replaced. If the seat does *not* lock, then your problem is probably the harness or the magnet.

Monitor Test Patterns

Use this item to see the thirteen screens for checking the video display, the color RAMs, the GSP, which controls the video RAMs (VRAMs), and the video output. To move through the screens, press the coin switches.

- *Color Bars* screen shows these colors from left to right: white, yellow, light blue, green, purple, red, blue, and grey. If the colors are incorrect, see your video display manual for adjustment procedures.
- *Monitor Brightness* checks the adjustment of the video display brightness.
- *Grey Scale* screen shows a white line on the left, and a grey scale showing black on the left.
- *B/W Dots* screen can be used to check convergence and focus.
- *B/W Grid* screen, shows a black background and a white grid pattern to check convergence. The grid lines should be straight within 3.0 mm. If you need to adjust the convergence, see the video display manual included with the simulator.
- *Diagonal Lines* screen can be used to check video display linearity.
- *Full Screen* colors test the color purity of the color RAMs and the display. The test displays a grey, white, red, green, and then blue screen. Each screen should be a rectangle of color, with no curving at the corners and no lines in the raster. If it does not, see your video display manual included with the simulator for adjustment procedures.
- *Monitor High Voltage Test* screens switch between a white screen and a grey screen. If the high voltage to the display is regulated properly, the sides of the screen will fluctuate about 3/4 inch from the white to the grey screen.
- *Scrolling Test* screen checks the scrolling mechanism in the GSP.

Set Clock Screen

Choose this item if you want to set the clock, turn the clock on, or turn it off. The clock should be set correctly so the statistics on the operator screen *Games Played by Day and Time* will be right.

The time on the clock also determines when the high score table is cleared. If you set the *Clear High Score Table* option in the *Game Options* screen to clear every week or every other week, then the high score table is cleared the first time the simulator is turned on after Wednesday midnight.

You may need to turn on the clock if the simulator has a program crash. Turn off the clock only if you plan to store the simulator more than six months. (The clock has a lithium battery that should last more than five years in normal use.)

To turn off the clock, choose *Clock Off* from the clock submenu, shown in Figure 2-13. To turn on the clock, choose *Start Clock* from the menu. In about two seconds, the clock starts.

If the clock is losing or gaining time, then use *Clock Faster* or *Clock Slower* to adjust the calibration of the clock.

Choose the item you need from the menu by using either coin switch. Change the setting by turning the key until you see the correct time.

The items on the clock menu are explained below.

- *Exit* returns you to the test menu.
- *Inc Hours* changes the hour setting ahead.
- *Inc Minutes* changes the minute setting ahead.
- *Inc Seconds* changes the second setting ahead.
- *Inc Day* changes the day of the week (for example, Monday or Tuesday) setting ahead.
- *Inc Month* changes the month setting ahead.



Figure 2-13 Set Clock Screen

- *Inc Date* changes the date setting ahead.
- *Inc Year* changes the year setting ahead.
- *Faster Clock* changes the calibration setting ahead. Each increase in the calibration setting makes the clock run about 5 seconds faster per month.
- *Clock Off* turns the clock off.
- *Dec Hours* changes the hour setting back.
- *Dec Minutes* changes the minute setting back.
- *Dec Seconds* changes the second setting back.
- *Dec Day* changes the day of the week (for example, Monday or Tuesday) setting back.
- *Dec Month* changes the month setting back.
- *Dec Date* changes the date setting back.
- *Dec Year* changes the year setting back.
- *Slower Clock* changes the calibration setting back. Each decrease in the calibration setting makes the clock run about 5 seconds slower per month.
- *Start Clock* starts the clock.

Disable Broken Controls Screen

Use this screen, shown in Figure 2-14, if you have a broken shifter, brake pedal, clutch pedal, or seat potentiometer and cannot repair it immediately. Before you use this screen use the *Set Controls* screens and read the information about the control in Chapter 3.

Disable these controls *only* as a *temporary* measure so you can continue to operate the simulator while waiting for parts. If you disable a control, the realistic driving feel of that control is lost. *Earnings could drop.*

When you disable a control, the control circuit is overridden, and the simulator compensates for the loss of the control. If you have disabled a control, remember to choose *working* after you repair it so the control works right.



Figure 2-14 Disable Broken Controls Screen

Special Functions Screens

Use the items on this screen, shown in Figure 2-15, if a system or board failed the program RAM and ROM test or the board and microprocessor test in the automated self-test. Also use this screen if you have problems with the steering wheel, the shifter, or if the clock settings or the statistics are erratic. A short summary of when to use these items is shown in Table 2-6.

The *Special Functions* items are explained below.

- *Exit* returns you to the test menu.
- *Main Board GSP Tests* should be used if you get the message *Bad GSP VRAM* or *Bad GSP Color RAM* in the automated self-test. This screen has six tests you can use.
- *Main Board MSP Tests* should be used if you get the message *Bad MSP DRAM* in the automated self-test. This screen has two tests you can use.
- *Main Board Controls* gives you most of the same information as provided in the *Control Inputs* screen plus five steering wheel tests, a line voltage calibration screen, and additional shifter tests. (All controls are "main board" controls.)
- *Main Board ROM Checksums* should be used if you get the message *Bad Program ROM* in the automated self-test. This tests the program ROMs individually and shows the results on the screen.
- *Main Board ZRAM Tests* should be used if your controls settings are changing or erratic even though



Figure 2-15 Special Functions Screen

Table 2-6 When to Use the Special Function Items

Item	When to Use
Main Board GSP Tests	If you see the message *Bad GSP VRAM* or *Bad GSP Color RAM* in the automated self-test.
Main Board MSP Tests	If you see the message *Bad MSP DRAM* in the automated self-test.
Main Board Controls	If you have control problems.
Main Board ROM Checksums	If you see the message *Bad Program ROM* in the automated self-test.
Main Board ZRAM Tests	If your controls settings are changing even though you have used the *Set Controls* screen or if the statistics are not being kept correctly.
ADSP Board Tests	If you see any message other than *ADSP Board OK* for the ADSP PC board test in the automated self-test.
Sound Board Tests	If you see the message *Bad Sound Board* in the automated self-test.

you used the *Set Controls* screen. Also use these tests if you suspect the simulator is not keeping the statistics correctly.

- *ADSP Board Tests* should be used if you get any message other than *ADSP Board OK* for the ADSP board test in the automated self-test. This screen has three tests and an ADSP ROM checksum test. It also has eight "scope loop" tests for factory use only since they require schematics and an oscilloscope.
- *Sound Board Tests* should be used if you get the message *Bad Sound Board* in the automated self-test. However, many of the sound board tests are for factory use only since they require schematics and an oscilloscope.

Main Board GSP Tests

If the automated self-test reports bad VRAMs, choose *Main Board GSP Tests* and the screen in Figure 2-16 appears.

First run the VRAM simple test. It gives the location of the bad VRAMs. If the VRAMs pass this test, but you think the simulator has a bad VRAM, run the VRAM verify test.

- *VRAM Simple Test* is the same test that is run in the automated self-test. It is run by the 68010 through the GSP interface and detects open or shorted address or data lines or missing parts. The results are displayed on-screen with a picture showing the VRAM section of the main PC board. The good parts are shown in green and the bad parts are shown in red. If an entire section appears in red, the problem may be with a buffer associated with that section. The test takes about 30 seconds.
- *VRAM Verify Test* is a complete memory test run by the GSP. The results are reported on the screen like in the simple test. The test takes about three minutes to run.

  Since the verify test is run by the GSP program in the VRAMs, a single bad VRAM can cause the GSP program to crash. When this happens, the 68010 microprocessor reports that all the VRAMs are bad, although probably only one VRAM is bad. You must run the VRAM complete test (described below) to find out which VRAM is bad.

  If the VRAM verify test fails, but the VRAM simple test shows the VRAMs are good, you should run the VRAM complete test.

  If the verify test runs and reports that the VRAMs are good, then the VRAMs should be good.
- *VRAM Complete Test* is a complete memory test run by the 68010 through the GSP interface. Because the 68010 runs the test, a single bad VRAM does not cause the test to report all the VRAMs are bad (as it does the verify test).

  Any VRAMs that are bad are shown on the screen at the end of the test. This test takes at least 22 minutes to run.
- *Test VRAM for Display Errors* checks for video display problems.



Figure 2-16 GSP Tests Screen

- *Color RAM* is the same test that is performed in the automated self-test. It tests the color RAM and reports the results.
- *VRAM Shift Register Test* checks the shift register part of the video RAMs.

Main Board MSP Tests

Use this item if the MSP microprocessor fails the microprocessor and board tests performed by the automated self-test.

When you choose *Main Board MSP Tests* the screen in Figure 2-17 appears. Run the MSP verify test, and if necessary, the MSP complete test.

The items in the MSP test screen are explained below.

- *Exit* returns you to the test menu.
- *MSP Verify Test* tests the MSP DRAMs. Use this test if the MSP microprocessor failed the microprocessor and board tests. The test is run by the MSP program in the DRAMs so almost any DRAM problem causes an error message to appear on the screen.

  In twenty seconds, the test displays the results as a picture of the main PC board with the good parts shown in green, the bad parts shown in red, and the integrated circuits that are not DRAMs and *not* tested shown in blue. If two DRAMs are shown in red, then the problem could be the buffer associated with the pair.

  If this test does not isolate the MSP problem, then try the MSP complete test.
- *MSP Complete Test* is run by the 68010 through the MSP interface. It tests the DRAMs and can detect nearly any problem that could develop. The test takes 2 minutes or longer, if it finds errors.

  The test displays the results as a picture of the main PC board with the good parts shown in green, the bad parts shown in red, and the integrated circuits that are not DRAMs and *not* tested shown in blue. If two VRAMs are shown in red, then the problem could be the buffer associated with the pair.



Figure 2-17 MSP Tests Screen

Main Board Controls

This screen provides more information about the controls than is shown in the *Control Inputs* screen. The items on the screen are described below and shown in Figure 2-18. After you choose any item on this screen and go to that item, you can return to this screen by turning the key.

The *Pots: 8 Bit* and *Pots: 12 Bit* screens have the same information as the the *Control Inputs* screen. They show the voltage inputs from the control potentiometers to the A/D converter circuits. As you use a control, the line on the screen changes as the voltage input changes. If the voltage does not change, you should check that control according to the procedures in Chapter 3, *Maintenance and Troubleshooting*.

- The controls under the heading *Pots: 8-Bit* feed into the 8-Bit A/D converter circuit on the main PCB. (See Figure 2-19.) These controls are the gas pedal, clutch pedal, seat movement, shifter (front to back), shifter (left to right), steering wheel position, and shifter force. (The steering wheel position is also checked on the 12-bit A/D converter circuit. If the numbers do not match, the steering wheel force is turned off.)

  As you use the controls, the lines should become longer and shorter. If the line does not move, then you have a problem with the control and you should see the information about the control in Chapter 3.

  In these controls, 0 Volts appears as no line or a short line and 5 Volts appears as a line halfway across the screen.



Figure 2-18 Main Board Controls Screen



Figure 2-19 Pots: 8-Bit Screen

- In the *Pots: 12-Bit* screen, shown in Figure 2-20, *Steering Wheel* shows the position of the steering wheel. The steering wheel location input is sent to both the 12-bit and the 8-bit A/D converter circuits and is compared. If the numbers do not match, the simulator turns the steering motor force off.

  Brake Force shows the force on the brake pedal. As you push harder and harder on the brake, the line disappears. If the line does not move, then you have a problem with the brake, the connection, or the A/D Converter circuit on the main PCB.

  In the steering wheel and the brake force lines, 0 Volts appears as no line or a short line and 5 Volts appears as almost eight full lines drawn across the screen.

  (The two lines on the bottom of this screen are not used.)

- *Steering Wheel* screen is explained below and shown in Figure 2-21.
- *Shifter* screen is described below and shown in Figure 2-23.
- *Duart* does not apply to this simulator.



Figure 2-20 Pots: 12-Bit Screen

Steering Wheel Submenu

Use these item if you believe you have a problem with the steering assembly or the motor amplifier assembly. The screen is shown in Figure 2-21. The section *Steering Assembly* in Chapter 3 explains how to use these tests.

CAUTION

Do not service the motor amplifier assembly, which is mounted on the left side of the cabinet. The assembly contains high voltage.

If you have a problem with the motor amplifier assembly return the entire assembly to your distributor for replacement.

To move through the menu and the screens, use the coin switches. To exit a screen, push both coin switches down.

- *Exit* returns to the *Main Board Controls* screen.
- *Send Force* sends a steady force to the motor amplifier PCB. See Figure 2-22.
- *Sine Wave* sends a sine wave force to the motor amplifier PCB. This screen is similar to Figure 2-22.
- *Square Wave* sends a square wave force to the motor amplifier PCB. This screen is similar to Figure 2-22.
- *Triangle Wave* sends a triangle wave force to the motor amplifier PCB. This screen is similar to Figure 2-22.
- *Closed Loop Test* reads the steering wheel position and sends a force to the motor amplifier PCB to simulate a simple spring.
- *Line Voltage Calibration* can be used to calibrate the simulator voltage reading to the line voltage



Figure 2-21 Steering Wheel Submenu Screen

reading. Put a voltmeter on the line, then set the voltage on this screen to match.

- *Opto Test* is a test used by manufacturing.
- *Life Test* is a test used by manufacturing quality assurance.

CAUTION

Do not use the Life Test. *It is used only in the factory for testing of potentiometers. If you leave the simulator in this test for a long time, you can destroy the potentiometer on the steering assembly.*



Figure 2-22 Send Force Screen

Shifter Test Screen

Use this screen if you have a problem with the shifter. Before you use the screen, see Figure 3-11, the shifter flowchart, to find out how to use the tests and settings on this screen. If you need to repair the shifter or the shifter PCB, see the shifter section in Chapter 3 for further information. The shifter screen is shown in Figure 2-23.

Under shifter outputs, you can see the voltage outputs change as you push the shifter from left to right and front to back. These numbers show the change in the voltage input from the shifter potentiometers to the 8-bit A/D converter circuit on the main PCB.

The *X-Pot* number changes as you move the shifter handle from left to right. The *Y-Pot* number changes as you move the shifter front to back. The *Strain Gage* number should be 90, and when you push the shifter forward into first or third gear, the number should go higher. It changes quickly, so watch carefully.

Under *Shifter Inputs*, you can exit the screen by turning the key, or you can press the coin switches to increase and decrease the *SG Bias* (strain gauge bias)



Figure 2-23 Shifter Screen

and shifter *Brake Force*. (This brake is the internal shifter brake, not the simulator brake.) Change the inputs to the strain gauge and the brake force as directed in the shifter flowchart in Chapter 3.

Main Board ROM Checksums

This screen checks the main PC board program ROMs for errors. Use this test if you have a bad program ROM message in the automated self-test or you suspect program ROM failure. To exit this screen, turn the key.

When the checksum test is complete, a hexadecimal number follows each ROM as shown in Figure 2-24. The first two digits in each hexadecimal number can be any number, but the last two digits must be the ones shown in Figure 2-24.

If the digits are all zeroes, the ROM is not on the board. Otherwise, if the last two digits are different than Figure 2-24, then the ROM is bad.



Figure 2-24 ROM Checksums Screen

Table 2-7 shows where the ROMs checked in this test are located on the main PC board.

Table 2-7 Program ROM Locations

Screen Designation	PCB Location	Screen Designation	PCB Location
ROM 0 H	210 R	ROM 0 L	200 R
ROM 1 H	210 S	ROM 1 L	200 S
ROM 2 H	210 T	ROM 2 L	200 T
ROM 3 H	210 U	ROM 3 L	200 U
ROM 4 H	210 V	ROM 4 L	200 V
ROM 5 H	210 W	ROM 5 L	200 W
ROM 6 H	210 X	ROM 6 L	200 X
ROM 7 H	210 Y	ROM 7 L	200 Y

Main Board ZRAM Test

This test checks the non-volatile RAM where the simulator statistics and control set-up values are kept. Check the ZRAMs if you think the statistics are incorrect. Also use this test if the control settings are changing even though you have recently set them with the *Set Controls* screens.

If the simulator loses power or is reset while it is in this test, then the statistics and the control settings will be lost. If this happens, use the *Set Controls* item from the main menu to reset the controls. The statistics cannot be restored.

ADSP Board Tests

Use this item if the ADSP PC board fails the microprocessor and board tests performed in the automated self-test.

When you select *ADSP Board Tests* from the test menu the screen in Figure 2-25 appears. The items on the screen are explained below.



Figure 2-25 ADSP Board Tests Screen

- *Exit* returns to the test menu.
- *ADSP RAM* tests the memory on the ADSP PC board. The test takes a few minutes to run. It displays a picture of the ADSP PC board with the good parts shown in green, the bad parts shown in red, and the integrated circuits that are not RAMs and not tested shown in blue. If two RAMs are red, then the problem could be the buffer associated with the pair.
- *2100 Test* checks the response of the 2100 integrated circuit on the ADSP PC board by copying data from one location to another using a 2100 program.
- *IRQ Test* checks if the ADSP can generate interrupts for the 68010.
- *ROM Checksums* tests the graphic ROMs on the ADSP PC board. When the checksum test is complete a hexadecimal number follows each ROM as shown in Figure 2-26. The first two digits in each hexadecimal number can be any number, but the last two digits must be the ones shown in Figure 2-26. If the last two numbers are different, then the ROM is bad or it is not on the board.
- *Scope Loops* shows a menu with hardware diagnostic tests to be used with an oscilloscope. The tests are shown in Table 2-8.



Figure 2-26 ADSP ROM Checksums Tests Screen

Sound Board

Use these tests if the sound PC board failed the microprocessor and board tests in the automated self-test.

If the sound PC board failed the test, select this item from the test menu and Figure 2-27 appears. Many of the tests require an oscilloscope and schematics. These are indicated on the list below. The tests are explained below.

Table 2-8 ADSP Scope Loop Diagnostic Tests

Test	Function
Seq Input Memory Reads	Reads the sequential input memory. The counters 9L, 9K, 9J, and 9H are incremented in a binary sequence from SRA0 to SRA15.
Seq Input Mem ADR Writes	Writes to the sequential input memory. The data written to the counters 9L, 9K, 9J, and 9H is incremented in a binary sequence from SRA0 to SRA15.
Seq Output Writes, Buf 1	Writes to the Sequential Output Memory 1. The outputs of the counters 4D, 4C, 4B, and 4A are incremented in a binary sequence from ASA0 to ASA12.
Seq Output ADR Writes, Buf 1	Writes the address to the Sequential Output Memory 1. Data written to the counters 4D,4C, 4B, and 4A is incremented in a binary sequence from ASA0 to ASA12.
Seq Output Writes, Buf 2	Writes the address to the Sequential Output Memory 2. The outputs of the counters 4E, 4F, 4H, and 4J are incremented in a binary sequence from BSA0 to BSA12.
Seq Output ADR Writes, Buf 2	Writes the address to the Sequential Output Memory 1. Data written to the counters 4D, 4C, 4B, and 4A is incremented in a binary sequence from ASA0 to ASA12.
Toggle MPAGE	The MPAGE at 7L, Pin 5, alternates between 0 and 1.
Toggle XPAGE	The XPAGE at 6K, Pin 5, alternates between 0 and 1.

- *Exit* returns to the test menu.
- *Play Sounds* takes you to the *Requesting Sound Screen*. Follow the instructions on the screen to hear the simulator sounds.
- *Self-Test* checks the sound program ROM and RAM, COMRAM, and 320 RAM.
- *SD ROM Checksums* tests the ROMs holding the waveform data. The screen appears in Figure 2-28. It shows the ROM location, a hexadecimal number, and the results of the test for each ROM. The result will be one of the following:

  NL—Nothing is loaded in that socket. No action is required.

  BAD—The ROM is bad.

  OK—The ROM is OK.

  PROG DEV—The ROM is a program development ROM.



Figure 2-27 Sound Board Tests Screen

320 Sweep—Runs a program in the sound PC board 32010 to generate a sine wave sweep from 20 Hz to 9 kHz (requires oscilloscope).

320 Tune—Runs a program in the sound PC board 32010 to play a tune.

Program ROM—Tests the sound PC board program ROMs with the sound PC board 68000 and reports the results on the screen.

Program RAM—Tests the sound PC board program RAMs with the sound PC board 68000 and reports the results on the screen.

COMRAM—Tests the sound PC board communications RAM with the sound PC board 32010 and reports the results on the screen.

320 RAM—Tests the sound PC board 32010 program RAM with the sound PC board 68000 and reports the results on the screen.

LED Test—Flashes the Test LED with the sound PC board 68000.

DAC Ramp—Writes to every DAC value with the sound PC board 68000. The sawtooth frequency is about 60 Hz (requires oscilloscope).

DAC 250 Hz—Writes to every fourth DAC value with the sound PC board 68000. The sawtooth frequency is about 250 Hz (requires oscilloscope).

SA Counter—Creates an oscilloscope loop for the sound address counter (requires oscilloscope).

SB Latch—Creates an oscilloscope loop for the sound block latch (requires oscilloscope).

320 Tone—Plays a sine wave tone created by the 32010 (requires oscilloscope).

320 IRQ—Generates interrupts with the 32010



Figure 2-28 Sound Board Sound Wave ROM Checksums

which the 68000 on the sound board recognizes (requires oscilloscope).

320 DAC Ramp—The sound PC board 32010 ramps the DAC (requires oscilloscope).

320 DAC Ones—The sound PC board 32010 writes walking ones through the DAC latch (requires oscilloscope).

320 SBLOCK—The sound PC board 32010 writes increasing addresses to the Sound Block Latch (requires oscilloscope).

LEDs on the Main PCB

The LEDs (light emitting diodes) on the main PCB show you the status of various signals on the main PCB. Using the LEDs, you can check signals from various circuits going to the 68010 processor. The state of the signals is indicated by the LEDs which flash or stay lit.

Figure 2-29 shows the location of the LEDs on the main PCB. Table 2-9 shows the possible status of the LEDs, with an explanation of what they indicate.

DIP Switches

If you try to enter the self-test, but nothing appears on the screen, use the DIP switch tests. Use the information from these diagnostic tests to help you find the problem.

Before you begin with these following tests, be sure that the problem is in the simulator hardware, not in the video display. If you have a completely dark screen, check the following:

- Do you have power to the video display?
- Are the video display's filaments lit?

Table 2-9 LED Status

LED	Indicates	Status
Run LED	State of 68010 HALT signal.	*On* when 68010 is running. *Off* when 68010 processor is not running. *Flashing at 2 Hz* if the 68010 cannot run. (The watch-dog and clock must be running.) (The Run LED is *on* in game mode.)
DTACK LED	State of 68010 DTACK (data acknowledge) signal.	*On* when the 68010 processor is running and the timing circuit is probably operating. *Flashes at 2 Hz* when the 68010 processor cannot run. (The watchdog and processor clock must be running.) (The DTACK LED is *on* in game mode.)
Clock LED	State of the 68010 processor clock signal.	*On* when the game board is on. *Off* if the processor clock signal is stuck high or low.
IRQS LED	State of all 68010 interrupts.	*On* in the game mode. *Off* in hardware diagnostic mode and the early part of self-test. *Off* if no interrupts are occurring or any interrupt signal is stuck low.



Figure 2-29 DIP Switch and LED Locations on the Main PCB

- Do you have high voltage to the video display?

If the answer to any of these questions is no, then you have a problem in the video display. Check the video display service manual included with your simulator for the suggested procedure.

If you are sure that the problem is not with the video display, then try the DIP switch diagnostics shown in Table 2-10. These tests isolate various ICs and systems for troubleshooting. The results of the tests are indicated by the main PC board LEDs or on the video display screen.

To set the DIP switches for the tests:

1. Put a jumper across the DIAGN test points, shown on Figure 2-29.
2. Select the diagnostic test you want to use with the DIP switch settings.
3. Turn on the self-test switch.
4. Put a jumper momentarily across the RESET test points, shown in Figure 2-29.

To change to another DIP switch test:

1. Change the DIP switch settings.
2. Put a jumper momentarily across the RESET test points, shown in Figure 2-29.

To end the DIP switch testing:

1. Take the jumper off the DIAGN test points.
2. Put a jumper momentarily across the RESET test points.

The DIP switch settings are *on* in the top position when the main PCB board is in the simulator.

Table 2-10 Using the DIP Switches

Type of Test	Purpose and Results	DIP Switch Settings 1 2 3 4 5 6 7 8
	Watchdog, Test Program ROMs, Test Menu RAMs, and LED Tests	
Uncleared Watchdog	Puts the 68010 in a loop. Does *not* clear the watchdog counter. The program RAM does not need to work. If the watchdog is working, the run LED, DTACK LED, and IRQs LED flash at 2 Hz and the clock LED is on.	X X 0 0 0 0 0 0
Cleared Watchdog	Puts the 68010 in a loop. Clears the watchdog counter. The program RAM does not need to work. If the watchdog is working, the run LED, clock LED, DTACK LED and IRQs LED are on.	X X 0 0 0 0 0 1
Test LEDs	Tests the test LEDs. The program RAM does not need to work. If the test LEDs are working, they flash at 2 Hz.	X X 0 0 0 0 1 1
Test Program ROM 0	Tests ROM 0 H and 0 L, which hold the test program. (This test takes about 5 seconds.) LED 1 and LED 2 flash together if both ROMs are good. If ROM 0 L is bad, LED 1 does not flash. If ROM 0 H is bad, LED 2 does not flash.	X X 0 0 0 1 1 1
Test Menu RAM 0	Tests RAM 0 H and 0 L, which run the test menu. (This test takes about 5 seconds.) LED 1 and LED 2 flash together if both RAMs are good. If RAM 0 L is bad, LED 1 does not flash. If RAM 0 H is bad, LED 2 does not flash.	X X 0 0 1 1 1 1
	GSP Tests	
GSP Communications	Tests if the 68010 can communicate with the GSP, which produces the video. If the GSP responds, the LEDs flash together. If the GSP does *not* respond, LED 1 and 2 flash alternately.	X X 0 1 1 1 1 1
Red Screen	Produces a red screen from the color RAM, regardless of GSP VRAM input. Use this to check the red video outputs.	X X 0 1 1 1 1 0
Green Screen	Produces a green screen from the color RAM, regardless of GSP VRAM input. Use this to check the green video outputs.	X X 0 1 1 1 0 0
Blue Screen	Produces a blue screen from the color RAM, regardless of GSP VRAM input. Use this to check the blue video outputs.	X X 0 1 1 0 0 0
GSP Memory Fill	Does a very slow GSP memory fill so you can test the pixel scanner.	X X 0 1 0 0 0 0
GSP VRAM Verify	Performs the GSP VRAM verify test. (This test is also in the self-test.)	X X 1 0 0 0 0 0
	ROM and RAM Tests	
ROM Test Loop	The results are displayed on the screen.	X X 1 0 0 0 0 1
RAM Test Loop	The results are displayed on the screen.	X X 1 0 0 0 1 1
	MSP Tests	
MSP Interface	Tests the MSP interface. Results are displayed on the screen.	X X 1 0 0 1 1 1
MSP Auto Increment	Tests the MSP auto-increment. Results are displayed on the screen.	X X 1 0 1 1 1 1
MSP Interrupts	Tests the MSP interrupts (IRQs). Results are displayed on the screen.	X X 1 1 1 1 1 1
MSP DRAM Verify	Performs the MSP DRAM verify test. (This test is also in the self-test.) The results are displayed on the screen.	X X 1 1 1 1 1 0
	Bus Error Test	
BERR	The DTACK timer times out and generates a bus error (BERR) signal. The results are displayed on the screen.	X X 1 1 1 1 0 0

1=On; 0=Off; X=Doesn't Matter.

Chapter 3

Maintenance and Troubleshooting



This chapter includes maintenance, repair, and troubleshooting information for your Hard Drivin™ simulator.

The chapter is organized with the general information first and the specific information about parts and controls last. The general information includes a schedule for simulator maintenance and inspection, a table with general troubleshooting information, and a table of the voltage levels and test points on the PCBs. The specific information is arranged by the part or control with maintenance procedures, repair procedures, troubleshooting tables, and troubleshooting flowcharts for each part.

In the simulator, the hardware and software are closely related. If you are having problems with a mechanical assembly, always keep in mind that your electrical connections may not be good or you may have an electronic problem. To determine what kind of the problem you have, use the self-test screens as recommended in the troubleshooting tables and flowcharts.

If after using these tests and screens, you decide to repair a part, the procedures for removal, disassembly, and repair are provided in this chapter. If a part is mentioned, but not illustrated, refer to Chapter 4, *Illustrated Parts Lists*, for information.

Maintaining and Inspecting

Preventive maintenance includes inspecting, cleaning, lubricating, and tightening hardware. Perform the preventive maintenance regularly so you can keep the simulator in top condition, avoid problems, and maximize your earnings. Preventive maintenance tasks and intervals are shown in Table 3-1.

Maintaining Your Simulator

For the best performance from your Hard Drivin' simulator, you should check and maintain your simulator according to the times shown in Table 3-1. How to perform these tasks is explained in the section about that control in this chapter. You may want to perform these tasks more often if the simulator is heavily used.

Table 3-2 is the first of ten troubleshooting tables in this chapter. Use this table if *all* of your controls are acting erratically or not responding. If only one control is not working, go to the section about that control and read the troubleshooting information there.

Table 3-3 shows the correct voltage levels to various PC boards and the test points for those voltage levels. Low voltages to PC boards may cause problems with the controls, with the video display, or in driving.

Dashboard

Removing the Dashboard

Remove the dashboard to service the steering assembly or to replace the switches. See Figure 3-1.

WARNING

The dashboard weighs about 40 pounds. Be careful when you remove it.

---

1. Turn off the power and unplug the game.
2. Take off the under-dash cover over the brake and clutch pedals. It is held in place by two Phillips-head screws. See Figure 4-1 for an illustration.
3. Remove the four nuts on either side of the dashboard and take out the carriage bolts.

NOTE

Do not remove the four tamperproof screws around the steering wheel unless you are replacing the steering assembly. Even then, remove the bolts only after the dashboard is out of the simulator.

Table 3-1 Maintenance and Inspection Items

Part	When to Check	What to Check and Maintain
Coin Mechanism	Every 6 months	Clean.
Brake and Clutch Pedals	Every 3 months	Oil all bearings. Check the switch and switch actuator distance.
Video Display Face and Shield	Every 6 weeks	Take off the video display shield and clean the shield and the face of the video display. (Carbon particles emitted by the steering motor collect on the shield and video display, obscuring the view.)
Game Exterior	Every 3 months	Make sure the glides are down. The casters may be damaged if the glides are not used. Be sure the rubber stop behind the clutch on the firewall is still on.
Gas Pedal	Every 6 months	Spray the pivot pin, spring cable, and pulley with dry Teflon spray.
Interior Components	Every 3 months	Clean.
Key Switch	Every 3 months	Lightly oil the spring and shaft.
Shifter	Every 3 months	Check the shifter boot for damage. Make sure the foam in the boot is in place.
Steering Wheel	Every 3 months	Grease the threads. Check the rubber stops and tighten the screws that hold the stops on. Make sure the potentiometer shaft has a very light coat of grease. Make sure the stop assembly on the motor shaft is tight on the shaft. To prevent injuries, replace the steering wheel if the rim or spoke padding is worn out.

Table 3-2 Troubleshooting All Controls

Problem	Solution
All controls do not respond or respond erratically.	1. Go through the *Set Controls* screens in the self-test. 2. Have you recently installed a new PCB or new controls? If so, go through the *Set Controls* screens in the self-test. 3. Check the ZRAMs in the self-test for errors. 4. The simulator may have lost power during a ZRAM test. Go through the *Set Controls* screen in the self-test.

4. Remove the two tamperproof screws in the middle of the dashboard.
5. Unlock the bottom service door to reach the nuts on the carriage bolts underneath the dashboard at the rear. Take off the nuts and washers.
6. Also from the rear, disconnect the four connectors from the dashboard harness to the simulator harness.
7. Remove the Phillips-head screws on the front and under the dashboard.
8. The dashboard is now supported by the top lip and the side panels. Sit in the simulator seat and pull the dashboard forward and out of the simulator onto your lap.

Installing the Dashboard

1. Sit in the seat with the dashboard in your lap. Pull the seat towards the video display. Lift up the dashboard and slide it in on the side panels.
2. Feed the dashboard harnesses through the front panel cutouts. Push the dashboard into place.
3. Hold the dashboard in place and put the carriage bolts in on either side. Put the washers and the nuts on the bolts.
4. Go around to the back of the simulator and connect the steering assembly and the switch harnesses to the simulator harness. Then install the two carriage bolts with washers and nuts under the dashboard at the rear.

Table 3-3 Voltage Inputs and Test Points on the Simulator PCBs

PCB	Voltage	Test Points	Source and Purpose
Main	+5±0.1 VDC	+5V2	+5 V Switching Power Supply
Main	+15±0.6 VDC	+15V1	Regulated and supplied by the APU PCB. Used by the 12-bit A/D converter and runs the +12 VDC regulator.
Main	-22 VDC	-22V1	Unregulated and supplied by the APU PCB. Runs the -5V regulator.
Main	+12±0.5 VDC	+C127	Regulated and comes from the +15 VDC supply. Used by the 12-bit A/D converter and the sound PCB.
Main	-5±0.2 VDC	-C125	Regulated and comes from the unregulated -22 VDC supply. Used by the 12-bit A/D converter and the sound PCB.
ADSP	+5 VDC	+5V1 or +5V2	Regulated and supplied from the Main PCB through the interface cable.
Sound	+5 VDC	+5V2	Supplied and regulated by the main PCB through the sound power cable. Used by the logic circuitry.
Sound	+12 VDC	105B Pin 4	Supplied and regulated by the main PCB through the sound power cable. Used by the analog circuitry.
Sound	-5 VDC	5R Pin 4	Supplied and regulated by the main PCB through the sound power cable. Used by the analog circuitry.
Sound	+5 VDC	+5V2	Supplied and regulated by the main PCB through the interface cable.
Sound	-15 VDC	105B Pin 11	Supplied by the APU PCB through the main PCB. Used by the 12-bit D/A converter on the sound PCB
APU	+14VDC	See schematics	Used by the coin counters and the audio amps on the APU PCB.
APU	-14VDC	See schematics	Used by audio amps on the APU PCB.

5. Install the two tamperproof screws and washers. Finally install the Phillips-head screws under the dashboard.
6. Install the under-dash cover above the brake and clutch pedals. Screw in the two Phillips-head screws that hold it in place.
7. Close and lock the service door.

Steering Assembly

If you have problems with the steering assembly, check the troubleshooting suggestions in Table 3-4. Always perform the *Set Controls* screens in the self-test first.



Figure 3-1 Removing and Installing the Dashboard

Greasing the Steering Assembly

Grease the steering assembly threads and stop regularly according to the maintenance schedule and if turning the steering wheel becomes difficult (and the problem is not the steering motor).

1. Take out the dashboard. See the procedure in the section *Removing the Dashboard.*
2. Grease the large threads on the stop assembly. See Figure 3-5.
3. Put the dashboard back in. See the procedure in the section *Installing the Dashboard.*

Replacing the Steering Assembly Potentiometer

Replace the potentiometer after you have followed the flowchart in Figure 3-2, 3-3, or 3-4 and you are sure the problem is the potentiometer.

1. Take out the dashboard. Follow the instructions in the section *Removing the Dashboard.*
2. Loosen the set screw that holds the potentiometer shaft in place. See Figure 3-5. Remove the nut that holds the potentiometer in the potentiometer bracket. Take out the potentiometer. If the small spring that holds the potentiometer bracket on the stop bracket is broken, replace it.
3. Solder the wiring harness to the new potentiometer. Connect the red wire nearest the shaft, the clear wire in the middle, and black wire at the end.

CAUTION

Carefully follow the instructions for installing the new potentiometer. If you do not, you might destroy the potentiometer.

---

4 Set up the potentiometer. Hold the new potentiometer with its shaft facing you and turn the shaft as

Table 3-4 Troubleshooting the Steering Assembly

Problem	Solution
Steering wheel does not respond or responds erratically.	1. Go through the *Set Controls* screens in the self-test. 2. Check the *Control Inputs* screen to see if the potentiometer input to the board is functioning correctly. The steering wheel and wheel lines, which both indicate steering wheel position, should smoothly appear and disappear as you turn the wheel. 3. Check the connections to the potentiometer and to the motor. 4. Check voltage level to main PCB. See Table 3-3.
Steering wheel is difficult to turn.	Grease the threads. Check the steering assembly for broken parts. Check the motor bearings by turning the shaft and seeing if it spins freely.
Steering has no feedback.	1. Try the *Set Controls* screens in the self-test. 2. See Figure 3-2 to determine the cause of the problem.
Steering is very jerky.	Some jerkiness is OK. 1. Try the *Set Controls* screens in the self-test. 2. If you think the steering is very jerky, see Figure 3-4 for more information.
Steering wheel is turned all the way to one side or the other during play and stays there.	1. Try the *Set Controls* screens in the self-test. 2. See Figure 3-3 for more information.
Steering wheel can spin more than three times around.	Replace the stop assembly and the potentiometer.
Force on the steering wheel changes.	The force on the steering wheel should be lighter when the seat is closer to the dashboard and harder when the seat is further away. This so children, who sit closer to the dashboard to drive, will be able to turn the steering wheel easily.



Figure 3-2 Steering Wheel Has No Feedback and You Have Tried the *Set Controls* Screens



Figure 3-3 Steering Wheel is Turned All the Way to One Side and You Have Tried the *Set Controls* Screens



Figure 3-4 Steering Wheel Is Jerky and You Have Tried the Set Controls Screens

far as it can go in the counterclockwise direction. Then turn the shaft back about 15 degrees.

5. Face the stop bracket on the end of the motor; then turn the motor shaft as far as it will go in the clockwise direction.
6. Apply one drop of light oil to the potentiometer shaft before you install it in the bracket.
7. Install the potentiometer into the potentiometer bracket with the flat of the shaft facing down and the tab in the keyhole.
8. Put the lock washer and nut on the potentiometer shaft and tighten the nut. Do not turn the potentiometer shaft from the position at which you set it.
9. Insert the potentiometer shaft into the motor shaft; tighten the socket-head screw.
10. Check the alignment of the potentiometer and the motor by carefully turning the motor shaft as far as it will go clockwise and counterclockwise. Check that the potentiometer shaft turns as far as the motor shaft turns in both directions. If the potentiome-

ter shaft stops turning before the motor shaft stops turning, then do steps 4 through 9 again.

11. Put the dashboard back in the simulator, following the instructions in the section *Installing the Dashboard.*
12. Go to the *Set Controls* screens in the self-test and re-initialize all the controls.

NOTE

You must go through the Set Controls *screens in the self-test because you replaced the potentiometer. If you do not do this, the simulator will not work right.*

Replacing the Steering Assembly Motor

Replace the steering assembly motor if you have followed the flowchart in Figure 3-2 and you are sure that the motor is the problem. Another reason to replace the motor is if the steering wheel is difficult to turn and the problem is not lubrication or the mechanical parts.

Before you replace the motor, check the harness connections to make sure they are good.

Removing the Steering Assembly Motor

1. Take out the dashboard. Follow the instructions in the section *Removing the Dashboard.*
2. Carefully peel off the Atari Games decal on the hub of the steering wheel. The steering assembly is shown in Figure 3-5.
3. Unscrew the socket-head screw under the decal. Remove the screw, the washer and the hub cover.
4. Remove the large nut under the hub cover with a 1 1/16-inch socket. The nut is torqued to 50 foot-pounds.
5. Take off the washer and the steering wheel.
6. At the other end of the steering assembly, remove the potentiometer from the end of the motor shaft by loosening the small screw at the end of the shaft. Take off the potentiometer and the potentiometer bracket.
7. Remove the nut at the end of the motor shaft which holds the stops on the shaft. This nut requires a 1 1/16-inch socket and is torqued to 50 foot-pounds. Remove the washer.
8. Remove the four tamperproof screws that hold the steering assembly on the dashboard. These are torqued to 340 inch-pounds. Take the steering assembly and the motor support plate off the dashboard.
9. Use a puller to loosen the stop assembly on the tapered shaft. You must remove the stop assembly at the same time as you remove the stop bracket.
10. Remove the four socket-head screws and washers that hold the stop bracket on the motor. Pull the stop bracket and the stop assembly off the motor shaft.

Checking the Steering Assembly Motor

11. Do the following tasks before you re-assemble the parts on the new motor:
    a. Tighten the socket-head screws that hold the rubber stops in place.
    b. Generously grease the threads.
    c. Check the spring that holds the potentiometer shaft on the stop bracket. If it is broken, replace it.
    d. Check the round stops on the corners of the large rectangular stops on the stop assembly. Make sure the round stops are not cracked or broken.

Replacing the Steering Assembly Motor

12. Put the stop assembly into the holes in sides of the stop bracket. Push the stop bracket and the stop assembly on the shaft of the new motor. (When you tighten the nut on the end of the shaft the stop assembly will be correctly seated.) Put the key slot on the stop assembly over the key on the shaft.
13. Screw the four socket-head screws and washers into the stop bracket and motor. Install the ground wire under the wide washer at the top left screw.
14. Replace the nut and the washer at the end of the motor shaft. Torque the nut to 50 foot-pounds.
15. Set up the potentiometer. Hold the new potentiometer with its shaft facing you and turn the shaft as far as it can go in the counterclockwise direction. Then turn the shaft back about 15 degrees clockwise.
16. Face the stop bracket on the end of the motor; turn the motor shaft as far as it will go in the clockwise direction.
17. Apply one drop of light oil to the potentiometer shaft before you install it in the bracket.
18. Install the potentiometer into the potentiometer bracket with the flat of the shaft facing down and with the tab in the keyhole.
19. Put the lock washer and nut on the potentiometer shaft and tighten the nut. Do not turn the potentiometer shaft from the position at which you set it.



Figure 3-5 Maintaining the Steering Wheel

20. Insert the potentiometer shaft into the motor shaft; tighten the socket-head screw.
21. Check the alignment of the potentiometer and the motor by carefully turning the motor shaft as far as it will go clockwise and counterclockwise. Check that the potentiometer shaft turns as far as the motor shaft turns in both directions. If the potentiometer stops turning before the shaft stops turning, then do steps 15 through 20 again.
22. Using the four tamperproof screws, install the steering assembly and the motor support plate on the dashboard. Put Loktite on the carriage bolts before you put the nuts on them. Tighten the nuts to 340 ± 10 inch-pounds so the steering assembly will not twist on the dashboard.
23. Install the steering wheel on the steering hub. Put the hole in the steering wheel over the alignment stud on the hub. (See Figure 3-5.)
24. Put on the washer and the large nut. Torque the nut to 50 foot-pounds.
25. Install the hub cover, split-lock washer, and the socket-head screw. Put Loktite on the screw before installing it. Tighten it to 95 inch-pounds.
26. Replace the Atari Games decal on the hub.
27. Put the dashboard back in the simulator, following the instructions in the section *Installing the Dashboard.*
28. Go to the *Set Controls* screens in the self-test and re-initialize all the controls.

Replacing the Steering Assembly Stop

It is unlikely that the steering assembly stop will have to be replaced. If it does, follow the instructions in *Replacing the Steering Assembly Motor* for assembly and disassembly. You also must replace the potentiometer on the steering assembly.

Key Switch Assembly

Table 3-5 lists what can go wrong with the key switch assembly.

Oiling the Key Switch Assembly

Oil the key switch bezel ring and shaft regularly, when turning the key switch becomes difficult, or when the key squeaks.

1. Take out the dashboard. See the procedure in the section *Removing the Dashboard.*
2. Lightly oil the bezel, shaft, and spring of the key switch. See Figure 3-6. Check that the spring is not broken. If it is, then replace the spring following the procedure under Repairing the Key Switch.
3. Put the dashboard back in. See the procedure in the section *Installing the Dashboard.*

Replacing the Spring in the Key Switch Assembly

If nothing happens when the key turns, and there is no resistance to turning, you may need to replace the spring.

1. Remove the dashboard. Follow the procedure in the section *Removing the Dashboard.*
2. Take the key switch assembly off the dashboard by removing the two carriage bolts and locknuts.
3. Remove the retaining ring from the back of the key switch case. See Figure 3-6.
4. Loosen the socket-head screw on the brass actuator with a 5/32-inch Allen-head wrench.
5. Remove the other retaining ring inside the case. Pull out the key. Take out the brass actuator, the old spring, and the nylon washer.
6. Put lithium grease (Atari Games part no. 107029-001) inside the collar. Wipe off the excess grease.
7. Put one end of the spring into the hole in the side of the case.
8. Push the shaft back into the case far enough to mount the spring on the shaft. You may have to cut the legs of the spring to the correct length so that they do not interfere with the operation of the switch assembly.
9. Put the brass actuator into the case with the actuator pin facing the key and opposite the switch. Catch the free end of the spring under the pin. Push the actuator and the nylon washer onto the shaft.
10. Push the shaft through the case and install the two retaining rings.
11. Adjust the actuator on the shaft until it is parallel to the roller on the switch.
12. When the actuator is against the case opposite the switch, the key should be vertical. If the key is not vertical, turn it until it is. Tighten the screw on the actuator.
13. Now hold the actuator against the switch and move the switch so that when you turn the key, the switch clicks once. If the switch is too close, it will click twice instead of once when you turn the key. Tighten the screws on the switch when the position is correct.
14. Put the key switch assembly back on the dashboard. Install the dashboard as described in the section *Installing the Dashboard.*

Table 3-5 Troubleshooting the Key Switch

Problem	Solution
Key does not return when turned and has no resistance.	The actuator screw may be loose or the spring may need to be replaced.
Key turns more that 90°.	The actuator is loose; tighten the screw on the actuator.
Key turns, but nothing happens.	Check the snap-action switch, switch connectors, actuator location, and harness connections.
Key squeaks when turned.	Oil the collar and shaft.



Figure 3-6 Maintaining the Key Switch Assembly

Tightening the Screw in the Key Switch Actuator

If nothing happens when the key turns, and it turns more than 90°, you may need to tighten the screw on the actuator.

1. Remove the dashboard. Follow the procedure in the section *Removing the Dashboard.*
2. Adjust the actuator on the shaft until it is parallel to the roller on the switch. See Figure 3-6.
3. When the actuator is against the case opposite the switch, the key should be vertical. If the key is not vertical, turn it until it is. Tighten the screw on the actuator.
4. Now hold the actuator against the switch and move the switch so that when you turn the key, the switch clicks once. If the switch is too close, it will click twice instead of once when you turn the key. Tighten the screws on the switch when the position is correct.
5. Install the dashboard as described in the section *Installing the Dashboard.*

Replacing the Switch on the Key Switch Assembly

Replace the switch if the key turns but nothing happens and the problem is not the spring, the actuator, or the connections. The key switch assembly is shown in Figure 3-6.

1. Remove the dashboard. Follow the procedure in the section *Removing the Dashboard.*
2. Take the key switch off the dashboard by removing the two carriage bolts and locknuts.
3. Remove the two Phillips-head screws that hold the snap-action switch on the key switch assembly. Take off the switch. Take the harness off the switch.

4. Install the switch on the assembly, but do not tighten the screws. The roller on the switch should face the brass switch actuator.
5. Loosen the screw on the brass actuator. Adjust the actuator on the shaft until it is parallel to the roller on the switch.
6. When the actuator is against the case opposite the switch, the key should be vertical. If the key is not vertical, turn it until it is. Tighten the screw on the actuator.
7. Now hold the actuator against the switch and move the switch so that when you turn the key, the switch clicks once. If the switch is too close, it will click twice instead of once when you turn the key. Tighten the screws on the switch when the position is correct.
8. Put the harness on the new switch. Connect the black wire to the C (or COM) terminal, and the white wire to the NO terminal.
9. Put the key switch assembly back into the dashboard and install the dashboard as described in the section *Installing the Dashboard.*

Clutch Pedal

The clutch is part of the clutch and brake pedal assembly. If you have trouble with the clutch, first go through the *Set Controls* screens. If that does not cure the problem, see Table 3-6, *Troubleshooting the Clutch Pedal.*

If you must repair the clutch, but you cannot do so immediately, you can disable the clutch circuit. All drivers must use the automatic transmission if you do this. *Do this only as a temporary measure.* Repair the clutch as soon as possible.

To disable the circuit, go to the *Disable Broken Controls* screen in the self-test and choose *broken* for the clutch.

Maintaining the Clutch and Brake Pedals

Take the pedals out of the simulator to maintain them. Regular maintenance includes oiling the pedals, which should be done with the pedals out of the simulator, since you cannot reach all the points and you may get oil on the PC boards below the pedals when they are in the game.

1. Turn off the power and unplug the game.
2. Take off the under-dash cover above the pedal assembly. Use a Phillips screwdriver to remove the four screws that hold the cover on.
3. Unlock the bottom service door. Take off the harness connector to the pedal.
4. The back of the pedal assembly is above the main PC board. Remove the four nuts and fender washers holding the pedal assembly to the cabinet. After you remove the nuts, the pedals will hang in the same position.
5. Go to the front. Twist and pull the pedal assembly counterclockwise to avoid the bottom of the dashboard.
6. Put light oil on the eight bearing points shown in Figure 3-8.
7. Before you install the pedal assembly, check the following.
   a. Can you push the brake pedal 1/4 to 1/2 inch before you feel resistance? If you feel resistance before this point, first check the bearings to see if they are moving. If the bearings are moving, adjust the nut on the brake spring return shaft so that the pedal has at least 1/4 inch of free play.
   b. Does the pedal return to its resting location? If not, check if the return spring is broken or the bearings are binding.

Table 3-6 Troubleshooting the Clutch Pedal

Problem	Solution
Clutch does not work or works erratically.	1. Perform the *Set Controls* screens in the self-test. 2. Follow the flowchart in Figure 3-7 to find the cause of the problem. 3. Check connections. 4. Check voltage levels to the main PCB. See Table 3-3. 5. If you had disabled the clutch circuit, but the clutch is now repaired, choose *working* on the *Disable Broken Controls* screen.
Does not return.	1. Check the bearings. 2. The springs may be broken or weak.



Figure 3-7 Clutch, Seat, or Gas Pedal Is Not Working or Working Erratically and You Have Tried the *Set Controls* Screens

c. Does the brake pedal move at least 1/4 inch before the switch clicks? If not, adjust the clamp on the white plastic actuator until you have 1/4 inch of play in the pedal. Make sure the switch clicks before you feel resistance on the pedal.

8. Put the pedal assembly back in the simulator. Install the fender washers and the locknuts. Connect the simulator harness.

Replacing the Clutch Potentiometer

Do not replace the potentiometer until you have performed the *Set Controls* screens. Check to see if that solves the problem. If not, follow the flowchart in Figure 3-7 to make sure that the potentiometer is the problem.

1. Turn off the power and unplug the game.
2. Take off the cover above the pedal assembly under the dashboard. Use a Phillips screwdriver to remove the four screws that hold the cover on.
3. Unlock the bottom rear service door. The back of the pedal assembly is above the main PCB. Disconnect the simulator harness from the assembly. Remove the washers and nuts holding the pedal assembly to the cabinet. After you remove the nuts, the pedals will hang in the same position.
4. Go to the front of the simulator. Twist and pull pedal assembly counterclockwise to avoid the bottom of the dashboard.
5. See Figure 3-8 for an illustration of the pedals. The clutch potentiometer is mounted on the brake side of the pedal assembly. Loosen the locknut on the potentiometer with a 1/2-inch flat wrench.
6. Loosen the screw on the small gear with a 3/32-inch Allen wrench.
7. Take off the gear, nut, washer, and potentiometer. Remove the wires on the potentiometer.
8. With the shaft of the new potentiometer facing you and the terminals pointing up, solder the black wire on the left terminal, the yellow on the middle, and the red to the right terminal.
9. Put on the new potentiometer. Insert the key into the key hole in the assembly frame. The potentiometer terminals must point up. Put the nut and washer on, but do not tighten the nut all the way.
10. Put the gear on the potentiometer shaft. The screw must be vertical and over the flat part of the shaft. Make sure that the gear meshes with and is directly over the gear below. Tighten the screw. Tighten the nut on the potentiometer.
11. Carefully press the clutch pedal and make sure that the potentiometer shaft turns until the pedal reaches its stop. If it does not, re-install the potentiometer, following steps 9 and 10.
12. Put the pedal assembly back in the simulator. Install the fender washers and the locknuts. Re-connect the simulator harness.
13. Now switch on the self-test and go through the *Set Controls* screens.

NOTE

You must enter the self-test and go through the Set Controls *screens because you repaired the pedal assembly. Otherwise the simulator will not work right.*

Replacing the Clutch Springs

Replace the clutch springs if the clutch does not return to position and the springs are weak or broken. See Figure 3-8 for an illustration of the pedals.

1. Turn off the power and unplug the game.
2. Take off the under-dash cover above the pedal assembly. Use a Phillips screwdriver to remove the four screws that hold the cover on the cabinet.
3. Open the bottom rear service door. The back of the pedal assembly is above the main PC board. Disconnect the simulator harness from the assembly. Remove the washers and nuts holding the pedal assembly to the cabinet. After you remove the nuts, the pedals will hang in the same position.
4. Go to the front of the simulator. Twist and pull the pedal assembly counterclockwise to avoid the bottom of the dashboard.
5. Remove the metal stop bracket on the assembly with the rubber bumper pads attached to it. Remove the two socket-head screws, one on either side, which hold the bracket to the frame. (You do not need to remove the rubber bumper pads.) Pull the stop bracket out the assembly.
6. Take off the locking tabs on the end of the spring shafts. Use an Allen wrench to remove the socket-head screws on the tabs.
7. Push the shafts out through the assembly frame and remove the springs.
8. Install the new springs, making sure the ends are hooked over the cut-out areas on the nylon shaft covers.



Figure 3-8 Maintaining the Clutch and Brake Assembly

9. Push the spring shafts back into place and reinstall the locking tabs.
10. Install the stop bracket. Make sure the pedal shafts rest against the rubber bumpers.
11. Put the pedal assembly back in the simulator. Install the fender washers and the locknuts. Re-connect the simulator harness.
12. Now switch on the self-test and go through the *Set Controls* screens.

NOTE

Enter the self-test and go through the Set Controls *screens when you replace the pedal assembly. Otherwise the simulator will not work right.*

Brake Pedal

The brake is part of the clutch and brake pedal assembly. For maintenance procedures, see *Maintaining the Clutch and Brake Pedals*, above.

Repairing the Brake

The brake may not work for several reasons. Before you do any repairs, always perform the *Set Controls* screens in the self-test; then try the brake to see if this corrects the problem. If that does not repair the problem see Table 3-7, *Troubleshooting the Brake Pedal* and follow the flowchart in Figure 3-9. The test procedures in the flowchart are explained below.

If you must repair the brake, but you cannot do so immediately, and you want to continue to use your game, you can disable the brake circuit. When you disable the brake, a screen appears before each race which tells drivers that the brake does not work and to slow down, just take their foot off the accelerator.

Disable the brake *only* as a temporary measure. Repair the brake as soon as possible since this is an essential part of the game.

To disable the brake circuit, go to the *Disable Broken Controls* screen in the self-test and choose *broken* for the brake.

Testing the Switch, Switch Actuator Distance, and Pedal Movement

If you have brake problems, see the flowchart in Figure 3-9. If necessary, do the following tests to check the switch actuator distance and the switch.

1. Check the actuator adjustment. The pedal should move at least 1/4 inch before the switch clicks. If not, then adjust the clamp on the white plastic actuator until you have 1/4 inch of play in the pedal. The switch must click before you feel resistance on the pedal.
2. Check the resistance on the pedal. It should begin after the switch clicks, but no further than 1/2 inch from the pedal resting place. If you feel resistance before this point, check if the bearings are moving. If the bearings are moving freely, adjust the nut on

Table 3-7 Troubleshooting the Brake Pedal

Problem	Solution
Brake does not work or is working erratically.	1. Go through the *Set Controls* screens in the self-test. 2. Check the F4 fuse on the power supply. (If this fuse is blown, the shifter will not work either.) 3. Check the brake force on the 12-bit A/D item in the *Control Inputs* screen. As you press down on the brake, the line should disappear, in realtion to how much force you are putting on the brake. 4. Check the harness connections. 5. Check the distance adjustment for the switch actuator. 6. Check the switch. a. The connections to the brake snap-action switch are incorrect. Harness connections should be on C and NC. b. Check the switch with an ohmmeter as described in *Checking and Adjusting the Brake*. 7. Check the brake PCB. 8. Check the strain gauge by connecting an ohmmeter as described in *Testing the Strain Gauge and Strain Gauge Bonding*. 9. Check voltage level to the main PCB. See Table 3-3. 10. If the brake was not working, and you disabled the brake circuit, but now the brake is repaired, go to the *Disable Broken Controls* screen and choose *working*.



Figure 3-9 Brake Is Not Working or Working Erratically and You Have Tried the *Set Controls* Screens

the brake spring return shaft so that the pedal has at least 1/4 inch of free play, and the switch clicks before the resistance begins.

3. If the pedal does not return to its resting location, check if the return spring is broken or if the bearings are not moving.
4. Check the switch. Disconnect the connector from the Brake PCB and connect an ohmmeter across pins 6 and 7 of the harness connector. If the switch is good, the switch closes when the pedal is *not* pressed, and opens when the pedal is pressed.

Testing the Strain Gauge and Strain Gauge Bonding

If you have brake problems, see the flowchart in Figure 3-9. If necessary, do the following tests to check the strain gauge and strain gauge bonding.

1. Remove the connector from the brake PCB in the back of the simulator and put an ohmmeter across pins 1 and 2 of the harness connector. If the ohmmeter does not measure 350 Ω ± 10%, then replace the brake pedal assembly because the strain gauge is bad.
2. If the ohmmeter does measure 350 Ω ± 10%, then check the bonding. Attach a digital volt-ohmmeter to pins 1 and 2 and have someone press hard on the brake. If the resistance does not change as the pressure on the brake pedal changes, then the bonding has failed and you must replace the brake pedal assembly.

Replacing the Brake Switch

Before you replace the brake switch, do the *Set Controls* screens in the self-test and follow the flowchart in Figure 3-9. Test the switch as explained above in *Testing the Switch, Switch Actuator Distance, and Pedal Movement.* If you are sure that you must replace the switch, do the following procedure.

1. Turn off the power and unplug the game.
2. With the pedal assembly out of the simulator, remove the two nuts that hold the switch against the wall. Take out the screws and the switch.
3. Replace the switch with the terminals pointing towards the top of the pedal assembly. Adjust the actuator position so the brake pedal has at least 1/4 inch of play in it before the switch clicks. Loosen or tighten the clamp on the white plastic actuator to adjust this distance. The switch must click before you feel resistance while pushing the pedal.
4. Connect the wires to the switch. The two wires attach to the C and NC terminals.

5. Put the pedal assembly back in the simulator. Install the fender washers and the locknuts. Re-connect the simulator harness.
6. Now switch on the self-test and go through the *Set Controls* screens.

NOTE

You must enter the self-test and go through the Set Controls *screens since you repaired the brake. Otherwise the simulator will not work right.*

Replacing the Brake Strain Gauge and Pedal Assembly

Before you replace the brake pedal assembly because you suspect the strain gauge, do the *Set Controls* screens in the self-test and follow the flowchart in Figure 3-9. Test the strain gauge as explained above in *Testing the Strain Gauge and Strain Gauge Bonding.* If you are sure that you must replace the brake pedal assembly, do the following procedure.

NOTE

The strain gauge is mounted on the pedal at the factory because special bonding is required. Therefore, you must replace the entire brake pedal assembly if the strain gauge or bonding is bad.

---

1. Turn off the power and unplug the game.
2. To replace the brake pedal assembly, take off the under-dash cover above the pedal assembly. Use a Phillips screwdriver to remove the screws that hold the cover on the cabinet.
3. Open the lower rear service door. The back of the pedal assembly is above the main PCB. Disconnect the simulator harness from the assembly. Remove the washers and nuts holding the pedal assembly to the cabinet. After you remove the nuts, the pedals will hang in the same position.
4. Go to the front of the simulator. Twist and pull the pedal assembly counterclockwise to avoid the bottom of the dashboard.
5. On the pedal assembly, disconnect the strain gauge wires from the Brake PCB. See Figure 3-8 for an illustration of the pedals.
6. Remove the metal stop bracket with the rubber bumper pads attached to it. Take out the two screws, one on either side, which hold the bracket to the frame. (You do not need to remove the rubber bumper pads.) Pull the bracket out the assembly.
7. Remove the retaining ring at the top of the brake shaft that holds the shaft and brake springs together.
8. Take off the locking tab on the end of the pedal pivot shaft. Use a 3/16-inch Allen wrench to remove the socket-head screw.
9. Push the pivot shaft towards the clutch. Remove the brake pedal assembly.
10. Put the new brake pedal assembly into position. Push the pivot shaft through the brake shaft and into the case. Install the locking tab and the socket-head screw.
11. Replace the retaining ring at the top of the brake shaft that holds the shaft and the brake springs together.
12. Replace the metal stop bracket. Put in the two screws that hold the bracket to the frame.
13. Re-connect the strain gauge wires to the brake PCB.
14. Check the following to make sure the brake is set up properly:
    a. Check the actuator adjustment. The pedal should move at least 1/4 inch before the switch clicks. If not, adjust the clamp on the white plastic actuator until you have 1/4 inch of play in the pedal. Make sure the switch clicks before you feel resistance on the pedal.
    b. Check the resistance on the pedal. It should begin sometime after the switch clicks, but no further than 1/2 inch from the starting point. If you feel resistance before this point, check if the bearings are moving. If the bearings are moving freely, then adjust the nut on the brake spring return shaft so that the pedal has at least 1/4 inch of free play. Check that the switch clicks before resistance begins.
15. Put the pedal assembly back in the simulator. Install the fender washers and the locknuts. Re-connect the simulator harness.
16. Now switch on the self-test and go through the *Set Controls* screens.

NOTE

Enter the self-test and go through the Set Controls *screens since you replaced the brake pedal assembly. Otherwise the simulator will not work right.*



Figure 3-10 Rewinding the Gas Pedal Pulley Cable

Gas Pedal Assembly

The most likely cause of gas pedal assembly failure is the pulley cable breaking or unwinding. Check the suggestions in Table 3-8 before repairing the gas pedal.

Lubricating the Gas Pedal

Maintain the gas pedal assembly by lubricating at the points shown in Figure 3-11.

1. Turn off the power and unplug the game.
2. From the front of the cabinet, unscrew the seven Phillips-head screws and pull the gas pedal assembly forward. Disconnect the simulator harness from the assembly. Take the assembly out.
3. Lubricate the pivot pin and surrounding area, the spring cable, and pulley with dry Teflon spray. Check that the cable is wound correctly. See Figure 3-10.
4. Put the gas pedal back in the simulator and re-connect it to the simulator harness connector. Make sure that the ground wire is connected. Screw in the Phillips-head screws that hold the assembly in the simulator.

Rewinding the Gas Pedal Pulley Cable

The pulley cable may become disconnected during normal use and must be rewound. If you remove or replace the cable spring, you may also have to rewind the pulley cable. If the cable is cut or frayed, replace it.

1. Turn off the power and unplug the game.
2. Remove the pedal assembly from the simulator by taking out the seven Phillips-head screws that hold the pedal assembly box in the simulator. Disconnect the pedal from the simulator harness.
3. Lay the pedal assembly on the bench, with the extension spring at the front. See Figure 3-11 for an illustration of the pedal.
4. Put the large circular lug on one end of the cable around the hook on the pedal. See Figure 3-10, Step A. Thread the rest of the cable up through the hole in the base plate.

   Wrap the cable counterclockwise around the pulley up to the cap screw. Put the cable through the notch and wrap it once, clockwise, around the cap screw in the pulley. (This screw must be at the top of the pulley. If it is not, turn the pulley so it is.)

5. Bring the cable back through the notch and wrap it twice, counterclockwise, around the pulley. Do not wrap the cable over itself. See Figure 3-10, Step B. Hook the small circular lug onto the cable spring. The cable spring should be stretched out. Push the pedal a few times to make sure the cable returns the pedal to the rest position.
6. Lubricate the pivot pin, springs, cable, and pulley with dry Teflon spray.
7. Install the pedal in the simulator and re-connect the harness. Make sure the ground wire is attached.
8. Go to the *Set Controls* screens in the self-test and re-initialize all the controls.

NOTE

You must go through the Set Controls *screens in the self-test because you re-paired the pedal. Otherwise, the simulator will not work right.*

Replacing the Gas Pedal Cable Spring

The gas pedal cable spring may break or become weak. Before you replace the spring, first make sure the cable is wound correctly around the pulley since this is a more likely cause of gas pedal failure.

1. Turn off the power and unplug the game.
2. Remove the pedal assembly from the simulator by taking out the seven Phillips-head screws that hold the pedal assembly box in the simulator. Disconnect the pedal from the simulator harness.
3. Lay the pedal assembly on the bench, with the extension spring pointing up at the front. See Figure 3-11 for an illustration of the pedal.
4. Disconnect the cable from the cable spring. Remove the spring and replace it.
5. If the cable is frayed or cut, replace it.
6. Put the large circular lug on one end of the cable around the hook on the pedal. See Figure 3-10, Step A. Thread the rest of the cable up through the hole in the base plate.

   Wrap the cable counterclockwise around the pulley up to the cap screw. Put the cable through the notch and wrap it once, clockwise, around the cap screw in the pulley. (This screw must be at the top of the pulley. If it is not, turn the pulley so it is.)
7. Bring the cable back through the notch and wrap it twice, counterclockwise, around the pulley. Do not wrap the cable over itself. See Figure 3-10, Step B. Hook the small circular lug onto the cable spring. The cable spring should be stretched out. Push the pedal a few times to make sure the cable returns the pedal to the rest position.
8. Lubricate the pivot pin, springs, cable, and pulley with dry Teflon spray.
9. Install the pedal in the simulator and re-connect the harness. Make sure the ground wire is attached.
10. Go to the *Set Controls* screens in the self-test and re-initialize all the controls.

Replacing the Gas Pedal Potentiometer

Replace the potentiometer if you have followed the flowchart in Figure 3-7 and decided that the potentiometer is the problem. However, when you take the gas pedal out of the simulator, first check if the springs are broken or if the cable is broken or unwound from the pulley before you replace the potentiometer.

1. Turn off the power and unplug the game.
2. Remove the pedal assembly from the simulator by taking out the seven Phillips-head screws that hold the pedal assembly box in the simulator. Disconnect the pedal from the simulator harness.

Table 3-8 Troubleshooting the Gas Pedal Assembly

Problem	Solution
Gas pedal does not work or works erratically.	1. Go through the *Set Controls* screen in the self-test. 2. If that doesn't work, see Figure 3-7 for more information. 3. Check the *Control Inputs* screen. If the gas line does not change as you press the pedal down, then you may need to replace the potentiometer, rewind or replace the pulley cable, or replace a broken spring. 4. Check voltage level to boards. See Table 3-3.
Does not return to rest position.	1. Is the gas pedal lubricated? Follow the procedure under *Lubricating the Gas Pedal.* 2. Check the pulley cable. 3. Check for a broken extension spring, shown in Figure 3-9.



Figure 3-11 Maintaining the Gas Pedal

3. Lay the pedal assembly on the bench, with the extension spring pointing up at the front. See Figure 3-11 for an illustration of the pedal.
4. Disconnect the cable from the cable spring. Loosen the screw on the pulley and remove the pulley from the potentiometer shaft.
5. Take off the potentiometer by removing the nut with a 1/2-inch wrench. Take the wires off the potentiometer.

6. Put a new potentiometer on the bracket in the base plate, with the three terminals facing towards you and the flat of the potentiometer shaft facing up. Tighten the nut.
7. Solder the harness wires onto the potentiometer in this order: red on the left terminal, white on the middle, and black on the right.
8. Put the pulley on the potentiometer shaft and tighten the screw in the hub on the flat of the potentiometer shaft.
9. Put the large circular lug on one end of the cable around the hook on the pedal. See Figure 3-10, Step A. Thread the rest of the cable up through the hole in the base plate.

   Wrap the cable counterclockwise around the pulley up to the cap screw. Put the cable through the notch and wrap it once, clockwise, around the cap screw in the pulley. (This screw must be at the top of the pulley. If it is not, turn the pulley so it is.)
10. Bring the cable back through the notch and wrap it twice, counterclockwise, around the pulley. Do not wrap the cable over itself. See Figure 3-10, Step B. Hook the small circular lug onto the cable spring. The cable spring should be stretched out. Push the pedal a few times to make sure the cable returns the pedal to the rest position.
11. Lubricate the pivot pin, springs, cable, and pulley with dry Teflon spray.
12. Install the pedal in the simulator and re-connect the harness. Make sure the ground wire is attached.
13. Go to the *Set Controls* screens in the self-test and re-initialize all the controls.

NOTE

You must go through the Set Controls *screens in the self-test because you replaced the potentiometer. The simulator will not work right if you do not set the controls.*

Replacing a Broken Spring on the Gas Pedal

It is unlikely that these springs will be sprung or fatigued. However, if they are, follow the instructions below.

1. Turn off the power and unplug the game.
2. Remove the pedal assembly from the simulator by taking out the seven Phillips-head screws that hold the pedal assembly box in the simulator. Disconnect the pedal from the simulator harness.
3. Lay the pedal assembly on the bench, with the extension spring pointing up at the front. See Figure 3-11 for an illustration of the pedal.
4. Disconnect the cable from the cable spring.
5. Remove the two retaining rings from either end of the pivot pin and take out the pivot pin.
6. Take out the springs. If you replace the compression spring, be sure that the large end of the spring is against the base plate when you put the pedal assembly together again.
7. Install the new spring and replace the pivot pin.
8. Rewind the pulley cable in the following way:
   a. Put the large circular lug on one end of the cable around the hook on the pedal. See Figure 3-10, Step A. Thread the rest of the cable up through the hole in the base plate.

      Wrap the cable counterclockwise around the pulley up to the cap screw. Put the cable through the notch and wrap it once, clockwise, around the cap screw in the pulley. (This screw must be at the top of the pulley. If it is not, turn the pulley so it is.)
   b. Bring the cable back through the notch and wrap it twice, counterclockwise, around the pulley. Do not wrap the cable over itself. See Figure 3-10, Step B. Hook the small circular lug onto the cable spring. The cable spring should be stretched out. Push the pedal a few times to make sure the cable returns the pedal to the rest position.
9. Lubricate the pivot pin, springs, cable, and pulley with dry Teflon spray before you put the assembly back in the simulator.
10. Install the pedal in the simulator and re-connect the harness. Make sure the ground wire is attached.
11. Go to the *Set Controls* screens in the self-test and re-initialize the controls.

NOTE

You must go through the Set Controls *screens in the self-test because you replaced the potentiometer. The simulator will not work right if you do not set the controls.*

Shifter Assembly

If you have problems with the shifter, check Table 3-9, *Troubleshooting the Shifter Assembly.*

If the shifter is not working but you cannot repair it immediately, you can disable the shifter circuit. When the shifter circuit is disabled, the simulator drives only with the automatic transmission, even if the driver chooses manual transmission. The driver can shift, but this has no effect. Disable the shifter circuit only as a *temporary* measure. Repair the shifter as soon as possible.

To disable the shifter, go to the screen *Disable Broken Controls* in the self-test. Choose *broken* under shifter. Remember to change this setting back to *working* when you repair the shifter.

Installing a New Shifter Boot

If you replace the boot, you must replace the foam cushion inside it too. The foam should come with wide double-sided tape wrapped around it. However, if the foam cushion comes without the tape, order Atari Games part number 178051-001.

The shifter is shown in Figure 3-12.

1. Loosen the self-locking screw in the shifter knob and take off the knob.
2. Remove the four tamperproof screws that hold the boot cover plate on the shifter case. Lift off the boot and the cover plate.
3. Discard the boot and the foam cushion.
4. If the cushion does not have tape on it, remove the covering on one side of the tape and put it around the outside of cushion. Make sure it is securely attached.
5. With the tape on the cushion, take the outside cover off the tape and install the cushion in the boot. Press the foam against the boot so the tape holds the foam securely in place.
6. Replace the boot.
7. Install the cover plate and the screws. Put the knob on.

Removing the Reverse Latch Pin

See the information in Chapter 2, in the *Game Options* section, under the *Reverse* option. Reverse is not required for the simulator to work correctly.

Replacing a Shifter Potentiometer

If the shifter acts erratically, follow the flowchart in Figure 3-10 to make sure that the problem is with the potentiometers. Before you replace the potentiometers, check that the screws on the ends of the roll link and the pitch link are tight but still allow free movement. If you tighten these screws, do the *Set Controls* screens in the self-test to see if the problem is solved.

The shifter is shown in Figure 3-12.

1. Loosen the self-locking screw in the shifter knob and take off the knob.
2. Remove the four tamperproof screws that hold the boot cover plate on the shifter case. Lift off the boot, the cover plate, and the shifter gate, which has the shift pattern in it.
3. Remove the screw on the tie wrap that holds the clutch harness on the side of the case.
4. Unscrew the nut on the carriage bolt on the left side of the case and slip the long thin pitch bar off the bolt.

Table 3-9 Troubleshooting the Shifter Assembly

Problem	Solution
Shifter does not work or works erratically.	1. Go through the *Set Controls* screen in the self-test. 2. See Figure 3-10 to determine the cause of the problem. 3. Check voltage level to the main PCB. See Table 3-3. 4. Check the F4 fuse on the power supply. (If this is blown, then the brake pedal will not work either.) 5. Check the setting of the shifter option on the *Disable Broken Controls* screen. If the shifter potentiometer is not working, set it to *broken* and repair as soon as possible. If it is working, set the option to *working*.
Moves in and out of gear freely without using the clutch.	Check the shifter PCB and magnet.
Shifter squeaks and squeals.	Some noise is normal. If you think the noise is excessive, replace the magnet or the magnet plate.



Figure 3-12 Shifter Is Not Working or Working Erratically and You Have Already Tried the *Set Controls* Screens

5. Inside the case, remove the cotter pin on the right side of the pivot shaft.
6. Push the pivot shaft out of the case through the hole on the outside of the cabinet. Use a screwdriver or a pencil. Disconnect the six-pin connector on the simulator harness from the shifter. Lift the shifter assembly out of the case.
7. Test the locknuts on the end of the roll link and the pitch link and the shoulder screws on the thin roll bar and pitch bar. These should be tight but still allow free movement of the bar and attached link. If these are fine, then go to the next steps. Otherwise, tighten them, assemble the shifter, do the *Set Controls* screens, and check the results on the *Control Inputs* screen.
8. If the screws and nuts are tight, disconnect the harness from the potentiometer that you are replacing. Loosen the nut on the potentiometer shaft with a 1/2-inch flat wrench. Remove the potentiometer.
9. Solder the harness to the new potentiometer. With the shaft facing you and the terminals pointing down, solder the black wire to the left terminal, the white to the middle, and the red to the right.
10. Install the new potentiometer. Put the potentiometer key in the key slot in the shifter. Tighten the nut.



Figure 3-13 Maintaining the Shifter

11. Put the shifter assembly back in the case. Attach the pitch bar to the carriage bolt at the top of the case with the locknut.
12. Attach the simulator harness assembly. Install the screw through the tie wrap on the clutch harness on the side of the shifter case.
13. Line up the tube for the pivot shaft with the holes in the case for the pivot shaft. Insert the shaft into the case from the driver's side with the cotter pin hole on the right and the slotted end on the left.
14. With the pivot shaft through both sides of the case, put a screwdriver on the slotted end and turn the shaft until the holes in the shaft line up with the holes in the tube. Put in the cotter pin. Do not bend the legs of the cotter pin.
15. Put the shifter gate back on, with the latch and the spring facing down. Then put the boot with the foam cushion on, then the boot cover plate. Install the four tamperproof screws. Install the knob.
16. Go into the self-test and perform the *Set Controls* screens.

NOTE

You must perform the Set Controls *screens because you replaced the potentiometer. Otherwise the simulator will not operate correctly.*

Replacing the Shifter Magnet or Plate

If the shifter squeaks or squeals excessively, you may want to replace the shifter magnet or the plate it rides on. To determine which to replace, take the shifter out of its case, as described below, and check the magnet and the magnet plate. The shifter is shown in Figure 3-12.

1. Loosen the self-locking screw in the shifter knob and take off the knob.
2. Remove the four tamperproof screws that hold the boot cover plate on the shifter case. Lift off the boot, the cover plate, and the shifter gate, which has the shift pattern in it.
3. Unscrew the nut on the carriage bolt on the left side of the case and take the long thin pitch bar off the bolt.
4. Take out the cotter pin on the right side of the pivot shaft.
5. Push the pivot shaft out of the shifter case through the hole on the outside of the cabinet. Use a screwdriver or a pencil. Disconnect the six-pin connector on the simulator harness from the shifter. Lift the shifter assembly out of the case.

Check the the welded face of the magnet that rides on the plate. It should be smooth. The magnet laminates should not be separated or damaged.

The magnet plate should be smooth with no gouges or grooves.

Replacing the Magnet

1. Disconnect the wiring from the magnet to the shifter harness.
2. Unscrew the two locknuts that hold the magnet bracket on the hinged plate assembly. Remove the bracket, magnet, spring, and insulator.
3. Install the new magnet, with the insulator, in the bracket with the spring. Install the bracket on the hinged plate assembly and put on the locknuts.
4. Connect the magnet connectors to the shifter harness.

Replacing the Magnet Plate

1. Remove the two locknuts that hold the plate on the side of the case. Take out the plate.
2. Put in the new plate with the smooth finished side out. Tighten the locknuts to hold it.

Installing the Shifter Assembly in the Case

1. Put the shifter assembly back in the case. Attach the pitch bar to the carriage bolt at the top of the case. Attach the simulator harness assembly.
2. Line up the tube for the pivot shaft with the holes in the case for the pivot shaft. Insert the shaft into the case from the driver's side with the cotter pin hole on the right and the slotted end on the left.
3. With the pivot shaft through both sides of the case, use a screwdriver on the slotted end to turn the shaft until the hole in the shaft lines up with the holes in the tube. Put in the cotter pin. Do not bend the legs of the cotter pin.
4. Put the shifter gate back on, with the latch and the spring facing down. Then put on the boot with the foam and boot cover plate. Install the four tamperproof screws. Install the knob.

Seat Assembly

The seat assembly has two controls: the magnet, which locks the seat in position during the game and slows the seat movement if the driver pushes the seat out of the game very fast; and the potentiometer, which senses the position of the seat and adjusts the steering wheel force.

The steering wheel force becomes lighter as the seat is moved closer to the dashboard. This is so small children, who sit very close, can turn the wheel easily.

The seat assembly does not require any regular maintenance, other than checking for obstructions around the seat movement area on the simulator floor and inside on the metal plate the magnet rides on. If you have difficulties with the seat, see Table 3-10, *Troubleshooting the Seat Assembly.*

Three flow charts help you troubleshoot seat assembly problems. Depending on the type of problem you have, use the following flow charts:

- If the seats moves erratically, follow the flowchart in Figure 3-7.
- If the seat does not lock when it should, follow the flowchart in Figure 3-13.
- If the seat locks when it should not, follow the flowchart in Figure 3-14.

Replacing the Seat Rod End Bearings

Replace both rod ends if the seat turns with difficulty, or the seat squeaks as it rotates. The seat assembly is shown in Figure 3-15.

1. Remove the four tamperproof screws that hold each end plate on the mounting box. Take off the end plates. Also remove the bottom cover on the mounting box.
2. The rod ends are attached to the pivot blocks with shoulder screws. Use an Allen-head wrench and a flat wrench to remove the screws and nuts.
3. Take out the rod ends and the pivot arm. Remove both rod ends from the pivot arm. Save the nut on the right rod end.
4. Insert the new right rod end into the pivot arm with the nut on the threads. (The left rod end has left-hand threads and will not fit on the right end.)
5. Carefully set the rod ends and pivot arm length to the following dimensions so that the seat assembly rotates correctly.
   - The distance from the center of the hole in left rod end to the point where it goes into the end of the pivot arm must be exactly 1.25 inches This is for clearance.
   - The distance from center of the hole in one rod end to the center of the hole in the other rod end should be exactly 11.25 inches.
6. Do not tighten the nut on the right rod end yet.
7. Put the rod ends and pivot arm into the seat mounting box, with the right rod end on the right side as you face the simulator. Tighten the socket-head screws and nuts to hold the rod ends on the pivot blocks.

Table 3-10 Troubleshooting the Seat Assembly

Problem	Solution
Action is erratic.	1. Go through the *Set Controls* screen in the self-test. 2. See Figure 3-7, 3-12, or 3-13 to determine the cause of the problem. 3. Check voltage level to the main PCB. See Table 3-3. 4. Check the setting of the seat option on the *Disable Broken Controls* screen. If the seat potentiometer is not working, set it to *broken* and repair as soon as possible. If it is working, set the option to *working.*
Does not turn easily, does not push in and out, or squeaks.	1. Check for obstructions on the simulator floor and inside the bottom of the simulator. 2. Check the rod end bearings. 3. Check the shaft bearings on the seat shaft. 4. Check the main seat bearings. 5. Check the gears on the seat assembly.
Seat does not lock in place when it should.	1. Go through the *Set Controls* screen in the self-test. 2. See Figure 3-12 to find out the cause. 3. Check the APU PCB.
Seat is locked when it should not be.	1. Go through the *Set Controls* screen in the self-test. 2. See Figure 3-14 to find out the cause. 3. Check the APU PCB.
Seat jiggles or twists excessively, and can be pulled up and down.	Does the seat alone do this, or do the seat and the mounting arm jiggle and twist together? If only the seat does it, replace the bearings on the seat pivot. If both the seat and the mounting arm jiggle, twist, and move up and down, replace the main seat bearings.



Figure 3-14 Seat Is Not Locked When It Should Be And You Have Already Tried the *Set Controls* Screens

8. Turn the mounting box until it is parallel to the front of the simulator. The sides of the seat mounting platform should be parallel with the sides of the mounting box too.

   If they are not, then screw the pivot arm in or out of the pivot blocks until the sides are parallel. When the mounting box and seat mounting platform sides are parallel to each other and to the sides of the simulator, tighten the nut on the right rod end.

   Check the alignment a final time.

9. Install the end plates on the mounting box with the tamperproof screws. Put the bottom cover back on.

Replacing Bearings on the Seat Pivot

The seat pivot bearings turns the seat (not the mounting box). Replace the seat pivot bearings if the seat twists or jiggles excessively or you can pull the seat up and down. (If both the seat *and* the mounting box twist and move up and down, the main bearings may need to be replaced.) The seat assembly is shown in Figure 3-15.



Figure 3-15 Seat Is Locked When It Should Not Be And You Have Already Tried the *Set Controls* Screens

1. Remove the tamperproof screws that hold each end plate of the mounting box on the seat assembly. Take off the end plates. Remove the bottom cover on the mounting block.
2. Using a punch, hammer out the spring pin in the seat pivot.
3. When the pin is out of the seat pivot, pull up on the seat and remove it.
4. You will need to take the seat mounting box to a machine shop to do the following items:
   a. Remove the old bearings. (They are press fit.)
   b. Cut down one of the new bearings to 0.6 inch long. This will be the bottom bearing. (You can use a bearing on the bottom that has not been cut down, but it may catch someone's foot.)
   c. Turn the bearings to the following specifications.
      - A shaft with a diameter of 1.249 inches should rotate freely in the bearing when a torque of 10 inch-pounds is applied.
      - A shaft with a diameter of 1.254 inches must *not* fit in the bearing.
   d. Press the bearings on the pivot of the seat mounting plate.
5. Insert the pivot through the new top bearing, the spacer tube, the pivot block, two washers, and the new bottom bearing.
6. Line up the holes for the spring pin in the seat pivot with the holes in the pivot block. Make sure the seat faces the right direction. Put in the spring pin. (You might want to use a 3/8-inch shaft or shoulder screw to hold the position while you are putting in the spring pin.)
7. Make sure the pin is flush with the outer edges of the pivot block.
8. Put the end plate back on and install the four tamperproof screws in each plate.

Replacing the Main Seat Bearings

The main seat bearings are located between the base of the simulator and the seat mounting box. Replace them if the seat mounting box is twisting or jiggling or you can pull the box up and down. (If *only* the seat twists and moves up and down, the seat pivot bearings, not the main bearings, may need to be replaced.) The seat assembly is shown in Figure 3-15.

To replace these bearings, remove the simulator floor and take out the seat assembly. You will need someone to help you.

1. Take out the Phillips-head screws on the back edge of the floor trim, which is the strip of metal across the middle of the floor. Remove the three Phillips-head screws along the front of the simulator under the rubber floor mat.
2. Turn the seat out of the simulator as far as it will go. Use two screwdrivers to lift and pry up the front corner of the floor. Take out the floor.
3. Before you can take out the seat mechanism, take out the coin module and the shifter. Open the top and bottom coin doors and take off the four locknuts on the carriage bolts on the side of the cabinet.
4. Disconnect the harness from the coin module. Remove the bolts and the coin module.
5. Now take out the shifter. Loosen the self-locking screw in the shifter knob and take off the knob.
6. Remove the four tamperproof screws that hold the shifter boot cover plate on the shifter case. Lift off the boot, the cover plate, and the shifter gate. Disconnect the shifter harness.
7. Take off the locknuts on the two tamperproof screws that hold the shifter on the side of the cabinet and remove the screws.
8. Remove the locknuts that hold the shifter on the seat assembly frame. Remove the shifter.
9. Disconnect the simulator harness from the seat assembly. Remove all the screws and nuts that hold the seat assembly in the simulator. Tip the seat back until the seat frame clear the floor. Push the seat assembly towards the pedals until the assembly is out from under the floor.

CAUTION

The gears and potentiometer are on the bottom of the assembly under the floor in front of the license plate. Do not damage these parts when you push the seat assembly forward and up.

---

10. When the assembly is clear of the floor, pull the assembly out of the simulator.

WARNING

The seat assembly is heavy. Be careful.

---

11. Remove the four tamperproof screws that hold each end plate of the mounting box on the seat assembly. Take off the end plates. Remove the bottom cover on the mounting block.
12. Remove the rod ends and the pivot arm from the pivot block inside the mounting box. The rod ends are attached to the pivot blocks with shoulder

screws. Use an Allen-head wrench and a flat wrench to remove the screws and nuts. Take out the rod ends and pivot arm and lay the assembly aside.

13. Remove the potentiometer bracket with the potentiometer gear and small gear from the bottom of the seat assembly.
14. Remove the large half gear on the bottom of the main shaft. You may want to turn the assembly on its side to do this.
15. Using a punch, hammer out the spring pin in the bottom of the main shaft in the magnet arm. Remove the magnet arm.
16. Turn the seat until you can pull the seat mounting box off the seat assembly frame.
17. Take the seat assembly frame to a machine shop to do the following items:
    a. Remove the old bearings. (They are press fit.)
    b. Turn the new bearings to the following specifications.
       - A shaft with a diameter of 1.624 inches should rotate freely in the bearing when a torque of 10 inch-pounds is applied.
       - A shaft with a diameter of 1.629 inches must *not* fit in the bearings.
    c. Press the new bearings into the seat frame.
18. Insert the main shaft through the top bearing, the shaft holder, the bottom bearing, and the magnet arm.
19. Line up the hole in the shaft for the spring pin with the hole in the magnet arm. Make sure the seat faces the right direction. Install the spring pin.
20. Put the rod ends and pivot arm assembly back into the seat mounting box, with the right rod end on the right side. Tighten the shoulder screws and nuts to hold the rod ends on the pivot blocks. Do not install the end plates or the bottom cover on the mounting box until the seat assembly is in the simulator.
21. Install the potentiometer bracket tightly on the bottom of the assembly.
22. Turn the small gear on the potentiometer shaft until its set screw is directly below the center terminal on the potentiometer.
23. Turn the seat so that when the large half gear is installed, the flat edge is opposite the small gear and is parallel to the sides of the assembly. Install the gear. Tighten the screws well.
24. Lift the assembly into the simulator. Push it forward and then back to ease it into position, under the floor. Be careful not to damage the gears and the potentiometer.
25. Install all the screws and nuts that hold the seat assembly in the simulator.
26. Reinstall the coin box and re-connect the harness.
27. Put the shifter back in the simulator. Put the locknuts on the tamperproof screws and the carriage bolts. Re-connect the harness.
28. Put the shifter gate back on, with the latch and the spring facing down. Then put on the boot with the foam cushion and install boot cover plate over the boot. Install the four tamperproof screws in the cover plate. Install the knob.
29. Re-install the floor. Put in the screws in the front of the floor and in the metal floor trim.
30. Turn the mounting box until it is parallel to the front of the simulator. The sides of the seat mounting platform should be parallel with the sides of the mounting box too.

    If they are not, then screw the pivot arm in or out of the pivot blocks until the sides are parallel. When the mounting box and seat mounting platform sides are parallel to each other and to the sides of the simulator, tighten the nut on the right rod end.

    Check the alignment a final time.
31. Install the end plates on the mounting box with the tamperproof screws. Put the bottom cover back on.
32. Enter the self-test and go through the *Set Controls* screens.

NOTE

You must go through the Set Controls *screen in the self-test because you repaired the seat assembly. If you do not do this, the seat will not work right.*

Replacing the Gears on the Seat Assembly

If the seat is not turning easily or does not turn at all, do the following:

- Check for obstructions on the simulator floor.
- Check for obstructions on the magnet plate below the floor. Do the following:
  1. Take out the Phillips-head screws on the back edge of the floor trim, which is the strip of metal across the middle of the floor. Remove the three



Figure 3-16 Maintaining the Seat Assembly

Phillips-head screws along the front of the simulator under the rubber floor mat.

2. Turn the seat out of the simulator as far as it will go. Use two screwdrivers on the front corner of the floor to lift and pry the floor up. Take out the floor.
3. Check for obstructions on the metal plate.

- Check the rod end bearings to make sure they are turning.
- Check for broken or missing gears. Lift up the simulator or turn it on its side, with the seat high, and look through the hole in the bottom of the simulator at the gears.

WARNING

This simulator weighs 750 pounds. Be extremely careful when you lift it, turn it, or work on it so that it does not fall.

Look in the hole directly underneath the main seat shaft. You should see two gears. The small gear is mounted on the potentiometer. The large gear is mounted on the bottom of the main shaft.

If the gears are broken, cracked, or missing, you must replace them.

Replacing the Small Gear

1. Remove socket-head screws which hold the potentiometer bracket in the simulator and pull the potentiometer bracket and the small gear a little ways out of the simulator. See Figure 3-15.
2. Loosen the small set screw on the small gear hub. Use a 5/64-inch Allen wrench. Pull off the gear.
3. Turn the potentiometer in the bracket until the flat of the potentiometer shaft is directly below the center terminal.
4. Install the bracket in the simulator. Make sure the socket-head screws in the bracket are tight so it will not fall off.
5. Turn the seat so that the flat edge of the large half gear is opposite the potentiometer and is parallel to the sides of the simulator.
6. Install the new gear on the potentiometer shaft. Do not turn the shaft while you are putting the gear on. Put Loktite on the set screw. Tighten the set screw.
7. Put the simulator back on the floor.
8. Go into the self-test and perform the *Set Controls* screens.

NOTE

You must go through the Set Controls *screen in the self-test. If you do not do this, the seat will not work right.*

Replacing the Large Gear

1. Turn the seat so it will not move.
2. Remove the two socket-head screws holding the large gear on the main shaft. Take off the gear.
3. Install the new gear. Make sure that it meshes with the small gear. Tighten the socket-head screws so the gear will not fall off.
4. If the seat did not turn or move while you were replacing this gear, you are done. If the seat ***did*** move, do the following:
   a. Take out the potentiometer bracket. Turn the small gear until its set screw is directly below the center terminal on the potentiometer.
   b. Turn the seat so that the flat edge of the large half gear is parallel to the front of the simulator and is opposite the place where the potentiometer bracket is installed.
   c. Install the potentiometer bracket in the simulator. Make sure the gears do not turn from the position they are set in. Tighten the socket-head screws on the bracket.
   d. Put the simulator back on the floor.
5. Go into the self-test and perform the *Set Controls* screen.

NOTE

You must go through the Set Controls *screen in the self-test. If you do not do this, the seat will not work right.*

Replacing the Magnet on the Seat Assembly

Before you replace the magnet because the seat does not lock, go through the flowchart in Figure 3-13 to make sure the magnet is the problem.

You must remove the floor as described in steps 1 and 2, below, to get access to the magnet.

1. Remove the Phillips-head screws on the back of the floor trim, which is the strip of metal across the middle of the floor.

2. Remove the three Phillips-head screws along the front of the simulator under the rubber floor mat. Turn the seat out of the simulator as far as it will go. Pry up the floor using two screwdrivers. Remove the floor.
3. Turn the seat so you can see the magnet. The magnet is attached to the arm by a bracket that permits the magnet to move freely. Check the harness to the magnet.
4. After going through the flowchart in Figure 3-13 and determining that the magnet must be replaced, do the following steps.
5. Unscrew the two Phillips-head screws that hold the magnet on the magnet bracket and disconnect the harness.
6. Discard all the hardware that came with the new magnet and install the magnet with the Phillips-head screws and nuts. Re-connect the harness.
7. Re-install the floor. Insert the screws that hold the floor and the metal floor trim in the simulator.

Replacing the Seat Potentiometer

Replace seat potentiometer if you have tried the *Set Controls* screens, you have followed the flowchart in Figure 3-7, and you are sure the problem is the potentiometer. (If the seat does not lock or locks when it should not, the problem is *not* the potentiometer.)

If you cannot repair the seat immediately, you can disable the seat potentiometer circuit. Read about what the seat potentiometer circuit does before you disable it with the *Disable Broken Controls* screen.

The seat potentiometer senses the location of the seat which determines the steering wheel force. The closer the seat is to the dashboard, the lighter the force is on the steering wheel. This is so small children, who sit very close, can turn the steering wheel easily. If you disable the seat potentiometer circuit, the steering wheel force is light in all positions. (If the *Steering Wheel Force* in the *Game Options* screen is set to *medium* (the default) the force will be light. If it is set to *light*, the force will be very light.)

Operate the simulator with the seat potentiometer circuit disabled *only a temporary measure*. Repair the seat potentiometer as soon as possible. Disable the circuit by going to the screen *Disable Broken Controls* in the self-test and choosing *broken* under *seat pot*. After you repair the potentiometer, remember to choose *working* again.

The potentiometer is mounted next to the end of the main shaft on the seat and has soldered connections. The seat is shown in Figure 3-15.

To replace the potentiometer, turn the simulator on its side or securely prop up the front of the simulator. In either case, you will need help, since the simulator is very heavy. You may find it easier to work on the simulator by turning it on its side, with the corner with the seat shaft high.

WARNING

This simulator weighs 750 pounds. Be extremely careful when you lift it, turn it, or work on it so that it does not fall.

---

1. In the hole directly underneath the main seat shaft, you can see two gears. The small gear is mounted on the potentiometer in the potentiometer bracket. Remove the socket-head screws that hold the potentiometer bracket in the simulator and bring the potentiometer bracket out of the simulator.
2. Loosen the set screw on the small gear hub. Use a 5/64-inch Allen wrench.
3. Loosen the locknut on the potentiometer shaft and take the potentiometer out of the bracket. Take off the harness wires. Leave the ground wire attached to the bracket.
4. Put the new potentiometer in the bracket, and put the key in the hole in the bracket. The connectors should be on the same side as the ground wire bracket. Tighten the nut on the shaft.
5. Bend the potentiometer connectors up, but not so they touch the bracket. Solder the black wire nearest the ground wire, the yellow wire in the middle, and the red wire on the other side.
6. Install the bracket back in the game. Tighten the socket-head screws on the bracket so it will not fall off.
7. Turn the potentiometer until the flat of the potentiometer shaft is directly below the center terminal.
8. Turn the seat so that the flat edge of the large half gear is opposite the potentiometer and is parallel to the sides of the simulator.
9. Install the new gear on the potentiometer shaft. Do not turn the shaft or the seat while you are putting the gear on. Put Loktite on the set screw. Tighten the set screw.
10. Put the simulator back on the floor.
11. Go into the self-test and perform the *Set Controls* screens.

Video Display

If you have problems with the video display, check Table 3-11, *Troubleshooting the Video Display,* before you remove the display.

Removing the Video Display

Perform the following procedure to remove the video display. (See Figure 3-16.)

1. Turn the simulator power off and wait two minutes. Leave the power cord plugged in.

WARNING

High Voltage

The video display contains lethal high voltages. To avoid injury, do not service this display until you observe all precautions necessary for working on high-voltage equipment.

X-Radiation

The video display is designed to minimize X-radiation. However, to avoid possible exposure to soft X-radiation, never modify the high-voltage circuitry.

Implosion Hazard

The cathode-ray tube may implode if struck or dropped. The shattered glass from the tube may cause injury up to six feet away. Use care when handling the display.

---

2. While you wait, remove the six screws that hold the small top service panel on the simulator.
3. Disconnect the simulator harness to the attraction sign. Remove the large outside panel that the attraction sign is mounted on by taking off the carriage bolts that hold the panel on the simulator.
4. Discharge the high voltage from the cathode-ray tube (CRT). The display assembly contains a circuit for discharging the high voltage to ground when power is removed. However, to make certain, always discharge the display as follows:
   a. Attach one end of a solid 18-gauge wire to a well-insulated screwdriver or wooden handle.
   b. Attach the other end of the wire to an earth ground.
   c. Quickly touch the blade end of the screwdriver to the CRT anode by sliding it under the anode cap.
   d. Wait two minutes and repeat part c.
5. Disconnect the harness connectors from the video display.
6. Remove the motor amplifier assembly from the cabinet side.
7. Remove the four screws and washers that hold the video display on the shelf.
8. Pull the video display out of the back of the cabinet.

WARNING

When you take the video display out of the cabinet, do not drop it! The display is heavy. Be careful!

Wear gloves to protect your hands fro m the sheet-metal edges.

---

9. Replace the video display as described in the following procedure.

Replacing the Video Display

Perform the following procedure to replace the video display in the cabinet. (See Figure 3-16.)

Table 3-11 Troubleshooting the Video Display

Problem	Solution
Any problem.	Determine if the problem is with the display or the simulator hardware by performing the self-test. If you cannot perform the self-test, use the DIP switch diagnostics to narrow down the source of the problem.
	Check the voltage level to the video display PCB.
Convergence, purity or color problems.	Check the video display settings with the Monitor Test Screens in the self-test.



Figure 3-17 Removing the Video Display

NOTE

Before you replace the display in the simulator, clean the screen and the inside of the shield. Carbon particles from the motor collect on the surfaces and obscure the view.

---

1. Carefully lift the video display onto the display shelf in the cabinet.

NOTE

When you replace the cathode-ray tube and yoke together, adjust the brightness, size, and centering as described in the video display service manual.

Check the purity and convergence according to the service manual instructions, but adjust both only if required.

---

2. Position the display so that the four holes in the video display mounting brackets line up with the four holes in the video display shelf.
3. Loosely install the four hex-head screws and washers through the mounting brackets and into the video display shelf.
4. Push the video display forward against the bezel.
5. Be sure that the display is centered horizontally in the bezel. Tighten the screws.
6. Install the motor amplifier assembly on the side of the cabinet.
7. Connect the harness connectors to the video display.
8. Replace the large and small top service panels.

Motor Amplifier Assembly

Removing the Motor Amplifier Assembly

1. Turn the simulator power off and wait two minutes. Leave the power cord plugged in.

WARNING

The PCBs in this assembly contain lethal high voltages. To avoid injury, do not remove the assembly until you observe all precautions necessary for working on high-voltage equipment.

2. Unplug the power cord.
3. Take off the harness to the PC boards.
4. Remove the entire assembly from the cabinet. Do not remove the PC boards from the heat sink.
5. Send the entire assembly back to your distributor for trade-in.

Speakers

If you have problems with a speaker, check Table 3-12, *Troubleshooting the Speakers*, before you replace it.

Removing a Speaker

1. Turn the simulator power off.
2. Remove the dashboard, following the directions in the section *Removing the Dashboard*.

CAUTION

Be careful when handling the speaker. The cone material is fragile and can be easily damaged.

3. Remove and replace the speaker.
4. Install the dashboard, following the directions in the section *Installing the Dashboard*.

Static-Sensitive Devices

Replacing Static-Sensitive Devices

Be careful when you work with static-sensitive devices on the simulator PCBs. These devices can be microprocessors, field-effect transistors (FET), complementary metal-oxide semiconductors (CMOS), and other large-scale integration (LSI) devices that use metal-oxide semiconductor (MOS) technology.

These devices can fail from a static charge that has built up in your body. They can also fail because of leakage from an improperly grounded soldering iron.

Before you handle a static-sensitive device or a PCB with such devices attached to it, ground any static voltage that may have accumulated in your body by touching an object that is earth-grounded. If you solder a static-sensitive device, use a soldering iron with a properly grounded three-wire cord.

Before you replace a static-sensitive device, make sure that the device actually is defective. A static-sensitive device can appear defective due to leakage on a PCB.

Table 3-12 Troubleshooting the Speakers

Problem	Solution
No sound	Make sure the volume is turned up.
	If the volume is turned up, do the following:
	Do the self-test to make sure you do not have a sound PCB problem.
	Check the voltage level to the sound PCB.
	Check the wiring.
	Replace the speaker if defective.
	If none of the above work, the problem may be on the APU PCB or the main PCB.

To check if a device is defective, ground any static voltages as described in the paragraph above. Clean both sides of the PCB with flux remover or an eraser. For discrete FETs, clean thoroughly between the gate, drain, and source leads. Then test the device.

A new static sensitive device may be packaged in conductive foam or may have a protective shorting wire attached to the pins. Remove the conductive foam just prior to inserting the device into its socket or soldering it to a PCB. Remove the shorting wire only after the device is inserted into its socket or after all the leads are soldered in place.

Cleaning the Coin Mechanism

Use a soft-bristled brush to remove loose dust or foreign material from the coin mechanism. Use a toothbrush to remove any stubborn build-up of residue in the coin path. After cleaning the coin mechanism, blow out the dust with compressed air.

Cleaning the Interior Components

Perform the following procedure to clean the components inside the cabinet.

1. Open the small top service panel and bottom service door.
2. Discharge the high voltage from the cathode-ray tube (CRT) before proceeding. The display assembly contains a circuit for discharging the high voltage to ground when power is removed. However, to make certain, always discharge the display as follows:

WARNING

Turn off the AC power, but do not unplug the power cord before cleaning inside the cabinet. The power cord provides a ground path for stray static voltages that can be present on the cleaning tools.

---

   a. Attach one end of a solid gauge wire to a well-insulated screwdriver or wooden handle.
   b. Attach the other end of the wire to an earth ground.
   c. Quickly touch the blade end of the screwdriver to the CRT anode by sliding it under the anode cap.
   d. Wait two minutes and repeat part c.
3. Use a vacuum cleaner with a soft long-bristled brush attachment or use a soft-bristled paint brush to remove loose dirt and dust accumulated on the inside of the cabinet. Be sure to clean the power supply, PCB assemblies, and video display thoroughly.

CAUTION

Be extremely careful when cleaning the electrical components inside the cabinet. Do not touch the electrical components with any solid object other than the soft bristles of the vacuum attachment or paint brush.

Chapter 4

Illustrated Parts Lists

This chapter provides information you need to order parts for your game.



The parts lists (except for the PCB parts lists) are arranged alphanumerically by Atari part number. All A-prefix numbers, which are assemblies, come first. Next are part numbers with six numbers followed by a hyphen (000598- through 201000-). Ending the list are part numbers with a two-number designation followed by a hyphen (00- through 99-).

The PCB parts lists are arranged in alphabetical order by component. Within each section the parts are arranged numerically by part number.

When you order parts, give the part number, part name, the number of this manual, and the serial number of your game. With this information, we can fill your order rapidly and correctly. We hope this will create less downtime and more profit from your games.



Atari Games Customer Service phone numbers are listed on the inside front cover of this manual.



Figure 4-1 Cabinet-Mounted Assemblies, Front View A046250-01 F



Not Shown:

A043705-01
Fan Cord Assy

A046338-01
Attraction Harness Assy

A046321-01
Main Harness Assy

A046322-01
Power Harness Assy

A046323-01
AC Harness Assy

A046324-01
Video Harness Assy

A046325-01
Motor Interconnect Harness Assy

A046326-01
PCB Interconnect Harness Assy

A046335-01
Shifter Ribbon Cable Assy

A046336-01
Motor Ribbon Cable Assy

A046337-01
PCB Ribbon Cable Assy

A039254-01
Component Bracket Harness Assy

046401-02
Top Rt. Decal

046409-01
Lft. Inner Decal

148007-104
Speaker

178126-002
Tamperproof Hex Key Driver

75-015F
1/4 Black Washer

82-8532B
1/4 Button-Hd Screw
(holding attraction frame to attraction sign sub-assy)

Figure 4-1 Cabinet-Mounted Assemblies, Front View, Continued
A046250-01 F



Figure 4-1 Cabinet-Mounted Assemblies, Rear View
A046250-01 F

Cabinet-Mounted Assemblies
Parts List

Part No.	Description
A043705-01	12-Inch Fan Cord Assembly
A043910-01	On/Off Harness Assembly
A043932-01	Shifter PCB Assembly (See Figure 4-13)
A044431-01	APU PCB Assembly (mounted on Power Supply Assembly) (See Figure 4-12)
A044817-01	Brake PCB Assembly (mounted on Clutch and Brake Assembly) (See Figure 4-14)
A045195-01	Motor Amplifier Assembly
A045988-XX	Hard Drivin' Main PCB Assembly[1] (See Figure 4-11)
A047046-02	ADSP PCB Assembly
A046252-01	Control Panel Assembly (See Figure 4-3)
A046253-01	Coin Box Assembly
A046254-01	Attraction Assembly. Replaceable Parts:
A046300-01	Attraction Sign Sub-Assembly
A046338-01	Attraction Harness Assembly
046304-01	Attraction Decal
046307-01	Attraction Shield
046308-01	Attraction Cover
170003-001	18-Inch, 15 Watt Fluorescent Light
171086-001	18-Inch Fluorescent Lamp Fixture
178232-001	Fluorescent Lamp Retaining Clip
75-010S	#10 Washer
75-99511	#10 Nut/Washer Assembly
82-8108B	#10-24 x 1/2-Inch Black Screw
A046256-01	Cabinet
A046321-01	Main Harness Assembly
A046322-01	Power Harness Assembly
A046323-01	AC Harness Assembly
A046324-01	Video Harness Assembly
A046325-01	Motor Interconnect Harness Assembly
A046326-01	PCB Interconnect Harness Assembly
A046335-01	Ribbon Cable Assembly to the Shifter
A046336-01	Ribbon Cable Assembly to the Motor
A046337-01	Ribbon Cable Assembly to the PCBs
A046340-01	Component Bracket Assembly
A039254-01	Component Bracket Harness Assembly
A046341-01	Coin Counter Assembly
119006-103	10 KΩ Potentiometer Audio Taper
160034-241	Slide Switch
160049-001	Push-Button Switch
A046345-01	Power Supply Assembly (See Figure 4-10)
A046355-XX	Seat Assembly[2] (See Figure 4-2)
A046380-01	Clutch And Brake Pedal Assembly (See Figure 4-7)
A046403-01	Gas Pedal Assembly (See Figure 4-8)
A046486-01	Shifter Assembly (See Figure 6-6)
A046491-01	Sound PCB Assembly
038091-01	Cash Box

Part No.	Description
045949-01	Right Canopy
045950-01	Left Canopy
045951-01	Center Canopy
046255-01	Coin Box Shroud
046278-01	Front Floor Panel[3] (for Seat Assembly A046355-01)
046280-01	Bottom Service Door
046281-01	Large Top Service Panel
046284-01	Small Top Service Panel
046294-01	Floor Trim
046296-01	Front Canopy Support
046297-01	Center Canopy Retainer
046299-01	Display Shield Retainer
046309-01	Attraction Frame
046313-01	Monitor Shield
046316-01	Under-Dash Cover
046390-02	Bumper Pad
046401-01	Top Left Decal
046401-02	Top Right Decal
046402-01	Video Display Bezel
046405-01	Bottom Left Decal
046405-02	Bottom Right Decal
046409-01	Left Inner Decal
046409-02	Right Inner Decal
046410-01	Number Plate Decal
046415-01	Hole Cover Plate
047049-01	Front Floor Panel[3] (for Seat Assembly A046355-03)
139019-001	25-Inch Framed Color Raster, Medium Resolution Video Display
148007-104	4 1/2-Inch Diameter, 8Ω, 10W Shielded Speaker
171002-001	Exhaust Fan
171027-001	Coin Door (See Figure 4-9)
175004-706	.154 I.D., .375 O.D. Fiber Washer
175004-708	.190 I.D., .640 O.D. Fiber Washer
176020-208	#8 x 1/2-Inch Black Phillips-Head Screw
176020-212	#8 x 3/4-Inch Black Phillips-Head Screw
176020-220	#8 x 1 1/4-Inch Black Phillips-Head Screw
176025-3620	1/4 Black Tamperproof Screw
176033-1610	#6 x 5/8-Inch Phillips-Head Screw
177000-144	1/4 Hex Nut
177010-244	1/4-20 Polymer Locknut
177010-440	#10-24 Polymer Locknut
177012-111	Push On Spring Nut
177024-0144	1/4-20 Low Crown Black Nut
178056-002	1/2-Inch Wide Foam Tape
178093-001	Fan Blade Guard

Cabinet-Mounted Assemblies
Parts List

Part No.	Description
178120-606	PCB Standoff
178126-002	Tamperproof Hex Key Driver
178254-016	Double-Coated Acrylic Foam Tape
178255-001	Adjustable Swivel Glide
178257-004	Black Square Finish Plug
178263-0402	1/4-Inch Wide Foam Tape
178274-001	Black Adhesive Back Foam
72-5116	#10-24 Hex Head Screw
72-5520	1/4-20 x 1 1/4 Hex Head Screw
72-5532	4 1/2-Inch Swivel Caster
72-5528	1/4 x 3/4 Inch Hex Head Screw
75-010F	#10 Flat Black Washer
75-010S	#10 Flat Washer
75-015F	1/4 Steel Flat Black Washer
75-015S	1/4 Flat Washer
75-040S	#10 Steel Split-Lock Washer
75-045S	1/4 Steel Split-Lock Washer
75-055B	1/4 Steel Black Oxide Interlock Washer
75-5128B	#10-24 x 1 3/4-Inch Black Carriage Bolt
75-5520B	1/4-20 x 1 1/4-Inch Round Head, Square Neck Black Carriage Bolt
75-5528B	1/4-20 x 1 3/4-Inch Round Head, Square Neck Black Carriage Bolt
75-5540B	1/4-20 x 2 1/2-Inch Black Carriage Bolt
75-07002	1/4 Fender Washer
75-99516	#6-32 Nut/Washer Assembly
75-99518	#8-32 Nut/Washer Assembly
82-8112B	#10-24 x 5/8-Inch Black Hex Socket Button-Head Screw
82-8116B	#10-24 x 1-Inch Black Hex Socket Button-Head Screw
82-8532B	1/4-20 x 2-Inch Black Button-Head Screw
	Documentation for the Hard Drivin' simulator:
SP-327	Hard Drivin' Schematic Package
ST-327	Hard Drivin' Self-Test Label
TM-295	Wells-Gardner 25-Inch, Med Res, Color Display Service Manual (for Model 25K5515)
TM-327	Hard Drivin' Operator's Manual

1 A045988-01 is the U.S. version.

A045988-02 is the German version.

A045988-03 is the right-hand drive British version.

2 A046355-01 is the seat assembly with a 1/4-inch metal plate that is bolted to the left side of the cabinet (as shown in Figure 4-2).

A046355-03 is the seat assembly without a 1/4-inch metal plate that is bolted to the left side of the cabinet .

A046355-03 replaces A046355-01.

3 Front floor panel 046278-01 goes with seat assembly A046355-01. It has the cutout for the metal plate on the seat assembly that is bolted to the left side of the cabinet.

Front floor panel 047049-01 goes with seat assembly A046355-03. However, seat assembly A046355-03 can use front floor panel 046278-01 if it is already installed.



Figure 4-2 Seat Assembly
A046355-XX[1] E

Seat Assembly
Parts List

Part No.	Description
A046333-01	Seat Harness Assembly
A046334-01	Seat Flex Harness Assembly
046356-01	Metal Seat Frame
046357-01	Seat Mounting Box
046358-01	Magnet Arm
046359-XX	Seat Mounting Platform[2]
046360-01	Seat Pivot
046361-01	Magnet Pivot Bracket
046362-01	Magnet Bracket
046363-01	Mounting Box End Plate
046364-01	Bottom Cover for Mounting Box
046365-01	Potentiometer Bracket
046366-01	Seat Pivot Arm
046367-01	Modified Gear
046371-01	Tube
046372-01	Seat Shield
046404-01	Seat
046373-01	Magnet
106007-001	Loktite 290
119008-1001	5 KΩ Potentiometer
172017-4616	5/16-18 x 1-Inch Long Shoulder Socket-Head Screw
172017-4628	5/16-18 x 1.75-Inch Long Shoulder Socket-Head Screw
172020-2428	.375-Inch Diameter x 1.75-Inch Slotted Spring Pin
172020-2436	.375-Inch Diameter x 2.25-Inch Slotted Spring Pin
172021-006	3/8-Inch Diameter, 3/8-24 Rod End
172021-106	3/8-Inch Diameter, 3/8-24 Rod End—Left Hand Thread
175012-0155	1.25-Inch I..D. Washer

Part No.	Description
176025-4106	#10-32 x 3/8-Inch Tamperproof Screw
176025-4108	#10-32 x 1/2-Inch Tamperproof Screw
177000-149	3/8-24 Hex Nut
177010-238	#8-32 Polymer Locknut
177010-244	#1/4-20 Polymer Locknut
177010-246	5/16-18 Polymer Lock Nut
177023-001	1/4-20 Toggle Nut
177024-0144	Low-Crown Nut
178100-007	1 5/8-Inch I.D. Bronze Bearing
178100-006	1.25-Inch I.D. Bronze Bearing
178101-007	24-Tooth Spur Gear
72-1828F	#8-32 x 1 3/4-Inch Phillips-Head Screw
72-5516	#1/4-20 x 1-Inch Hex-Head Screw
72-5528	#1/4-20 x 1 3/4-Inch Hex-Head Screw
72-5520	1/4-20 x 1 1/4-Inch Hex-Head Screw
72-5912	5/16-18 x 3/4-Inch Hex-Head Screw
72-8008	#10-32 x 1/2-Inch Socket-Head Screw
75-010F	#10 Flat Black Washer
75-010S	#10 Flat Washer
75-015F	#1/4 Flat Black Steel Washer
75-015S	#1/4 Flat Washer
75-018S	#8 Flat Washer
75-019S	5/16 Flat Steel Washer
75-040S	#10 Split Lock Washer
75-043S	5/16 Steel Split-Lock Washer
75-045S	1/4 Steel Split-Lock Washer
75-055B	1/4 Interlock Washer
75-5520B	1/4-20 x 1 1/4-Inch Round Head, Square Neck Black Carriage Bolt
75-5528B	1/4-20 x 1 1/2-Inch Round Head, Square Neck Black Carriage Bolt
75-07002	1/4 Fender Washer

1 A046355-01 is the seat assembly with 046359-01, the seat mounting platform, which has a 1/4-inch vertical metal plate that is bolted to the left side of the cabinet (as shown in Figure 4-2).

A046355-03 is the seat assembly with 046359-03, the seat mounting platform, without the vertical metal plate on the left side.

A046355-03 replaces A046355-01.

2 046359-01 is the seat mounting platform with the 1/4-inch vertical metal plate that is bolted the the left side of the cabinet.

046359-03 is the seat mounting platform without the 1/4-inch vertical metal plate.

046359-03 replaces 046359-01.

Not Shown:
A046327-01
Key Switch Harness Assy
177010-240
#10-24 Locknut



Figure 4-3 Dashboard Assembly
A046252-01 C

Dashboard Assembly
Parts List

Part No.	Description
A046327-01	Key Switch Harness Assembly
A046328-01	Push Button Harness Assembly
A046445-01	Key Switch Assembly
A046460-01	Steering Assembly
036895-01	Push Button Switch Bezel
046295-01	Control Panel
046408-01	Control Panel Decal
046654-01	Motor Support Plate
106007-001	Loktite 390
160044-001	5V/5mA SPDT Snap-Action Switch
160052-001	Red, Lighted, SPDT Pushbutton Switch
176020-212	8 x 3/4-Inch Phillips-Head Screw
176025-3620	1/4-20 x 1 1/4-Inch Black Tamperproof Screw

Part No.	Description
177000-144	1/4 Hex Nut
177010-240	#10-24 Polymer Locknut
177012-111	Push-On Spring Nut
177024-0144	1/4-20 Low Crown Nut
178233-002	6.3 V "Seat Adjust" Button With Lamp Assembly
72-8512	1/4-20 x 3/4-Inch Socket-Head Screw
75-015F	1/4 Flat Steel Washer
75-045S	1/4 Split-Lock Washer
75-055B	1/4 Interlock Washer
75-5108B	#10-24 x 1/2-Inch Black Carriage Bolt
75-5520B	1/4-20 x 1 1/4-Inch Black Carriage Bolt
75-07002	1/4 Fender Washer
82-8916B	3/8-16 x 1-Inch Black Button-Head Screw

Not Shown:

172020-0614
Spring Pin
72-8006
#10-32 Socket-Head Screw
75-040S
#10 Split-Lock Washer



Figure 4-4 Key Switch Assembly A046445-01 C

Key Switch Assembly
Parts List

Part No.	Description
046446-01	Housing
046447-01	Collar
046448-01	Key
046449-01	Shaft
046450-01	Actuator
107029-001	Lithium Grease
160045-003	SPDT Switch
172020-0814	0.125-Inch x 0.875-Inch Slotted Spring Pin
176008-110	#10-32 x 5/8-Inch Nyloc Socket-Head Screw

Part No.	Description
177010-232	#4-40 Nut
175009-364	Nylon Washer
178001-004	1/2-Inch Retaining Ring
178256-001	Torsion Spring
72-1412S	#4-40 x 3/4-Inch Phillips-Head Screw
72-8006	#10-32 x 3/8-Inch Socket-Head Screw
75-014S	#4 Flat Washer
75-040S	#10 Split-Lock Washer



Figure 4-5 Steering Assembly
A046460-01 C

Steering Assembly
Parts List

Part No.	Description
A046331-01	Steering Assembly Harness
A046332-01	Motor Assembly
046378-01	3/4-Inch Spacer
046454-01	3-Rotation Stop
046455-01	Stop Bracket
046456-01	Potentiometer Bracket
046457-01	Steering Wheel Hub
046458-01	Hub Cover
046459-01	Steering Wheel Hub Decal
046462-01	Rubber Stop
046463-01	Rubber Stop Bracket
046649-01	Steering Motor Support
106007-001	Loktite 390
119018-001	10-Turn Potentiometer
175002-001	0.750-Inch Flat Shaft Washer
176022-3806	#8-32 x 3/8-Inch Thread Lock Hex-Head Screw

Part No.	Description
177010-238	#8-32 Nyloc Nut
177010-260	3/4-16 Nyloc Nut
177011-260	3/4-16 Thin Nyloc Nut
178026-015	3/16-Inch O.D. x 1 3/8-Inch Extension Spring
178099-005	12-Inch Steering Wheel
178181-7806	3/8-Inch Long Steel Spacer
72-8512	1/4-20 x 3/4-Inch Hex-Head Screw
176022-3806	#8-32 x 3/8-Inch Hex-Head Screw
72-8810	#8-32 x 5/8-Inch Hex-Head Screw
72-8816	#8-32 x 1-Inch Hex-Head Screw
75-015S	1/4 Flat Washer (for ground wire
75-018S	#8 Flat Washer
75-045S	1/4 Split-Lock Washer
78-1709	Grease



Figure 4-6 Shifter Assembly
A046486-01 C

Shifter Assembly
Parts List

Part No.	Description
A046329-01	Harness Assembly
046424-01	Reverse Position Latch
046427-01	Knob
046440-01	Reverse Position Latch Bearing
046472-01	Magnet Insulator
046474-01	Boot
046475-01	Boot Cover Plate
046476-01	Shifter Gate
046477-01	Pitch Bar
046478-01	Pitch Link
046479-01	Shifter Housing
046480-01	Hinged Plate (assembled at factory with strain gauge)
046481-01	Roll Bar
046482-01	Roll Link
046483-01	Pivot Shaft
046484-01	Detent Plate
046485-01	Magnet Bracket
046489-01	Magnet
046523-01	Detent Roller
046524-01	Roller Bearing
046525-01	Detent Lever
046560-01	Boot Cushion
046906-01	Magnet Plate
106007-001	Loktite 390
119008-1001	5 KΩ Potentiometer
171087-001	Strain Gauge (assembled at factory with hinged plate)
175002-002	5/8-Inch Flat Washer
176024-4108	#10-32 x 1/2-Inch Self-Locking Socket-Head Screw

Part No.	Description
177000-132	#4 Hex Nut
177000-136	#6-32 Hex Nut
177000-138	#8-32 Hex Nut
177010-238	#8-32 Polymer Locknut
177010-241	#10-32 Polymer Locknut
177010-244	1/4-20 Polymer Locknut
178006-004	Compression Spring
178026-017	Reverse Position Latch Spring
178026-019	Detent Lever Spring
178051-010	Wide Double-Sided Tape
178192-6306	Spring Spacer
72-1010F	#10-32 x 5/8-Inch Pan-Head Screw
72-1408S	#4-40 x 1/2-Inch Pan-Head Screw
72-1608F	#6-32 x 1/2-Inch Pan-Head Screw
72-1818F	#8-32 x 1 1/8-Inch Pan-Head Screw
72-8806	#8-32 x 3/8-Inch Socket-Head Screw
72-8808	#8-32 x 1/2-Inch Socket-Head Screw
72-8810	#8-32 x 5/8-Inch Socket-Head Screw
72-8012	#10-32 x 3/4-Inch Socket-Head Screw
72-E005	#10-32 x .312-Inch Shoulder Screw
72-E802	0.187-Inch O.D. Shoulder Screw
73-00824	1/8-Inch Diameter x 1 1/2-Inch Cotter Pin
75-020S	#10 Flat Washer
75-028S	#8 Flat Washer
75-040S	#10 Lock Washer
75-048S	#8 Lock Washer
75-07007	1/4 Flat Washer
75-5512B	1/4-20 x 3/4-Inch Carriage Bolt
75-5528B	1/4-20 x 1 3/4-Inch Carriage Bolt



Figure 4-7 Clutch And Brake Pedal Assembly
A046380-01 D

Clutch and Brake Pedal Assembly
Parts List

Part No.	Description
A044817-01	Brake PCB Assembly
A046330-01	Brake/Clutch Harness Assembly
A046499-01	Brake Pedal Assembly (includes strain gauge and strain gauge harness)
040249-01	14-Tooth Spur Gear with Hub (Acceptable substitute is part no. 046050-02 when used with part no. 72-8404, screw cap, and part no. 106007-001, adhesive.)
045401-01	Spring Housing Spacer (Acceptable substitutes are part nos. 178266-6620, 178266-3620, 178266-7620, 178266-0620, 178266-2620.)
046379-01	Clutch Bearing Tab
046383-01	Clutch Pedal
046384-01	Cover over Rear Spring Shaft
046385-01	Clutch Spring Housing
046386-01	3-Inch Clutch Shaft
046387-01	4-Inch Clutch Shaft
046388-01	Pedal Pivot Shaft
046389-01	Stop Bracket
046390-01	Bumper Pad
046391-01	Clutch Link
046392-01	Brake Switch Actuator
046393-01	Locking Tab
046394-01	Cover over the Front Spring Shaft
046395-01	Brake Compression Spring
046396-01	Brake End Cap
046397-01	Brake Guide Cap
046398-01	Urethane Brake Spring

Part No.	Description
046399-01	Brake Rod
106007-001	Loktite 390
107013-001	Light Oil
119008-1001	5 KΩ Clutch Potentiometer
160044-001	Snap-Action Brake Switch
171087-001	Strain Gauge (assembled at factory with brake pedal and shaft)
176022-3604	#6-32 x 1/4-Inch Socket-Head Screw
177000-147	#5/16-24 Nut
177010-232	#4-40 Nyloc Nut
177010-236	#6-32 Nyloc Nut
177010-238	#8-32 Nyloc Nut
177010-244	1/4-20 Nyloc Nut
177012-111	Push-On Spring Nut
178012-004	3/8-Inch Diameter Clip Ring
178026-016	Clutch Extension Spring
178120-606	PCB Standoff
178181-3604	1/4-Inch Spacer
178244-220	Actuator Clamp
72-8412	#4-40 x 3/4-Inch Socket-Head Screw
72-8612	#6-32 x 3/4-Inch Pan-Head Screw
72-8808	#8-32 x 1/2-Inch Pan-Head Screw
75-015S	1/4 Flat Washer
75-016S	#6 Flat Washer
175-5520B	1/4-20 x 1 1/4-Inch Black Carriage Bolt
75-5540B	1/4-20 x 2 1/2-Inch Carriage Bolt
75-07002	Fender Washer

Not Shown:
A043947-01
Gas Pedal Harness Assy



All parts shown above make up the Foot Control Assembly, part no. A039235-03 E. The Foot Control Assembly is a large subassembly of the Gas Pedal Assembly, part no. A046403-01.

Figure 4-8 Gas Pedal Assembly A046403-01 A

Gas Pedal Assembly
Parts List

Part No.	Description
A039235-03	Foot Control Assembly. Replaceable Parts:
039236-01	Pivot Pin
039238-01	Pulley
039239-01	Foot Pedal Control Base Plate
039240-01	Foot Pedal Accelerator
039242-01	Cable
039703-01	Cable Extension Spring
039704-01	Pedal Extension Spring
040028-01	Pedal Compression Spring

Part No.	Description
107012-001	Dry Teflon Spray Lubricant
178012-004	Retaining Ring for 3/8-Inch-Diameter Shaft
119008-1001	5 KΩ Potentiometer
72-8606	#6-32 x .38-Inch Socket-Head Screw
A043947-01	Gas Pedal Harness Assembly
046298-01	Foot Pedal Bracket
177010-240	#10-24 Polymer Locknut
75-010S	#10 Flat Washer



Figure 4-9 Coin Acceptors, Inc. Coin Door Assembly 171027-001



NOTE

The acceptable substitute for this door (and the one used in games manufactured in Ireland) is the Coin Controls, Inc. Coin Door Assembly, part number 171034-001.

Figure 4-9 Coin Acceptors, Inc. Coin Door Assembly, Continued 171027-001

Coin Acceptors , Inc. Coin Door Assembly
Parts List

Part No.	Description
160057-001	Coin Switch
70-11-47	Miniature Bayonet Lamp
72-9406S	#4-40 x 3/8-Inch Truss-Head Screw
72-HA1404C	#4-40 x 1/4-Inch Pan-Head Screw
72-JA1405B	#4-40 x .31-Inch Pan-Head Screw
75-1412S	#4-40 x 3/4-Inch Pan-Head Screw
75-994S	#4-40 Locknut
99-10008	Retainer
99-10042	Coin Switch Assembly for Belgian 5 Fr and U.S. 25¢
99-10043	Coin Switch Assembly for German 1 DM, Japanese 100 Yen, Swiss 1 Fr
99-10044	Coin Switch Assembly for German 2 DM, Italian 100 L, U.S. $1.00
99-10045	Coin Switch Assembly for Australian $.20, German 5 DM, British 10 P
99-10068	Coin Return Chute
99-10075	Switch Wire (included in coin switch assembly 99-10043)
99-10076	Switch Wire (included in coin switch assembly 99-10042)
99-10077	Switch Wire (included in coin switch assembly 99-10044)
99-10078	Switch Wire (included in coin switch assembly 99-10045)
99-10080	Lamp Socket

Part No.	Description
99-10081	Key Holder
99-10096	Fastener
99-10104	Bar Retainer
99-10105	Bar
99-10115	Spring
99-10116	Plastic Coin Return Lever
99-10117	Steel Coin Return Door
99-10139	Coin Door
99-10140	Coin Door Inner-Panel Assembly
99-10141	Die-Cast Coin Return Cover
99-10143	Coin Door Frame
99-10144	Channel Clip
99-10147	Harness
99-10148	Lock Assembly
99-10149	Service Door
99-10150	Switch Cover
99-10151	Left Coin Inlet
99-10152	Right Coin Inlet
99-10153	Coin Return Box
99-10154	Bracket Assembly
99-10160	1-Inch Wide Die-Cast Coin Inlet Housing
99-10161	25¢ Amber Side-Entry Coin Button Assembly
99-15066	Screw for Clamp
171006-035	Metal Coin Mechanism for U.S. 25¢

N O T E S

Not Shown
034544-01
Fuse Block Cover



Figure 4-10 Power Supply Assembly
A046345-01 B

Power Supply Assembly
Parts List

Part No.	Description
A042384-01	Line Filter Assembly
A043367-01	Jumper Assembly
A044431-01	Hard Drivin' Audio Power Unit (APU) PCB Assembly
A046346-01	15-Inch Black Jumper Assembly
A046346-02	15-Inch White Jumper Assembly
034544-01	Fuse Block Cover
142044-001	Transformer

Part No.	Description
146008-2022	2 Amp, 250V Slow Blow Fuse
146008-3022	3 Amp, 250 V, Slow Blow Fuse
146008-7022	7 Amp, 250 V, Slow Blow Fuse
149005-002	5 V, 15 A Hitron Switching Power Supply (see below)
179211-001	Terminal Block Jumper
179225-2205	5-Position Fuse Block
179231-002	2-Position Terminal Block

Hitron 5V, 15 A Switching Power Supply Sub-Assembly
Parts List

Part No.	Description
	Transistors
99-211002	Transistor, NPN, 2SC1413A
99-211003	Transistor, NPN, PE8050B
99-211004	Transistor, PNP, PE8550B
99-211062	Transistor, 2SD725
99-211063	Transistor, Pe8550B
	Diodes
99-211005	Diode, Schottky, S10SC4M
99-211006	Diode, Fast Recovery, 30DF1
99-211007	Diode, Zener, 1N752A
99-211008	Diode, Rectifier, 1N4006
99-211009	Diode, Fast Recovery, Rpg10B
99-211010	Diode, Fast Recovery, Rpg10K
99-211011	Diode, Fast Recovery, Rpg15B
99-211012	Diode, Switching, 1N4148
99-211064	Diode, S15SC4M
99-211076	Diode, 31DQ04
99-211013	Rectifier, Silicon Controlled, S2800
	Resistors
99-211014	Potentiometer, Trimming, 3K Ohm
99-211015	Resistor, Wire Wound, 50 Ohm, 5%, 2W
99-211016	Resistor, Wire Wound, 150 Ohm, 5%, 2W
99-211017	Resistor, Wire Wound, 33 Ohm, 5%, 2W
99-211018	Resistor, Wire Wound, 0.47 Ohm, 5%, 2W
99-211019	Resistor, Wire Wound, 120 Ohm, 5%, 2W
99-211020	Thermistor, 0.5 Ohm, 5%, 5W
99-211021	Résistor, 2.2K Ohm, 2%, 1/4W
99-211022	Resistor, Carbon Film, 330 Ohm, 5%, 1/2W
99-211023	Resistor, Carbon Film, 270 Ohm, 5%, 1/2W
99-211024	Resistor, Carbon Film, 470 Ohm, 5%, 1/4W
99-211025	Resistor, Carbon Film, 47 Ohm, 5%, 1/4W

Part No.	Description
99-211026	Resistor, Carbon Film, 330 Ohm, 5%, 1/4W
99-211027	Resistor, Carbon Film, 5.6 Ohm, 5%, 1/4W
99-211028	Resistor, Carbon Film, 8.2 Ohm, 5%, 1/4W
99-211029	Resistor, Carbon Film, 10 Ohm, 5%, 1/4W
99-211030	Resistor, Carbon Film, 39 Ohm, 5%, 1/4W
99-211031	Resistor, Carbon Film, 56 Ohm, 5%, 1/4W
99-211032	Resistor, Carbon Film, 1K Ohm, 5%, 1/4W
99-211033	Resistor, Metal Film, 2K Ohm, 2%, 1/4W
99-211034	Resistor, Carbon Film, 180K Ohm, 5%, 1W
99-211035	Resistor, Carbon Film, 2K Ohm, 5%, 1/4W
99-211065	Resistor, Wire Wound, 27 Ohm, 5%, 2W
99-211066	Resistor, Carbon Film, 6.8 Ohm, 5%, 1/2W
99-211067	Resistor, Carbon Film, 12 Ohm, 5%, 1/4W
99-211068	Resistor.Carbon Film, 2.4 Ohm, 5%, 1/2W
99-211077	Resistor, 470 Ohm, 1/2W, 5%
99-211078	Resistor, 120K Ohm, 1W, 5%
	Capacitors
99-211036	Capacitor, Metal Film, 0.047UF, 250V
99-211037	Capacitor, Metal Film, 0.22UF, 100V
99-211038	Capacitor, Metal Film, 0.1UF, 400V
99-211039	Capacitor, Metal Film, 0.022UF, 100V
99-211040	Capacitor, Ceramic, 1800PF, 2KV, Z5V
99-211041	Capacitor, Ceramic, 0.01UF, 1KV, Z5U
99-211042	Capacitor, Ceramic, 0.001UF, 2KV
99-211043	Capacitor, Ceramic, 470PF, 1KV, Z5P
99-211044	Capacitor, Electrolytic, 470UF, 25V
99-211045	Capacitor, Electrolytic, 220UF, 25V
99-211046	Capacitor, Electrolytic, 100UF, 200V
99-211047	Capacitor, Electrolytic, 1000UF, 25V
99-211048	Capacitor, Electrolytic, 2200UF, 16V
99-211049	Capacitor, Ceramic, 4700UF, 400V

Hitron Power Supply Sub-Assembly, Continued
Parts List

Part No.	Description
99-211069	Capacitor, Electrolytic, 2200UF, 16V
99-211070	Capacitor, Electrolytic, 220UF, 25V
99-211079	Capacitor, De7100F22M
99-211080	Capacitor, 1000UF, 35V
99-211081	Capacitor, 470UF, 25V
99-211082	Capacitor, 220UF, 16V
99-211090	Capacitor, Ceramic, 1000PF, 2KV
99-211091	Capacitor, Electrolytic, 2200UF, 10V
	Inductors
99-211050	Inductor, 7UH
99-211051	Inductor, 7UH, 35MM
99-211052	Inductor, 15MH
99-211053	Inductor, 1.5MH
99-211054	Inductor, 2.2UH
99-211071	Inductor, 9.8UH
99-211084	Inductor, 8UH
99-211085	Inductor, 9.8UH
99-211086	Inductor, 0.75MH
99-211087	Inductor, 2.2UH
99-211088	Inductor, 60MH

Part No.	Description
	Transformers
99-211075	Transformer, Power
99-211083	Transformer, Power
99-211089	Transformer, 4.75MH
99-211092	Transformer
99-211055	Transformer
	Miscellaneous
99-211001	Regulator, UA431AWC
99-211056	Fuse, 2A, 250V
99-211057	Terminal Block, 8CKT
99-211058	Fuse, 2A, 250V, Semko
99-211059	Heatsink
99-211060	Fuse Holder, 6.35MM
99-211061	Heatsink, 1.5MM
99-211072	Fuse Holder, 5.2X20
99-211073	Fuse, 2A, 125V
99-211074	Terminal Block, 9CKT



Figure 4-11 Hard Drivin' Main PCB Assembly
A044425-01 G

Hard Drivin' Main PCB Assembly
Parts List

Designator	Description	Part No.
	Integrated Circuits	
5K	Integrated Circuit, 4464, 64K X 4,DRAM	137546-003
5M	Integrated Circuit, 74F244	137502-001
15B	Integrated Circuit, 74LS374	137144-001
15K	Integrated Circuit, 4464, 64K X 4, DRAM	137546-003
15M	Integrated Circuit, 74ALS245	137440-001
20P	Integrated Circuit, 74ALS574	137548-001
20S, 20U	Integrated Circuit, 74AS823	137513-001
20W	Integrated Circuit, 74AS823	137513-001
25K	Integrated Circuit, 4464, 64K X 4, DRAM	137546-003
25M	Integrated Circuit, 74AS573	137547-001
30B	Integrated Circuit, ADC0809	137243-001
30D	Integrated Circuit, AD7582	137545-001
30P	Integrated Circuit, 74LS245	137134-001
30S, 30U	Integrated Circuit, 2149, 45 nsec	137199-002
30W	Integrated Circuit, 2149, 45 nsec	137199-002
30Y	Integrated Circuit, 74LS245	137134-001
35K	Integrated Circuit, 4464, 64K X 4, DRAM	137546-003
35M	Integrated Circuit, 74ALS245	137440-001
40H	Integrated Circuit, 74LS123	137268-001
40S, 40U	Integrated Circuit, 2149, 45 nsec	137199-002
40Y	Integrated Circuit, 74LS245	137134-001
50B, 50D	Integrated Circuit, 74LS244	137038-001
50H	Integrated Circuit, 74LS123	137268-001
50S, 50U	Integrated Circuit, 74ALS574	137548-001
50W	Integrated Circuit, 74ALS574	137548-001
50Y	Integrated Circuit, 74AS573	137547-001
55L-MSP	Integrated Circuit, 34010-50	137538-002
60P, 60S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
60U, 60W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
65C	Integrated Circuit, 74LS259	137137-001
70P, 70S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
70U, 70W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
75C	Integrated Circuit, 74LS259	137137-001
75H	Integrated Circuit, 74LS14	137056-001
80P, 80S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
80U, 80W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
80Y	Integrated Circuit, 74AS08	137484-001
85C	Integrated Circuit, 74LS374	137144-001
90P, 90S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
90U, 90W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
95C	Integrated Circuit, 74LS374	137144-001
100K	Integrated Circuit, 74LS74	137023-001
100M	Integrated Circuit, 74ALS08	137460-001
100P, 100S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
100U, 100W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
100Y	Integrated Circuit, 74AS08	137484-001
110C	Integrated Circuit, 7406	137052-001
110K	Integrated Circuit, 74ALS138	137517-001
110M	Integrated Circuit, 74ALS138	137517-001
110P, 110S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
110U, 110W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
120H	Integrated Circuit, 74F74	137436-001
120K	Integrated Circuit, 74LS393	137146-001
120M	Integrated Circuit, 74ALS08	137460-001
120P, 120S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
120U, 120W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002

Hard Drivin' Main PCB Assembly
Parts List

Designator	Description	Part No.
130M	Integrated Circuit, 74ALS161	137470-001
130P, 130S	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
130U, 150W	Integrated Circuit, VRAM, 64KX4, 150 nsec (Acceptable substitute is part no. 137553-001, Integrated Circuit, 64X4, VRAM, 120 nsec.)	137553-002
135C	Integrated Circuit, 74F74	137436-001
135H	Integrated Circuit, 74F74	137436-001
135K	Integrated Circuit, 74AS32	137487-001
140C	Integrated Circuit, 74LS244	137038-001
140H	Integrated Circuit, 74LS393	137146-001
140K	Integrated Circuit, 74F11	137583-001
140M	Integrated Circuit, 74ALS574	137548-001
150C	Integrated Circuit, 74LS245	137134-001
150E	Integrated Circuit, 74LS244	137038-001
150H	Integrated Circuit, 74LS74	137023-001
150K	Integrated Circuit, 74LS20	137060-001
150P	Integrated Circuit, 74AS573	137547-001
150S-PSP	Integrated Circuit, 34012-50	137559-001
150U	Integrated Circuit, 74F244	137502-001
150W	Integrated Circuit, 74AS573	137547-001
160C	Integrated Circuit, 74LS244	137038-001
160E	Integrated Circuit, 74ALS161	137470-001
160H	Integrated Circuit, 74ALS32	137464-001
160K	Integrated Circuit, 74ALS138	137517-001
160M	Integrated Circuit, 74F04	137437-001
160P	Integrated Circuit, 74AS573	137547-001
160U	Integrated Circuit, 74AS00	137480-001
160W	Integrated Circuit, 74AS573	137547-001
170C	Integrated Circuit, 74LS245	137134-001
170E	Integrated Circuit, 74LS244	137038-001
170H	Integrated Circuit, 74LS148	137417-001
170K	Integrated Circuit, 74ALS161	137470-001
170P	Integrated Circuit, 74LS244	137038-001
170U	Integrated Circuit, 74AS08	137484-001
180C	Integrated Circuit, 74ALS138	137517-001
180E	Integrated Circuit, 74ALS139	137467-001
180S-GSP	Integrated Circuit, 34010-50	137538-002
180U	Integrated Circuit, 74AS573	137547-001
180W	Integrated Circuit, 74F04	137437-001
180Y	Integrated Circuit, 74AS573	137547-001
190C	Integrated Circuit, 74LS393	137146-001
190E	Integrated Circuit, 74AS00	137480-001
190K	Integrated Circuit, 68010	137414-002
190N	Integrated Circuit, 74LS245	137134-001
190U	Integrated Circuit, 74AS32	137487-001
190W	Integrated Circuit, 74ALS74	137156-001
190Y	Integrated Circuit, 74LS259	137137-001
200A	Integrated Circuit, 68681	137543-001
200C, 200D	Integrated Circuit, RAM, 8KX8, 150 nsec	137535-006
200E	Integrated Circuit, 48T02-15, RAM	137540-150
200F	Integrated Circuit, 74LS245	137134-001
200H, 200J	Integrated Circuit, 74LS244	137038-001
200K	Integrated Circuit, Slapstic 17	137412-117
200L	Integrated Circuit, 74ALS32	137464-001
200M	Integrated Circuit, 74ALS138	137517-001
200N, 200P	Integrated Circuit, 74LS245	137134-001
200R	Integrated Circuit, PR EPROM, 421, 137444-200	136052-7105
200S	Integrated Circuit, PR EPROM, 137444-200	136052-2106
200T	Integrated Circuit, PR EPROM, 137444-200	136052-1107
200U	Integrated Circuit, PR EPROM, 137444-200	136052-1108
200V	Integrated Circuit, PR EPROM, 137444-200	136052-1109
200W	Integrated Circuit, PR EPROM, 137444-200	136052-1110
200X	Integrated Circuit, PR EPROM, 137444-200	136052-1111
200Y	Integrated Circuit, PR EPROM, 137444-200	136052-1112
205B	Integrated Circuit, 4066B	137580-001
210A	Integrated Circuit, MC1488	137403-001
210B	Integrated Circuit, MC1489AL	137263-001
210C	Integrated Circuit, RAM, 8KX8, 150 nsec	137535-006
210D	Integrated Circuit, RAM, 8KX8, 150 nsec	137535-006
210E	Integrated Circuit, 48Z02-15, RAM	137442-150
210F	Integrated Circuit, 74LS245	137134-001
210H	Integrated Circuit, 74LS244	137038-001
210J	Integrated Circuit, 74LS244	137038-001
210K	Integrated Circuit, 74LS244	137038-001
210L	Integrated Circuit, 74LS245	137134-001
210M	Integrated Circuit, 74LS245	137134-001
210N	Integrated Circuit, 74LS244	137038-001
210P	Integrated Circuit, 74LS245	137134-001
210R	Integrated Circuit, PR EPROM, 137444-200	136052-7113

Hard Drivin' Main PCB Assembly
Parts List, Continued

Designator	Description	Part No.
210S	Integrated Circuit, PR EPROM, 137444-200	136052-2114
210T	Integrated Circuit, PR EPROM, 137444-200	136052-1115
210U	Integrated Circuit, PR EPROM, 137444-200	136052-1116
210V	Integrated Circuit, PR EPROM, 137444-200	136052-1117
210W	Integrated Circuit, PR EPROM, 137444-200	136052-1118
210X	Integrated Circuit, PR EPROM, 137444-200	136052-1119
210Y	Integrated Circuit, PR EPROM, 137444-200	136052-1120
	Capacitors	
C1	Capacitor, 100 µF, 35 V, Electrolytic	124000-107
C2	Capacitor, .01 µF, 50 V, Ceramic	122002-103
C3-C43	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C44-C63	Capacitor, .001 µF, 50 V, ±10%	122015-102
C64-C78	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C79	Capacitor, 10 pF, 100 V, Ceramic	122016-100
C80-C82	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C83, C84	Capacitor, 100 pF, 100 V, Ceramic	122016-101
C85-C87	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C88-C91	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C92	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C93	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
C94-C106	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C108-C111	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C112-C118	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C119	Capacitor, 3900 pF, 50 V, Ceramic	122020-392
C120	Capacitor, 560 pF, 50 V, Ceramic	122020-561
C121	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
C122	Capacitor, .0022 µF, 100 V, Plastic	121022-222
C123	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C124	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C125-C128	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
C129-C137	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C138	Capacitor, 1000 pF, 100 V, Ceramic	122016-102
C139	Capacitor, 1000 pF, 100 V, Ceramic	122016-102
C140	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C141	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C142	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C143	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C144	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C145	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
C146-C227	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C228	Capacitor, .001 µF, 50 V, ±10%	122015-102
C229	Capacitor, 47 pF, 100 V, Ceramic	122016-470
C230-C249	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C250	Capacitor, 47 pF, 100 V, Ceramic	122016-470
C251-C273	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C274	Capacitor, 47 pF, 100 V, Ceramic	122016-470
C275-C320	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C322	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
C323-C326	Capacitor, 10 pF, 100 V, Ceramic	122016-100
C330-C333	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C335	Capacitor, 100 pF, 100 V, Ceramic	122016-101
C336	Capacitor, 100 pF, 100 V, Ceramic	122016-101
C337-C342	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C344-C346	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C347	Capacitor, 10 µF, 35 V, Electrolytic	124000-106
	Diodes	
CR1, CR2	Diode, MV5053, Light Emitting	131027-002
CR3, CR4	Diode, 1N914	131052-001
CR5	Diode, 1N4002	131048-002
CR6	Diode, MV5053, Light Emitting	131027-002
CR7, CR8	Diode, 1N4002	131048-002
CR9-CR12	Diode, MV5053, Light Emitting	131027-002
CR13	Diode, 1N4002	131048-002
CR14	Diode, MV5053, Light Emitting	131027-002
CR17	Diode, 1N4733 A, 5.1 V, Zener	131009-206
CR18, CR19	Diode, 1N4002	131048-002
CR20	Diode, 1N4742 A, 12 V, Zener	131009-215
	Transistors	
Q1, Q2	Transistor, 2N6044	133042-001
Q3	Integrated Circuit, 7905	137581-001
Q4	Integrated Circuit, 7812	137597-001
Q5	Transistor, 2N3904	133041-001
Q6	Transistor, 2N3906	133040-001
Q7	Transistor, 2N3904	133041-001
Q8	Transistor, 2N3906	133040-001
Q9	Transistor, 2N3904	133041-001
Q10	Transistor, 2N3906	133040-001
Q11-Q13	Transistor, 2N3904	133041-001
	Resistors	
R1-R26	Resistor, 100 Ω, ±5%, 1/4 W	110000-101
R27-R45	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R46-R48	Resistor, 470 Ω, ±5%, 1/4 W	110000-471
R49-R54	Resistor, 4.7 K Ω, ±5%, 1/4 W	110000-472
R55, R56	Resistor, 100, ±5%, 1/4 W	110000-101
R57, R58	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R61	Resistor, 4.7 K Ω, ±5%, 1/4 W	110000-472
R62, R63	Resistor, 220 Ω, ±5%, 1/4 W	110000-221
R64-R67	Resistor, 5.6 K Ω, ±5%, 1/4 W	110000-562

Hard Drivin' Main PCB Assembly
Parts List, Continued

Designator	Description	Part No.
R68	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R69	Resistor, Metal Film, 56 K Ω, ±1% 1/4 W	110011-5602
R70-R73	Resistor, 220 Ω, ±5%, 1/4 W	110000-221
R74, R75	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R76	Resistor, 220 Ω, ±5%, 1/4 W	110000-221
R77, R78	Resistor, 4.7 K Ω, ±5%, 1/4 W	110000-472
R79	Resistor, 47 K Ω, ±5%, 1/4 W	110000-473
R80, R81	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R82, R83	Resistor, 470 Ω, ±5%, 1/4 W	110000-471
R84-R88	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R89-R96	Resistor, 33 Ω, ±5%, 1/4 W	110000-330
R98-R101	Resistor, 100 Ω, ±5%, 1/4 W	110000-101
R102-R107	Resistor, 33 Ω, ±5%, 1/4 W	110000-330
R109-R111	Resistor, 100 Ω, ±5%, 1/4 W	110000-101
R113-R115	Resistor, 100 Ω, ±5%, 1/4 W	110000-101
R116-R123	Resistor, 33 Ω, ±5%, 1/4 W	110000-330
R124	Resistor, 220 Ω, ±5%, 1/4 W	110000-221
R125-R131	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R132	Resistor, 4.7 K Ω, ±5%, 1/4 W	110000-472
R134	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R144	Resistor, 620 Ω, ±5%, 1/4 W	110000-621
R145, R146	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R147, R148	Resistor, 100 K Ω, ±5%, 1/4 W	110000-104
R149, R150	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R151, R152	Resistor, 220 Ω, ±5%, 1/4 W	110000-221
R155	Resistor, 0 Ω, ±5%, 1/4 W	110005-001
R156-R159	Resistor, 5.6 K Ω, ±5%, 1/4 W	110000-562
R160, R161	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R162, R163	Resistor, 150 Ω, ±5%, 1/4 W	110000-151
R164, R165	Resistor, 10 Ω, ±5%, 1/4 W	110000-100
R166	Resistor, 68 Ω, ±5%, 1/4 W	110000-680
R167	Resistor, 91 Ω, ±5%, 1/4 W	110000-910
RN1, RN2	Resistor Network, 470X9, ±5%, 1/8 W, SIP(10PIN)	118010-471
RN3-RN5	Resistor Network, R2R Ladder	118015-001
RN6	Resistor Network, 4.7KX9, ±5%, 1/8 W, SIP(10PIN)	118010-472
	Crystals	
XOSC1	Osc, 32MHZ	144008-002
XOSC2	Crystal, 48 Mhz, Oscillator Module	144008-003
XOSC3	Crystal, 50 Mhz, Oscillator Module	144008-005
XTAL1	Crystal, 3.6864, Standup	144000-011
	Miscellaneous	
	Socket, 28 Pin, .600"	179257-028
	Socket, 68 Pin	179237-068
	Socket, 64 Pin, .900"	179256-064
	Socket, 40 Pin, .600"	179257-040
	Socket, 20 Pin	179259-020
	Socket, 24 Pin, .600"	179257-024
	Test Point	179051-001
J1	Connector, 12 Circuit, Header .250 Ctr	179069-012
J2-J6	Connector, 11 Circuit, Header, .100 Ctr	179118-011
J7	Connector, 60 Circuit, Header, .100 Ctr	179021-060
J8-J11	Connector, 11 Circuit, Header, .100 Ctr	179118-011
J12	Connector, 9 Circuit, Header, .250 Ctr	179069-009
J14	Connector, 26 Circuit, Header, .1 X . 1 Dual	179261-026
J15	Connector, 16 Circuit, Header, .1 X . 1 Dual	179261-016
SW1	Switch, 8 Pos DIP	160031-008



Figure 4-12 APU PCB Assembly
A044431-01 D

APU PCB Assembly
Parts List

Designator	Description	Part No.
	Capacitors	
C1	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C2	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C3	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C4	Capacitor, .001 µF, 50 V, Ceramic	122002-102
C5	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C6	Capacitor, 22 µF, 35 V, Electrolytic	124000-226
C7-C14	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C15-C18	Capacitor, 3300 µF, 25 V, Electrolytic, Radial	123003-338
C19	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C20, C21	Capacitor, 3300 µF, 25 V, Electrolytic, Radial	123003-338
C22	Capacitor, 22 µF, 35 V, Electrolytic	124000-226
C23	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C24	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C25	Capacitor, .001 µF, 50 V, Ceramic	122002-102
C26	Capacitor, .22 µF, 50 V, Ceramic	122015-224
C27	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C28	Capacitor, 10 µF, 25 V, Electrolytic	124009-106
C29	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C31	Capacitor, 1000 µF, 25 V, Radial	123003-108
	Diodes	
CR1-CR6	Diode, 1N4001	131048-001
CR7-CR12	Diode, 1N5401	131051-002
CR19	Diode, 1N5401	131051-002
	Fuse	
FU2	Fuse, 3 Amp, 250 V, Norm	146007-3022

Designator	Description	Part No.
	Transistors	
Q1, Q2	Integrated Circuit, TDA2030	137301-001
Q3	Integrated Circuit, 7815, Standup	137598-001
Q6	Transistor, TIP33, 40 V, 80 W	133044-001
Q7	Transistor, Mps-U07, 100 V, 2 A	133003-001
	Resistor	
R1	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R2	Resistor, 1 Ω, ±5%, 1/4 W	110000-010
R3, R4	Resistor, 22 K Ω, ±5%, 1/4 W	110000-223
R5	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R6	Resistor, 10 Ω, ±5%, 1/4 W	110000-100
R7	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R8, R9	Resistor, 22 K Ω, ±5%, 1/4 W	110000-223
R10	Resistor, 1 Ω, ±5%, 1/4 W	110000-010
R11	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R20	Resistor, 47 Ω, ±5%, 1/4 W	110000-470
R21	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R22, R23	Resistor, 1Ω, ±5%, 1 W, Carbon Film	110030-010
R24	Resistor, 2.2Ω, ±5%, 1/2 W	110001-022
	Miscellaneous	
FM1, FM2	Fuseclip	179050-002
HS1, HS2	Heatsink, TDA2030	178190-032
HS3	Heatsink, 7815	178190-124
	Connector, 2 Ckt, Header, .156 Ctr	179213-002
	Connector, 9 Circuit, Header, .156 Ctr	179213-009
	Connector, 3 Ckt, Header, .156 Ctr	179213-003
	Connector, 6 Ckt, Header, .156 Ctr	179213-006
	Connector, 9 Circuit, Header, .156 Ctr	179213-009



Figure 4-13 Shifter PCB Assembly
A043932-01 E

Shifter PCB Assembly
Parts List

Designator	Description	Part No.
	Capacitors	
C1	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C2, C3	Capacitor, 47 pF, 100 V, Mica	128002-470
C4	Capacitor, 100 µF, 25 V, Electrolytic	124010-107
C5	Capacitor, 4700 µF, 25 V, Electrolytic, Radial	123021-478
C6	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C7	Capacitor, 100 pF, 100 V, Ceramic	122016-101
C8	Capacitor, 100 µF, 25 V, Electrolytic	124010-107
C9, C10	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C13-C17	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C19	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C18	Capacitor, 100 pF, 100 V, Ceramic	122016-101
C20, C21	Capacitor, 1000 µF, 25 V, Electrolytic, Radial	123003-108
C22	Capacitor, 1 µF, 50 V, Electrolytic	124001-105
C23-C30, C74	Capacitor, .1 µF, 50 V, Ceramic	122002-104
	Diodes	
CR1	Diode, 1N4001	131048-001
CR2	Diode, 1N5401	131051-002
CR3	Diode, 1N4005	131048-005
CR5	Diode, MV5053, Light Emitting	131027-002
CR6	Diode, 1N100	131053-001
CR7	Diode, 1N4001	131048-001
	Integrated Circuits	
IC1, IC2	Integrated Circuit, 74LS163 A	137114-001
IC3	Integrated Circuit, 74HCT00	137606-001
IC4, IC5	Integrated Circuit, 74LS163 A	137114-001
IC6	Integrated Circuit, 7414	137017-001
IC7	Integrated Circuit, 74LS374	137144-001
IC8	Integrated Circuit, DAC-08	137159-001
IC9	Integrated Circuit, 74LS374	137144-001
IC10	Integrated Circuit, TL082CP	137584-001
IC11	Integrated Circuit, ADOP07CN	137523-001
IC12	Integrated Circuit, 74HCT00	137606-001
L1	Inductor, 3.3 µH	141023-001
	Fuse	
PTC1	Fuse, Current, PTC, .9 A, 50 V	146011-090

Designator	Description	Part No.
	Transistors	
Q1	Transistor, FET, IRF630	133039-001
Q4	Integrated Circuit, 7905	137581-001
Q5	Integrated Circuit, 7805	137596-001
Q6	Transistor, 2N3906	133040-001
	Resistors	
R1	Resistor, 100 K Ω, ±5%. 1/4 W	110000-104
R2	Resistor, 270 Ω, ±5%, 1/4 W	110000-271
R5	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R6, R7	Resistor, 510 Ω, ±5%, 1/4 W	110000-511
R8	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R9	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R10	Resistor, 2.2 K Ω, ±5%, 1/4 W	110000-222
R11	Resistor, 100 Ω, ±5%, 20 W (Acceptable Substitute is part no. 116027-101)	116025-101
R12	Resistor, 68 K Ω, ±5%, 1/4 W	110000-683
R13, R14	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R19, R20	Resistor, 1.2 K Ω, ±5%, 1/2 W	110001-122
R21	Resistor, 22 K Ω, ±5%, 1/4 W	110000-223
R22	Resistor, 2.2 K Ω, ±5%, 1/4 W	110000-222
R23	Resistor, 4.7 K Ω, ±5%, 1/4 W	110000-472
R24, R25	Resistor, 3 K Ω, ±5%, 1/4 W	110000-302
R26	Resistor, 330 Ω, ±5%, 1/4 W	110000-331
R27, R28	Resistor, 4.7 Ω, 1 W	110030-047
R29, R30	Resistor, 348 Ω, 1 W	110029-3480
R31	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R32	Resistor, 47 K Ω, ±5%, 1/4 W	110000-473
R33	Resistor, 100 Ω, ±5%, 1/4 W	110000-101
R34	Resistor, 39 K Ω, ±5%, 1/4 W	110000-393
R35	Resistor, 2.2 Ω, ±5%, 1/4 W	110000-022
R36	Resistor, 348 Ω, 1 W	110029-3480
R37	Resistor, 2.7 K Ω, ±5%, 1/4 W	110000-272
R134	Resistor, 0 Ω, ±5%, 1/4 W	110005-001
	Miscellaneous	
HS1	Heatsink, TDA2030	178190-032
JP1-3	Connector, Rcpt, 2 Ckt	179178-002
J1-J5	Connector, 3 Circuit, Header, .156 Ctr	179213-003
J6	Connector, 26 Circuit, Header, .1 X . 1 Dual	179261-026
JP1-JP3	Connector, 3 Ckt, Header, .100 Ctr	179048-003



Figure 4-14 Brake PCB Assembly
A044817-01 F

Brake PCB Assembly
Parts List

Designator	Description	Part No.
	Capacitors	
C1	Capacitor, 1000 µF, 25 V, Electrolytic	24-250108
C2, C3	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C4	Capacitor, 470 µF, 25 V, Electrolytic	123009-477
C5-C7	Capacitor, .1 µF, 50 V, Ceramic	122002-104
C8	Capacitor, 10 µF, 20 V, Tant	127001-106
C9	Capacitor, .001 µF, 50 V, ±10%	122015-102
C10	Capacitor, .1 µF, 50 V, Ceramic	122002-104
	Diodes	
CR1	Diode, 1N4740, 10 V, 5%, Zener	131009-213
CR2	Diode, MV5053, Light Emitting	131027-002
	Integrated Circuit	
IC1	Integrated Circuit, OPA111	137576-002
	Transistor	
Q1	Integrated Circuit, 7812	137597-001

Designator	Description	Part No.
	Resistors	
R1	Resistor, 10, ±5%, 1/4 W	110000-100
R3	Resistor, 330 Ω, ±5%, 1/2 W	110001-331
R4	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R5	Resistor, 2.2 M Ω, ±5%, 1/4 W	110000-225
R6	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R7	Resistor, 10 K Ω, ±5%, 1/4 W	110000-103
R8	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
R9	Resistor, 270 K Ω, ±5%, 1/4 W	110000-274
R10-R12	Resistor, 1 K Ω, ±5%, 1/4 W	110000-102
	Miscellaneous	
J1	Connector, 9 Circuit, Header, .156 Ctr, Key 3	179213-009

Hard Drivin' Statistics Sheet

Left Coins:		Auto Games:		Champ Laps	
Right Coins:		Error Count:		Champ Wins	
Aux Coins:		Total Games:		Inst Rpls:	
Idle Mins:		Laps by Track:		Rpl Aborts:	
Active Mins:				Rpl Sec:	
Xtnded Plays:		Xtended Games by Track:		Total Credits:	
1-X Games:				Avg Time/Credit:	
2-X Games:		No X Games by Track:			
N-X Games:					

H I S T O G R A M I N F O R M A T I O N

Time	No. of Games	Time	No. of Games	Time	No. of Games	Time	No. of Games
0-99		180-199		280-299		380-399	
100-119		200-219		300-319		400-419	
120-139		220-239		320-339		420-439	
140-159		240-259		340-359		440-459	
160-179		260-279		360-379		460-UP	

G A M E S P L A Y E D B Y D A Y A N D H O U R

Time	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
8:00 a.m.							
9:00 a.m.							
10:00 a.m.							
11:00 a.m.							
Noon							
1:00 p.m.							
2:00 p.m.							
3:00 p.m.							
4:00 p.m.							
5:00 p.m.							
6:00 p.m.							
7:00 p.m.							
8:00 p.m.							
9:00 p.m.							
10:00 p.m.							
11:00 p.m.							
Midnight							
1:00 a.m.							
2:00 a.m.							
3:00 a.m.							
4:00 a.m.							
5:00 a.m.							
6:00 a.m.							
7:00 a.m.							

ATARI®
GAMES

Atari Games Corporation
675 Sycamore Drive
P.O. Box 361110
Milpitas, CA 95035