


GOAL IV

Operation, Maintenance and Service Manual

Amended Table Top Assembly Drawing

For those owning the Goal IV game with all four control knobs located on the table top instead of on the base:

The enclosed Atari drawing #A003870 and parts list #003870 reflect this changed configuration. Please use these materials as aids in servicing the Goal IV game, top-knob version. This drawing and parts list replace those printed in the Goal IV manual, namely #A003838 Bar--Top Assembly. No electrical changes have been made to the game with this knob placement modification.



Drawn	
Checked <i>MJ. 6/24/75</i>	Mech. Eng. <i>Bruce [Signature]</i>
Proj. Eng. <i>AG</i>	Elec. Eng. <i>Eli Shekel</i>
(W.C. TOP) GOAL IV	
	REV. A

Rev.	Description	Date	Apprv.	Rev.	Description	Date	Apprv.
A	PROD REL	6/25/75	<i>AG</i>				

Item	Part Number	Qty.	DESCRIPTION
1	003871	1	Tabletop
2	003877	1	Cover, Tabletop
3	003841	1	Trim, Tabletop
4	A003693	4	Switch, Assembly
5	004015	1	Harness, Top
6	73-77002	8	Pop Rivet
7	75-5548N	4	Bolt, Carriage, 1/4-20 x 3" Lg.
8	82-1606	18	Screw, Wood, Flat Head, #6 x 3/8" Lg.
9	003878	3	Panel, Cover
10	003879	1	Panel, Cover
11	82-8806	16	Screw, Button Head, Socket Cap, #8-32 x 3/8" Lg.
12	75-020S	16	Washer, Flat, #10
13	78-3401	2	3" Chain Bolt (Stanley #1055)
14	003845	1	Chain, Release
15	PART OF ITEM #13	2	Chain Guide
16	72-6824	8	Screw, SM, Self Tapping, Cross Recessed, #8 x 1 1/2" Lg.
17	72-6612	4	Screw, SM, Self Tapping, Cross Recessed, #6 x 3/4" Lg.
18	75-015S	4	Washer, Flat, #1/4
19	75-915S	4	Nut, Hex, #1/4-20
20	003881	4	Washer