

Easy to play, Hard to go through

Continuation Feature

Simple & Neat Sound

Horizontal



MAYA


DIP SW₁

		1	2	3	4	5	6	7	8
DIFFICULTY	EASY	ON	ON	ON					
	HARD	OFF	OFF	OFF					
DEMO SOUND	NO						ON		
	YES						OFF		


DIP SW₂

		1	2	3	4	5	6	7	8
COIN	1 COIN 1 CREDIT	OFF	OFF	OFF					
	1 COIN 2 CREDIT	ON	OFF	OFF					
	1 COIN 3 CREDIT	OFF	ON	OFF					
	1 COIN 4 CREDIT	ON	ON	OFF					
	2 COIN 1 CREDIT	OFF	OFF	ON					
	3 COIN 1 CREDIT	ON	OFF	ON					
	4 COIN 1 CREDIT	OFF	ON	ON					
	5 COIN 1 CREDIT	ON	ON	ON					
TEST MODE	TEST MODE								ON
	GAME MODE								OFF


CONTROL PANEL



CONTROL STICK



FIRING



JUMPING

W I R I N G D I A G R A M
 =====
 (M A Y A)
 =====

SOLDER SIDE	NO.	PART SIDE
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
+12V	5	+12V
	6	
	7	
	8	
	9	
SPEAKER(-)	10	SPEAKER(+)
	11	
GREEN	12	RED
SYNC	13	BLUE
	14	
	15	
COIN 2P	16	COIN 1P
START 2P	17	START 1P
UP 2P	18	UP 1P
DOWN 2P	19	DOWN 1P
LEFT 2P	20	LEFT 1P
RIGHT 2P	21	RIGHT 1P
CHOOSE 2P	22	CHOOSE 1P
ERASE 2P	23	ERASE 1P
HELP 2P	24	HELP 1P
	25	
	26	
GND	27	GND
GND	28	GND

DIP SW1

	1	2	3	4	5	6	7	8
DIFFICULTY	EASY	ON	ON	ON				
	HARD	OFF	OFF	OFF				
DEMO SOUND	NO					ON		
	YES					OFF		

DIP SW 2

	1	2	3	4	5	6	7	8
COIN	1 COIN 1 CREDIT	OFF	OFF	OFF				
	1 COIN 2 CREDIT	ON	OFF	OFF				
	1 COIN 3 CREDIT	OFF	ON	OFF				
	1 COIN 4 CREDIT	ON	ON	OFF				
	2 COIN 1 CREDIT	OFF	OFF	ON				
TEST MODE	3 COIN 1 CREDIT	ON	OFF	ON				
	4 COIN 1 CREDIT	OFF	ON	ON				
	5 COIN 1 CREDIT	ON	ON	ON				
TEST MODE	TEST MODE							ON
	GAME MODE							OFF