

TOPIS
COMPUTER CO., LTD.



 **DUCKSAN**
Ducksan Trading Co., Ltd.


TEL : (02) 337-3029.
FAX : (02) 337-4589. TLX : K33268

2인 팀서 게임 가능

HOW TO PLAY

FOR CHOOSING CHECKER STONE AND MOVING.

FOR CANCEL IN MAKING A BAD CHOICE.




1. PUTTING CURSOR ON CHECKER STONE GOING TO MOVE, AND PUSH THE BUTTON, THEN IT WILL BEGIN TO TWINKLE.
2. AT THIS MOMENT, YOU CAN MOVE CURSOR ONE BLOCK TOWARD ALL DIRECTIONS AND PUSH THE BUTTON, SO CHECKER STONE WILL MOVE WITH COPYING.

IN CASE OF MOVING TWO BLOCK, PLAYER CAN JUMP CHECKER STONE OF COMPETITOR OR HIS OWN. (BUT PLAYER CAN NOT MOVE CHECKER STONE MORE THAN TWO BLOCKS)


MOVABLE AREA WITH COPY CHECKER STONE.

MOVABLE AREA WITH JUMP CHECKER STONE.


THE SEIZABLE AREA OF COMPETITOR'S STONE.



EX. 1



EX. 2



3. IF THERE IS CHECKER STONE OF PLAYER AROUND ONE PLACED, THEY WILL BE TURN INTO PLAY'S.
4. FINALLY THE MAN WHO HAS MANY PIECES OF CHECKER STONE BETTER THAN COMPETITOR, WILL BE WINNER.
5. IN TWO PLAYER, LIKE ABOVE, GAME IS PROCEEDING.

JAMMA CODE

SOLD SIDE	1	COMP SIDE
GND	2	GND
GND	3	GND
+5V	4	+5V
+5V		+5V
	5	
+12V	6	+12V
	7	
	8	COIN COUNTER
	9	
-SPEAKER	10	+SPEAKER
	11	
COLOR GREEN	12	COLOR RED
SYNC	13	COLOR BLUE
	14	GND
	15	
COIN	16	COIN
1P START	17	1P START
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
2P MOVE	22	1P MOVE
2P CANCEL	23	1P CANCEL
	24	
	25	
	26	
GND	27	GND
GND	28	GND



