

PINBELEGUNG FITTER

A (Bestückungsseite)

1
 2 + 5V
 3 + 12V
 4 Sound GND
 5 Video Sync.
 6 n c
 7 Video green
 8 Video GND
 9 n c
 10 n c
 11 n c
 12 1 Play start
 13 1 Player up
 14 1 Player left
 15 1 Player down
 16 1 Player right
 17 1 Player fire
 18 n c
 19 n c
 20 n c
 21 GND
 22 GND

B (Lötseite)

1
 2 + 5V
 3 + 12V
 4 Sound out
 5 n c
 6 n c
 7 Video red
 8 Video blue
 9 n c
 10 Coin Credit
 11 2 Play start,
 12 n cq
 13 2 Player up
 14 2 Player left
 15 2 Player down
 16 2 Player right
 17 2 Player fire
 18 n c
 19 n c
 20 n c
 21 GNC
 22 GNC