

4. NAMES OF PARTS





TABLE 4 Dimensions and Weights






	Width × Length × Height	Weight
Cabinet w/o POP & Coin Chute Tower	1,020 mm × 2,640 mm × 2,000 mm	502 kg
When assembled	1,200 mm × 2,640 mm × 2,200 mm	527 kg

5. ACCESSORIES


When transporting the machine, make sure that the following parts are supplied. Magnetic cards for the recording of play results, and cleaning kits for cleaning the head of the card reader/writer are sold separately. Subsequent purchases of these items can be made by contacting the office listed on this manual or the dealer from whom the product was originally purchased. Be sure to provide the part number(s), name(s), and required number of items.

- Cleaning Kit
601-11050 CLEANING CARD: Package of 30 sheets
- Magnetic Cards
601-11334-01 CARD PACKAGE FZR ENG: Package of 200 Magnetic Cards


TABLE 5 a ACCESSORIES

<p>DESCRIPTION OWNERS MANUAL Part No. (Qty.) 420-6769-01 (1) Note Figures NOTE: Parts not labeled with part numbers are as yet unregistered or cannot be registered. Be sure to handle all parts with care, as some parts are not available for purchase separately.</p>	<p>KEY MASTER 220-5576 (2) For opening/closing the doors</p>	<p>KEY (2) For the CASHBOX DOOR</p>
<p>CLEANING CARD 601-11050 (1) For the periodic maintenance. See Sections 7 and 10. (30 sheets of Cleaning Card)</p>	 <p>The Keys are inside the Coin Chute Door at the time of shipment from the factory.</p>	
	<p>VOL CONT B-5K OHM 220-5484 } (1) 220-5753 } Spare, see Sections 11.</p>	
<p>FUSE 10A 125V 514-5036-10000 (1) Spare, see Section 18.</p>		<p>VOL CONT B-10K OHM W/BD 220-5775 (1) Spare, see Sections 11.</p>
		

ASSY FIBER CABLE (NETWORK CABLE) 10 m
 600-7269-1000 (1)
 Used for the Network Play. See Section 20.



CARTON BOX
 601-11224-01 (1)
 Used for transporting the Game Board.
 See 19-6.



The following Table 5b lists the parts that had been separately packed when the product was shipped from the factory but are necessary when you use the product. These parts will be mounted on the product when installing and assembling it.

TABLE 5 b

POP
 FZR-0013 (1)
 Used for installation. See 1 of Section 6.




POP CARD
 FZR-0020-01 (1)
 Used for installation. See 1 of Section 6.




AC Cable (Power Cord)
 600-7228 } (1) TAIWAN
 600-6729 }
 600-6619-01 (1) HONG KONG
 600-6618 (1) AC 220~240V AREA
 600-6695-01 (1) USA


Used for installation,
 See [4] of Section 6.



WIRE HARN EARTH W/LUG
 M6
 600-6664-02 (1)
 <For TAIWAN>
 Used for installation,
 See [4] of Section 6.




CORD CLAMP
 280-5009-01 (1)
 Used for securing the
 power cord.
 See [4] of Section 6.



SCREW
 000-P00416-W (3)
 Used for securing the GD-ROM DRIVE.
 See [3] of Section 6.




GD CABLE
 600-7247-500 (1)
 Used for connecting between the GD-ROM Drive
 and the DIMM Board. See [3] of Section 6.



TAPPING SCREW
 012-P00408 (4)
 Used for securing the GD-ROM DRIVE.
 See [3] of Section 6.



GD DRIVE BRACKET
 105-5435 (1)
 To be mounted on the GD-ROM drive.
 See [3] of Section 6.




GD SOFT KIT FZR
 610-0650-0007 (1) <ASIA>
 610-0650-0004 (1) <OTHERS>
 GD-ROM software.
 See [3] of Section 6.

CUSHION SPONGE
 601-11137 (1)
 GD-ROM Disc Protector

GD-ROM DISC

DISC CASE
 253-5507



NOTE: When you order the GD-ROM disc only, specify the part number;
 610-0649-0007 (GD SOFT FZR ASIA): ASIA
 610-0649-0004 (GD SOFT FZR): OTHERS


The following Table 5c lists the parts that are separately marketed but are necessary when booting this product's software. When having unpacked the shipping crate, make sure that all the parts in this Table 5c are in the crate. If not so, contact where you have obtained the product.

TABLE 5 c (XKT-0833 : GD-ROM DRIVE KIT)

GD-ROM DRIVE


610-0617 }
610-0617-01 } (1)

Device that loads the software in a GD-ROM disc.
See 6 of Section 6.



GD-ROM DRIVE CARTON BOX (1)

Used for transporting the GD-ROM DRIVE.
See 19-6.



This carton box is a standard accessory of the GD-ROM drive. If you want to obtain the carton box itself separately, specify the part number 601-11031.