

DANGAR

WIRING DIAGRAM

| SOLIDER SIDE |    | PART SIDE   |  |
|--------------|----|-------------|--|
| 1P UP        | 1  | 1P DOWN     |  |
| 1P LEFT      | 2  | 1P RIGHT    |  |
| 1P SHOOT I   | 3  | 1P Shoot II |  |
| 2P UP        | 4  | 2P DOWN     |  |
| 2P LEFT      | 5  | 2P RIGHT    |  |
| 2P SHOOT     | 6  |             |  |
| COIN 1       | 7  | COIN 2      |  |
| GND          | 8  | GND         |  |
| GND          | 9  | GND         |  |
| +5 VOLT      | 10 | +5 VOLT     |  |
| +12 VOLT     | 11 |             |  |
|              | 12 | +12 VOLT    |  |
| +5 VOLT      | 13 | +5 VOLT     |  |
| GND          | 14 | GND         |  |
| GND          | 15 | GND         |  |
| SELECT-1     | 16 | SELECT-2    |  |
|              | 17 | SERVICE SW  |  |
| COUNTER 1    | 18 | COUNTER 2   |  |
| SPEAKER      | 19 | SPEAKER     |  |
|              | 20 | RED         |  |
| GREEN        | 21 | BLUE        |  |
| GND          | 22 | SYNC        |  |

| DIP SW 1           | 1 | 2   | 3   | 4   | 5   | 6   |
|--------------------|---|-----|-----|-----|-----|-----|
| NUMBER OF PLAYER   | 3 | OFF | OFF |     |     |     |
|                    | 4 | ON  | OFF |     |     |     |
|                    | 5 | OFF | ON  |     |     |     |
|                    | 6 | ON  | ON  |     |     |     |
| BONUS PLAYER 20000 |   |     |     | OFF |     |     |
| (1 ST) 50000       |   |     |     | ON  |     |     |
| (AFTER 2ND) 60000  |   |     |     |     | OFF |     |
|                    |   |     |     |     | ON  |     |
| DEMO SOUND WITH    |   |     |     |     | OFF |     |
| WITHOUT            |   |     |     |     | ON  |     |
| TYPE TABLE         |   |     |     |     |     | OFF |
| UP RIGHT           |   |     |     |     |     | ON  |

| DIP SW 2         | 1 | 2   | 3   | 4   | 5   | 6 |
|------------------|---|-----|-----|-----|-----|---|
| COIN 1           |   |     |     |     |     |   |
| 1 COIN 3 CREDIT  |   | OFF | OFF |     |     |   |
| 1 COIN 2 CREDIT  |   | ON  | OFF |     |     |   |
| 2 COIN 1 CREDIT  |   | OFF | ON  |     |     |   |
| FREE PLAY        |   | ON  | ON  |     |     |   |
| COIN 2           |   |     |     |     |     |   |
| 1 COIN 3 CREDIT  |   |     |     | OFF | OFF |   |
| 1 COIN 6 CREDIT  |   |     |     | ON  | OFF |   |
| 2 COIN 3 CREDIT  |   |     |     | OFF | ON  |   |
| 3 COIN 1 CREDIT  |   |     |     | ON  | ON  |   |
| DIFFICULTY EASY  |   |     |     |     | OFF |   |
| HARD             |   |     |     |     | ON  |   |
| SCREEN INVERSION |   |     |     |     |     | X |