



ITEM NO.	PART NO.	DESCRIPTION
1	CQ-1001	ASSY SUB-CABINET
2	CQ-1012	WOODEN BASE
3	CQ-1013	HOLDER
4	CQ-0001	DISPLAY PLATE FRONT
5	CQ-0002	DISPLAY PLATE REAR
6	CQ-0003	HOLDER
7	CQ-1022	PANEL BASE
8	CQ-4000-01	ASSY PWR SPLY
9	CY-1025	AC UNIT
10	200-5187-15	ASSY CLR DSPL 26 TYPE 15K 100V
11	200-5195-15	ASSY CLR DSPL 26 TYPE 15K 100V } いすれか一方使用
12	CQ-1027	BRACKET MASK
	CY-1034	CONN BRKT 36P
14	280-5112	BUSH FOR TV
15	280-5113	COLLAR FOR TV
16	280-5114	SPACER 6.4-25x2
17	117-5039	PLATE ELBC SPEC
18	421-6651	STICKER BUSINESS INFO
19	421-6556	STICKER POSSESSION INFO
20	421-6555	STICKER SEGA INFO
21	421-6571	STICKER DANGER HIGH VOLTAGE
22	421-6516	STICKER EARTH
23	421-6672	STICKER MAIN SW PUSH ON PUSH OFF
24	421-6673	STICKER SERVICE INSTR
26	421-5563	STICKER ARROW
27	421-6891-01	STICKER COIN METER
28	SGR-3042X	EXT BD 36P
29	SGM-1035X	KEY BAG
30	SGM-2875	POLYETHYLENE COVER 750x950x1400
31	SGM-2975	ADJ INSTR SH CLR DSPL (200-5187-15, ナナオ製キニター用)
32	421-7180-91	ADJ INSTR SH CLR DSPL (200-5195-15, 三和電業製キニター用) } いすれか一方使用
	421-7626-91	STICKER SERVICE INSTR
33	421-6682	STICKER SERVICE INSTR
34	CQ-1018	MASK BRACKET
35	CQ-1024	PLATE
36	220-5167-01	COIN ENTRY ¥ 100
37	420-8887-91	OWNERS MANUAL CITY 26
38	117-5140	SERIAL NUMBER PLATE
39	600-5712-91	CONN PLUG 3P & CONN FEM 3P
101	220-5064	MAG CNTR 6 DIG DC 5V
102	509-5156	SW PB IM YELLOW
103	253-5092	CAP SW
	601-6151	CASTER
	029-0031	M SCR PH M6x18
	061-0006	SPR WSR M6
	CQ-6000	CARD SYSTEM UNIT
	978-9	SEGA AERO CITY COM
	540-0006-01	WRENCH FOR TMP SCR DUAL TYPE M4
	540-0007-01	WRENCH FOR TMP SCR DUAL TYPE M4
	DP-1148X	LKG TNG
	421-7295	STICKER ¥ 50