


# GUILTY GEAR ISUKA (DX), KIT PACKAGE CONTENTS (USA)

**A** Main PCB,  
(w/EX I/O board &  
Plastic cover)

Part#: 99-10-010



**B** Game Cartridge, Guilty  
Gear DX (ISUKA)

Part#: 65-90-850



**C** Push Button Assy  
Player 1 & 2

Part#: 99-50-010

Part#: 99-50-011



**D** Push Button Assy  
Player 3 & 4

Part#: 99-50-016

Part#: 99-50-017



**E** Instruction Decal Sheet  
Guilty Gear ISUKA (DX)

Part#: 65-30-210



**F** Marquee, Guilty Gear ISUKA (DX)

Part#: 65-30-100



**G** Push Button Assy  
RED (20 pcs)

Part#: 99-50-001



**H** Joystick Assy, 8 ways (2 pcs)

Part#: 99-50-100



**I** Overlay,

Part#: 99-30-151



**J** Instruction Banner A, GGDGX

Part#: 65-30-211



**K** Manual, GGDGX

Part#: 65-30-300



**L** AAMA Sticker (Green)

Part#: 99-30-750



**M** Instruction Banner B, GGDGX

Part#: 65-30-212



**N** EX I/O 3P&4P Harness (For KIT)

Part#: 65-60-675



**O** Speaker jumper Harness (For KIT)

Part#: 65-60-676



**M** TV jumper Harness (For KIT)

Part#: 65-60-677

