

CAPACITOR FOR MOTOR INSIDE OF HOSE ASSY



NAME OF GAME: BRAVE FIRE FIGHTER

April 12th, 2007

DEAR CUSTOMER:

PLEASE REMOVE CAPACITOR (See Fig.3) WHEN YOU RECEIVE NEW MOTOR ASSY FOR MAINTENANCE PARTS FROM US BECAUSE NEW MOTOR ALREADY INCLUDE CAPACITOR INSIDE OF MOTOR. (SPEAKER MAKES POP NOISE AND SOUND DROPS)

Capacitor




FIG.1 □ NEW MOTOR
(with Capacitor that inside of cap)




FIG.2 □ OLD MOTOR
(No Capacitor)

PLEASE REMOVE THIS CAPACITOR ON HARNESS WHEN YOU EXCHANGE TO NEW MOTOR.




FIG.3 □ INSIDE OF HOSE ASSY MOTOR
(Capacitor on harness)