



## 取扱説明書

### 【仕様】

ゲーム名称 ..... **VASARA2 (バサラ2)**

基板外形 ..... **W310×D238×H70 (mm)**

供給電源仕様 ..... **+5V7A / +12V1A**

※電圧の測定は、基板コネクタ一部分で測定してください。

画面 ..... **縦画面**

**VISGO®**



# vasara2 (バサラ 2)

## DIP SWITCH [ 1 ]

		1	2	3	4	5	6	7	8
GAME STYLE	COIN PLAY	OFF							
	FREE PLAY	ON							
SCREEN POSITION	NORMAL		OFF						
	REVERSE		ON						
TEST MODE	NORMAL			OFF					
	TEST			ON					
DEMO SOUND	ON				OFF				
	OFF				ON				
COIN A	1COIN=1CREDIT					OFF	OFF		
	1COIN=2CREDIT					ON	OFF		
	2COIN=1CREDIT					OFF	ON		
	2COIN=3CREDIT					ON	ON		
COIN B	1COIN=1CREDIT							OFF	OFF
	1COIN=2CREDIT							ON	OFF
	2COIN=1CREDIT							OFF	ON
	2COIN=3CREDIT							ON	ON

## DIP SWITCH [ 2 ]

		1	2	3	4	5	6	7	8
DIFFICULTY	NORMAL	OFF	OFF						
	EASY	ON	OFF						
	DIFFICULT	OFF	ON						
	MORE DIFFICULT	ON	ON						
PLAYERS COUNT	3			OFF	OFF				
	5			ON	OFF				
	2			OFF	ON				
	1			ON	ON				
GAME VOICE	ON					OFF			
	OFF					ON			
VASARA STOCK	2						OFF		
	3						ON		
SUBTITLES	ON							OFF	
	OFF							ON	

\*出荷時の設定は、SW 1・2ともに全てOFFです。





# CONNECTOR DIAGRAM

SOLDER SIDE	NO,	NO,	PARTS SIDE
GND	<b>A</b>	<b>1</b>	GND
GND	<b>B</b>	<b>2</b>	GND
+5V	<b>C</b>	<b>3</b>	+5V
+5V	<b>D</b>	<b>4</b>	+5V
	<b>E</b>	<b>5</b>	
+12V	<b>F</b>	<b>6</b>	+12V
-----	<b>H</b>	<b>7</b>	-----
COIN COUNTER 2	<b>J</b>	<b>8</b>	COIN COUNTER 1
COIN LOCKOUT 2	<b>K</b>	<b>9</b>	COIN LOCKOUT 1
SPEAKER (-)	<b>L</b>	<b>10</b>	SPEAKER (+)
	<b>M</b>	<b>11</b>	
VIDEO GREEN	<b>N</b>	<b>12</b>	VIDEO RED
VIDEO SYNC	<b>P</b>	<b>13</b>	VIDEO BLUE
SERVICE SW	<b>R</b>	<b>14</b>	VIDEO GND
	<b>S</b>	<b>15</b>	
COIN SW 2	<b>T</b>	<b>16</b>	COIN SW 1
2P START	<b>U</b>	<b>17</b>	1P START
2P UP	<b>V</b>	<b>18</b>	1P UP
2P DOWN	<b>W</b>	<b>19</b>	1P DOWN
2P LEFT	<b>X</b>	<b>20</b>	1P LEFT
2P RIGHT	<b>Y</b>	<b>21</b>	1P RIGHT
2P A BUTTON	<b>Z</b>	<b>22</b>	1P A BUTTON
2P B BUTTON	<b>a</b>	<b>23</b>	1P B BUTTON
	<b>b</b>	<b>24</b>	
	<b>c</b>	<b>25</b>	
	<b>d</b>	<b>26</b>	
GND	<b>e</b>	<b>27</b>	GND
GND	<b>f</b>	<b>28</b>	GND

## CONTROL PANEL

## DIP SW POSITION





バ サ ラ  
婆 娑 羅 2

製造・開発元

株式会社 ビスコ <http://www.visco.co.jp>

〒171-0043 東京都豊島区要町3-12-12 大宏ビル3F

TEL : 03-3554-0121 FAX : 03-3554-0150

**VISCO CORPORATION**

TAIKO BLDG.,3RD FLOOR,

3-12-12,KANAME-CHO,TOSHIMA-KU TOKYO 171-0043,JAPAN

TEL : 03-3554-0121 FAX : 03-3554-0150